

# PR Series

Paperless Smart Recorder PR10 – PR20- PR30



## User Manual

PR-Series\_UK\_M1

English Language

Product Rev: 1.0 - Manual Rev: 1.0



## Dear Customer

Thank you for the choice of our product, which we hope will be in accordance with your expectations, because our mission is not just to do the things that serve to a technical function, but we work hard every day and not without difficulty to create something more complete that at the end is conceptually a chest containing many things, our ideas, our ability to do, our business commitment to help in building a new world, even with just a little brick, and all this because we are convinced that companies like ours have a fundamental social role in building a sustainable tomorrow.

Besides we are ambitious and we like to hope that our work can contribute in a small way to your success.

Finally we would like to underline that while working every day for a continuous improvement, we are not perfect and that it could happen that something unfortunately we missed.

If you would aware of something however small and seemingly irrelevant, or even had a suggestion please report it promptly however, with an email addressed to: [sales@ceamgroup.it](mailto:sales@ceamgroup.it)

The sincere and constructive customer feedback is a very important resource for us, and a real help to improve ourselves.

Thank you

Simone Campinoti  
President



# TABLE OF CONTENTS

<b>1.</b>	<b>GENERAL DESCRIPTION.....</b>	<b>11</b>
1.1	UNIQUE FEATURES OF RECORDER.....	11
1.2	COMPARISON OF PR SERIES RECORDERS.....	15
1.3	EXPANDABLE INPUT AND OUTPUT CARDS .....	16
1.4	COMMUNICATION .....	19
1.5	EXTERNAL STORAGE MEDIA.....	19
1.6	SMART MECHANISM .....	20
1.7	ORDERING CODES AND ACCESSORIES .....	21
1.7.1	PR 10 Ordering code .....	21
1.7.2	PR 20 Ordering code .....	23
1.7.3	PR 30 Ordering code .....	25
1.7.4	Accessories: .....	27
1.8	SPECIFICATIONS .....	28
<b>2.</b>	<b>INSTALLATION AND WIRING.....</b>	<b>33</b>
2.1	UNPACKING .....	33
2.2	INSTALLATION .....	33
2.3	PANEL MOUNTING STYLE.....	34
2.4	SETUP INPUT AND OUTPUT .....	39
2.5	WIRING OF THE CARDS .....	45
2.6	RS-232, RS-422, AND RS-485 WIRING.....	52
2.7	EXTERNAL MEMORY CARD:.....	53
<b>3.</b>	<b>BASIC FUNCTIONS OF RECORDERS.....</b>	<b>55</b>
3.1	CONFIGURATION .....	55
3.2	STANDARD AND PLUS VERSION OF FIRMWARE .....	55
3.3	COMMUNICATION WITH THIRD PARTY INTERFACES .....	57
3.4	INFORMATION ACCESSIBILITY THROUGH WEB .....	57
3.5	HANDWRITING MESSAGES ON TREND SCREENS .....	58
3.6	CUSTOM EDITED DISPLAY SCREENS.....	62
3.7	ANALOG INPUT LOG SPEED FLEXIBILITY.....	63
3.8	HIGH SPEED INPUT .....	63
3.9	SYSTEM CLOCK SYNCHRONIZATION VIA INTERNET .....	63
3.10	INCREASED SECURITY IN PASSWORD CONFIGURATION.....	63

3.11	AUTO OUTPUT TO PRINTER .....	63
3.12	EXTERNAL CHANNELS .....	63
3.13	BATCH .....	63
3.14	FDA 21 CFR PART 11 .....	63
<b>4.</b>	<b>CONFIGURATION .....</b>	<b>64</b>
4.1	CHANNEL .....	65
4.1.1	Analog Input.....	65
4.1.2	Digital Input.....	72
4.1.3	Math Channel .....	74
4.1.4	Analog Output .....	88
4.1.5	Digital Output .....	89
4.1.6	External.....	89
4.1.7	Jobs .....	90
4.2	DISPLAY .....	93
4.2.1	Status Bar .....	95
4.3	TIMER .....	96
4.4	CLOCK .....	99
4.5	COMMUNICATION .....	100
4.5.1	Connections .....	102
4.5.2	Commands .....	103
4.5.3	Modbus RTU Master, Example1 .....	104
4.5.4	Modbus RTU Master, Example2 .....	106
4.5.5	Modbus RTU Slave, Example .....	108
4.6	INSTRUMENT .....	110
4.7	SECURITY .....	111
4.7.1	Normal .....	111
4.7.2	CFR-21 .....	112
4.8	DEMO .....	113
4.9	AUTO-OUTPUT .....	113
4.9.1	USB Printer .....	114
4.9.2	Network Printer (LPT1).....	116
4.9.3	Print Historical data.....	117
4.9.4	Print Reports.....	119
4.9.5	Print Snapshot.....	120
4.10	SYSTEM INFO .....	121
4.11	BATCH CONTROL .....	124
4.12	CALIBRATE .....	132
4.13	PROCEDURE TO RESET AND RESTORE FACTORY DEFAULT SETTINGS .....	140

<b>5.</b>	<b>PC BASED SOFTWARE .....</b>	<b>142</b>
5.1	<b>FREE BASIC SOFTWARE.....</b>	<b>142</b>
5.1.1	Requirements .....	142
5.1.2	Operating system .....	142
5.1.3	Software.....	142
5.1.4	Ethernet Configuration .....	146
5.2	<b>DATA ACQUISITION STUDIO SOFTWARE .....</b>	<b>149</b>
5.2.1	Requirements.....	149
	Operating system.....	149
5.2.2	Software.....	149
5.2.3	How to configure Communication Bank .....	150
5.2.4	How to configure Recorder.....	152
5.2.5	Touch Screen .....	153
5.2.6	Ethernet .....	153
5.2.7	Removable Media .....	156
5.2.8	Configuration .....	161
5.2.9	How to view Historical data .....	172
5.2.10	How to view Real time data in PC .....	180
5.2.11	Bank configuration .....	180
5.2.12	Ethernet .....	182
5.2.13	Serial (RS232/422/485) .....	185
5.2.14	View Real time data from Multiple Recorders .....	186
5.3	<b>PANEL STUDIO VERSION .....</b>	<b>187</b>
5.3.1	System Requirements.....	188
5.3.2	Software Installation.....	189
5.3.3	Project status .....	190
5.3.4	Create new project.....	191
5.3.5	Menu bar .....	192
5.3.6	File .....	193
5.3.7	Environment.....	194
5.3.8	Edit .....	196
5.3.9	Format .....	197
5.3.10	View .....	199
5.3.11	Objects .....	201
5.3.12	Project .....	203
5.3.13	Standard bar .....	203
5.3.14	Format bar .....	204

5.3.15	Project Explorer .....	205
5.3.16	Screen .....	206
5.3.17	Tool box .....	209
5.3.18	Enhanced Objects .....	268
5.3.19	Graphics .....	296
5.3.20	Symbol Factory .....	304
5.3.21	Project Tools .....	315
5.3.22	Build.....	315
5.3.23	Build & Offline Simulation .....	316
5.3.24	Stop .....	317
5.3.25	Build & Download .....	317
5.3.26	Download .....	317
5.3.27	Project status .....	319
<b>6.</b>	<b>WEBSERVER.....</b>	<b>320</b>
<b>6.1</b>	<b>REQUIREMENTS .....</b>	<b>320</b>
6.1.1	Hardware .....	320
6.1.2	Operating system .....	320
6.1.3	Browser Requirements.....	320
6.1.4	IP Address Requirements .....	321
<b>6.2</b>	<b>HOW TO CONFIGURE WEB SERVER SETTINGS .....</b>	<b>321</b>
6.2.1	How to Configure Static IP Address .....	322
6.2.2	How to Enable Web Server .....	323
<b>6.3</b>	<b>HOW TO VIEW RECORDER DATA IN PC VIA WEBSERVER:.....</b>	<b>324</b>

## Safety

This recorder is compliant with the requirements of EN61010-1, UL 61010C-1 & CSA C22.2 No. 24-93. The protection provided by the recorder may be impaired if it is used in a manner inconsistent with its intended purpose, or in an environment that exceeds the specifications of the recorder. CEAM Control Equipment is not liable if the customer fails to comply with these requirements.

## Safety Symbols

The following symbols may be seen in the user manual or on recorder labeling.



**Caution**



**Protective Earth**



**DC Supply**

## Safety Notes and Precautions

1. Before any connection is made, the protective earth terminal should be connected first. To avoid making the recorder dangerous under fault conditions, any interruption of the protective Earth conductor inside or outside the recorder is prohibited. Even in the case of a portable unit, the protective earth terminal must remain connected if the recorder is connected to any hazardous voltage.
2. Keep signal and supply voltage wiring separated from one another. If this is impractical, use shielded cables for signal wiring. Double insulation should be used for signal wiring when the recorder is used with hazardous voltage.
3. Do not use the recorder where there is high vibration or a high magnetic field. This could cause damage or error of measurement.

4. All maintenance or repairs should be carried out with power disconnected to avoid personal injury or damage to the unit.
5. In areas with conductive pollution, adequate ventilation, filtering and sealing must be installed.
6. When cleaning the recorder, handle carefully and use soft dry cloth. Avoid the use of abrasives, or any sharp or hard objects which would damage the display.
7. Do not operate the recorder if any part has been removed or disassembled. Consult your nearest dealer at once.

### **Static Electricity**

Appropriate precautions must be taken when handling the recorder. The circuit board components are susceptible to damage caused by electrostatic discharge. Take static electricity precautions while handling and inserting USB memory into the recorder.

.

# 1. General Description

## 1.1 Unique features of recorder

The PR series is a well-designed new generation paperless recorders with many outstanding features as follows:

### **Hardware**


- Three sizes including 4.3", 5.6" and 12.1"
- PR10, with a 4.3" display, with 3 or 6 universal analog inputs and 24 Optional External Channels
- PR20, with a 5.6" display, with 6, 12, 18 or 24 universal analog inputs and 48 Optional External Channels
- PR30, with a 12.1" display, with 6, 12, 18, 24, 30, 36, 42 or 48 universal analog inputs and 96 Optional External Channels
- TFT Color LCD, Touch screen & high resolution
- 100 millisecond sample rate and data logging
- High accuracy 24-bit A-D Analog Input
- 16-bit D-A Analog Output
- Digital input, maximum 100 Hz.
- Plug & play I/O cards (AI, AO, DI, DO) for easy expansion
- On-board SD card slot for Internal memory
- USB slot for external storage
- 171 mm short depth
- Ethernet as standard with optional RS-232 or RS422/RS485 communication
- Two USB Host ports for downloading the data or connect to Printer
- IP65 / NEMA 4X water-resistant




## Firmware and PC Software

- Free Basic software for configuration, Historical viewer
- Extensive Software- Data Acquisition Software for configuration, Historical viewer and Real time viewer
- View Circular Trends in PR30
- Additional Panel Studio Software for editing and customizing displays
- Display values in Digital, Real time trends, Historical trends, Bar graphs etc.
- Real time and Historical alarms
- Event management, Jobs linked with events
- Reports (Daily, Weekly and Monthly)
- Timers, Optional -Counters, Totalizers, Math channels and CFR-21
- Customized messages for alarms
- Alarms by email directly from paperless recorder
- Batch control, log data in batches
- 100 msec. data logging and historical data archival tools
- Display screen rotation
- Dynamic Data Exchange via PC software
- Search data with reference to time and period, then Export to spread sheets
- Data logging by value change or time base
- Start/Stop data logging functions which can be linked with real time clock or events


Historical Viewer in Free and Extensive Software:




## Configuration Editing in either Free or Extensive Software:




## Extensive Software- Data Acquisition Studio with Real-time Viewer:




## Panel Studio Software to Edit Custom Displays:



## Circular Trends in PR30:





## 1.2 Comparison of PR series Recorders

Description	PR10	PR20	PR30
<b>Display Size</b>	<b>4.3"</b>	<b>5.6"</b>	<b>12.1"</b>
<b>Analog Inputs (Maximum)</b>	<b>6</b>	<b>24</b>	<b>48</b>
<b>Math Channels (Maximum)</b>	<b>15</b>	<b>40</b>	<b>60</b>
<b>External Channels (Other devices)</b>	<b>24</b>	<b>48</b>	<b>96</b>
<b>Total Pages</b>	<b>8</b>	<b>20</b>	<b>21</b>
<b>Pens/Page (Maximum)</b>	<b>6</b>	<b>6</b>	<b>10</b>
<b>Batches (Maximum)</b>	<b>1</b>	<b>1</b>	<b>1</b>

### 1.3 Expandable Input and Output cards

The recorder is equipped with rear expansion slots, which work flexibly with the following plug & play I/O cards.

**Analog Input cards** (part number AI206 & AI203): These two cards are used for 3 or 6-channel analog inputs. Each input is isolated from each other to avoid noise and to ensure stable measurement.

**AI206**  
6 AI (6 analog inputs)



**AI203**  
3 AI (3 analog inputs)



**Relay Output card** (RO206): Each card includes 6 alarm relays. Contacts are rated 5 Amp/240 VAC

**RO206**  
6 relay outputs



**Digital Input card** (DI206): Each card includes 6 channels. Logic Low: -5V minimum, 0.8V maximum, Logic High: 3.5V minimum, 24V maximum

**DI206**  
6 DI (6 digital inputs)



**Combination Relay Output and Digital Input Card (RD233):** Each Card includes 3 digital Inputs and 3 Relay Outputs. For Digital Inputs, Logic Low: -5V minimum, 0.8V maximum, Logic High: -3.5V minimum, 24V maximum. For Relay Outputs, the Contacts are rated 5 Amp/240 VAC

**RD233**  
**3 relays + 3DI**



**Analog Output cards (AO206):** Each card includes 6 channels. They are used for 4-20mA, 0-20mA current output, 0-5V, 1-5V, 0-10VDC voltage output.

**AO206**  
**6 AO (6 analog outputs)**




**Note 1:** The IO Cards should not be removed or Inserted to the PR when the Power is ON. This should only be done when the recorder power is OFF.

**Note 2:** For Thermocouple Inputs, a 1 hour warm up is necessary for initial set up.


**Note3:** Information regarding removing the IO Cards from PR.

For removing the IO Card, First remove the metal screws then plastic screws, after that press the lock on the top and bottom of the Card and pull to remove it. Failing to do so will damage the IO Card. Please follow the below pictures for more information.


The Maximum Torque for the metal screw is 3Kg-cm (2.6in-lb) and the Maximum Torque for the plastic screw is 0.8Kg-cm (.7in-lb)



Metal  
Screws



Plastic  
screws



**Note4:** For the PR30, Analog Input card should be inserted in slots 1 to 8 only.  
AI Cards should not be inserted into slots 9 to 16.

**Note5:** Circular Trends are only available for the PR30 mode

## 1.4 Communication

The standard communication interface is Ethernet with protocol IEEE 802.3 – 10/100 Base T. Other options are RS-232 / RS-422 / RS-485.

Details are explained in Chapter 2.6 - RS-232, RS-422, RS-485 wiring

## 1.5 External Storage media

There are two types of External storage for the recorder, SD card and USB. If the recorder is used with **6-channel inputs**, we've made an easy chart to show the maximum days based on available memory.

Log speed	SD card	16GB	32GB
1 second		15, 808 days	31,616 days
10 seconds		158,032 days	316,064 days
120 seconds		1,896,304 days	3,792,608 days

\* The above is an approximation , Each record of data uses 2 or 4 bytes of memory depending on the data type.

For ex: Selected data size = 2 bytes

If the Log Speed (the recording speed of measured data) is set to the fastest speed at 1 second per data, then for a six channels, a 16GB SD Card will last approximately 15, 808 days [16GB / (2 bytes x 24 hours x 60 minutes x 60 seconds x 6 Channels)].

**The following formula** is to calculate how many days a USB disk can do saving before it is full.

***# of days = (The capacity of SD card memory x Log Speed) / (2 x # of hours per day x 60 x 60 x Number of channels)***

***If the User is using USB to store data, to avoid losing recorded data while transferring to PC, it is necessary to insert USB memory back again into the recorder soon after loading recorded data onto PC. Otherwise, data may not be recorded while the USB is absent.***


## 1.6 Smart Mechanism

The recorded data is stored in the manufacturer's special binary format. It is not possible to manipulate or modify the recorded data. This feature fully guarantees the security of the data.

Front View:



Rear View:





## **6 Mounting types, Power Cord & Switch**

- 0: panel mount, no power cord, no power switch
- 1: panel mount, no power cord, power switch
- 2: portable, UL & CSA power cord, power switch
- 3: portable, VDE power cord, power switch
- 4: portable, SAA power cord, power switch
- 5: portable, BS power cord, power switch

## **7 & 8 Special options**

- 00: none
- 01: 16G SD card
- 02: 32G SD card

\*DI- Digital Input



- 5: 6 AO
- 6: 3 relays + 3 DI

## **PR2024 (24 Analog Inputs)**

### **1 Other Inputs and Outputs\***

- 0: none

### **2 Power**

- A: 90-250 VAC, 50/60 Hz
- D: 11-36 VDC

### **3 Communication**

- 0: standard Ethernet interface
- 1: Ethernet + RS-232
- 2: Ethernet + RS-422/485

### **4 Firmware**

- 0: Standard Version
- 1: Plus Version 1 with extra mathematics, external channels, batch & FDA21 CFR Part 11
- 2: Plus Version 2 with editable custom display and Panel Studio software
- 3: Plus Version 3- includes Plus version 1 and 2

### **5 PC Software**

- 1: Free Basic Software of Historical Viewer and Configuration
- 2: Extensive software Data Acquisition Studio  
(Real Time Viewer + Historical Viewer + Configuration)

### **6 Mounting types, Power Cord & Switch**

- 0: panel mount, no power cord, no power switch
- 1: panel mount, no power cord, power switch
- 2: portable, UL & CSA power cord, power switch
- 3: portable, VDE power cord, power switch
- 4: portable, SAA power cord, power switch
- 5: portable, BS power cord, power switch

### **7&8 Special options**

- 00: none
- 01: 16G SD card
- 02: 32G SD card

\*DI- Digital Input

AO-Analog Retransmission Output

### 1.7.3 PR 30 Ordering code

PR3006 (6 Analog Inputs) - □ □ □ □ □ □ □ □ □ □  
PR3012 (12 Analog Inputs) 1 2 3 4 5 6 7 8 9 10  
PR3018 (18 Analog Inputs)  
PR3024 (24 Analog Inputs)  
PR3030 (30 Analog Inputs)  
PR3036 (36 Analog Inputs)  
PR3042 (42 Analog Inputs)  
PR3048 (48 Analog Inputs)

#### 1 Relay Outputs

- 0: none
- 1: 6 Relays
- 2: 12 Relays
- 3: 18 Relays
- 4: 24 Relays

#### 2 Digital Inputs

- 0: none
- 1: 6 Channels
- 2: 12 Channels
- 3: 18 Channels

#### 3 Analog Outputs

- 0: none
- 1: 6 Channels
- 2: 12 Channels

#### 4 Power

- A: 90-250 VAC, 50/60 Hz
- D: 11-36 VDC

#### 5 Communication

- 0: standard Ethernet interface
- 1: Ethernet + RS-232
- 2: Ethernet + RS-422/485

#### 6 Firmware

- 0: Standard Version
- 1: Plus Version 1 with extra mathematics, external channels, batch & FDA21 CFR Part 11
- 2: Plus Version 2 with editable custom display and Panel Studio software
- 3: Plus Version 3- includes Plus version 1 and 2

## **7 PC Software**

- 1: Free Basic Software of Historical Viewer and Configuration
- 2: Extensive software Data Acquisition Studio  
(Real Time Viewer + Historical Viewer + Configuration)

## **8 Mounting types, Power Cord & Switch**

- 0: panel mount, no power cord, no power switch
- 1: panel mount, no power cord, power switch
- 2: portable, UL & CSA power cord, power switch
- 3: portable, VDE power cord, power switch
- 4: portable, SAA power cord, power switch
- 5: portable, BS power cord, power switch

## **9&10 Special options**

- 00: none
- 01: 16G SD card
- 02: 32G SD card

#### 1.7.4 Accessories:

Part no.	Descriptions
AI203	3-channel analog input card (TC, RTD, mA, V, mV)
AI206	6-channel analog input card (TC, RTD, mA, V, mV)
RO206	6-channel relay output card
DI206	6-channel digital input card
RD233	3-channel Relay output and 3-channel digital input card
AO206	6-channel analog output card
IF232	RS-232 communication module
IF485	RS-422/485 communication module
PM201	90-250VAC 47-63Hz panel mount power supply board without power switch for PR10 and PR20
PM202	90-250VAC 47-63Hz panel mount power supply board with power switch for PR10 and PR20
PM203	90-250VAC 47-63Hz portable power supply board with power switch for PR10 and PR20
PM211	11-36VDC panel mount power supply board without power switch for PR10 and PR20
PM212	11-36VDC panel mount power supply board with power switch for PR10 and PR20
PM213	11-36VDC portable power supply board with power switch for PR10 and PR20
PM301	90-250VAC 47-63Hz panel mount power supply board without power switch for PR30
PM302	90-250VAC 47-63Hz panel mount power supply board with power switch for PR30
PM303	90-250VAC 47-63Hz portable power supply board with power switch for PR30
PM311	11-36VDC panel mount power supply board without power switch for PR30
PM312	11-36VDC panel mount power supply board with power switch for PR30
PM313	11-36VDC portable power supply board with power switch for PR30

#### Notes:

- ◆ The rear Slots of the recorder will only accept certain Input or output cards in any combination based on selected model.
- ◆ For example, PR10 has 4 empty slots. But only 3 slots can be used. In one slot, it needs 1 pc. of either a 3 or 6 channel analog input card. The other slot can be used as per the combination showed in the ordering code.
- ◆ The basic PC software is supplied free with the recorder. There is an additional charge for the extensive Data Acquisition Software supplied with communication of RS-232/422/485 or Ethernet.

- ◆ The Ordering Code for various standard model Recorders with an AC supply and without any additional options are as follows:

PR1003- 0A001000  
PR2003- 0A001000  
PR3006- 000A001000

## 1.8 Specifications

### Power:

#### PR10 and PR20:

90-250VAC, 47-63Hz, 52VA, 26W maximum  
11-36VDC, 26VA, 26W maximum

#### PR30:

90-250VAC, 47-63Hz, 110VA, 62W maximum  
11-36VDC, 62VA, 62W maximum

### Display:

PR10: LCD, 480 x 272 pixel resolution, 65K color  
PR20: LCD, 640 x 480 pixel resolution, 65K color  
PR30: LCD, 1024 x 768 pixel resolution, 65K color

### Memory:

256MB storage memory on board.

### Analog Input Cards (AI20X):

**Channels:** AI203 ~ 3 channels, AI206 ~ 6 channels

**Resolution:** 24 bits

**Sampling Rate:** 10 times/ second

**Maximum Rating:** RTD input  $\pm 20V$

T/C and Voltage input  $\pm 65V$

mA input  $\pm 10V$

**Temperature Effect:**  $\pm 0.1\mu V \pm 15PPM$  of reading for all inputs except mA,  $\pm 30PPM$  of reading for mA input

#### Sensor Lead Resistance Effect:

T/C: 0.32PPM of reading/ohm     3-wire RTD: 2.6 °C /ohm of resistance difference of two leads (Based on °C measurement temperature for PT100)

2-wire RTD: 2.6 °C /ohm of resistance sum of two leads (Based on °C measurement temperature for PT100)

**Burn-out Current:** 10uA

**Common Mode Rejection Ratio (CMRR):** 120dB

**Normal Mode Rejection Ratio (NMRR):** 55dB

**Isolation Breakdown Voltage between channels:** 1500VAC min.

**Sensor Break Detection:**

Sensor opened for TC, RTD and mV inputs, below 1 mA for 4-20mA input, below 0.25V for 1-5V inputs, unavailable for other inputs

Sensor Break Responding Time: Within 1 seconds for TC, RTD and mV inputs, 0.1 second for 4-20 mA and 1-5V inputs

### Characteristics:

Type	Range	Accuracy at 25 °C	Input Impedance
J	-120 ~ 1000 °C (-184 ~ 1832 °F)	±1 °C	3.12MΩ
K	-200 ~ 1370 °C (-328 ~ 2498 °F)	±1 °C °	3.12MΩ
T	-250 ~ 400° °C (-418 ~ 752°F)	±1 °C	3.12MΩ
E	-100 ~ 900 °C (-148 ~ 1652 °F)	±1 °C	3.12MΩ
B	0 ~ 1820 °C (32 ~ 3308 °F)	±2 °C (200 ~ 1820 °C)	3.12MΩ
R	0 ~ 1768 °C (32 ~ 3214 °F)	±2 °C	3.12MΩ
S	0 ~ 1768 °C (32 ~ 3214 °F)	±2 °C	3.12MΩ
N	-250 ~ 1300 °C (-418 ~ 2372 °F)	±1 °C	3.12MΩ
L	-200 ~ 900 °C (-328 ~ 1652 °F)	±1 °C	3.12MΩ
U	-200 ~ 600°C (-328 ~ 1112 °F)	±1 °C	3.12MΩ
P	0 ~ 1395 °C (32~2543 °F)	±1 °C	3.12MΩ
W5	0 ~ 2315 °C (32 ~ 4199°F)	±1 °C	3.12MΩ
W3	0 ~ 2315°C (32 ~ 4199 °F)	±1 °C	3.12MΩ
LR	-200 ~ 800 °C (-328 ~ 1472 °F)	±1 °C	3.12MΩ
A1	0 ~ 2500 °C (-32 ~ 4532 °F)	±1 °C	3.12MΩ
A2	0 ~ 1800 °C (-32 ~ 3272 °F)	±1 °C	3.12MΩ
A3	0 ~ 1800 °C (-32 ~ 3272 °F)	±1 °C	3.12MΩ
M	-200 ~ 100 °C (-328 ~ 212 °F)	±1 °C	3.12MΩ
PT50 (α = 0.00385)	-200 ~ 850 °C (-328 ~ 1562 °F)	±0.4 °C	2.0KΩ

PT100	-200 ~ 850 °C	±0.4 °C	2.0KΩ
(α = 0.00385)	(-328~ 1562 °F)		
PT200	-200 ~ 850 °C	±0.4 °C	2.0KΩ
(α = 0.00385)	(-328 ~ 1562 °F)		
PT500	-200 ~ 850 °C	±0.4 °C	2.0KΩ
(α = 0.00385)	(-328 ~ 1562 °F)		
PT1000	-200 ~ 350 °C	±0.4 °C	2.0KΩ
(α = 0.00385)	(-328 ~ 662 °F)		
PT50	-200 ~ 850 °C	±0.4 °C	2.0KΩ
(α = 0.00391)	(-328 ~ 1562 °F)		
PT100	-200 ~ 850 °C	±0.4 °C	2.0KΩ
(α = 0.00391)	(-328 ~ 1562 °F)		
JPT50	-200 ~ 600 °C	±0.4 °C	2.0KΩ
(α = 0.003916)	(-328 ~ 1112 °F)		
JPT100	-200 ~ 600 °C	±0.4 °C	2.0KΩ
(α = 0.003961)	(-328 ~ 1112 °F)		
JPT200	-200 ~ 600 °C	±0.4 °C	2.0KΩ
(α = 0.003916)	(-328 ~ 1112 °F)		
JPT500	-200 ~ 600 °C	±0.4 °C	2.0KΩ
(α = 0.003916)	(-328 ~ 1112 °F)		
JPT1000	-200 ~ 350 °C	±0.4 °C	2.0KΩ
(α = 0.003916)	(-328 ~ 662 °F)		
Cu50	-50 ~ 200 °C	±0.4 °C	2.0KΩ
(α = 0.00426)	(-58 ~392 °F)		
Cu100	-50 ~ 200 °C	±0.4 °C	2.0KΩ
(α = 0.00426)	(-58 ~392 °F)		
Cu50	-180 ~ 200 °C	±0.4 °C	2.0KΩ
(α = 0.00428)	(-292 ~392 °F)		
Cu100	-180 ~ 200 °C	±0.4 °C	2.0KΩ
(α = 0.00428)	(-292 ~392 °F)		
Ni100	-60 ~ 180 °C	±0.4 °C	2.0KΩ
(α = 0.00617)	(-76 ~356 °F)		
Ni200	-60 ~ 180 °C	±0.4 °C	2.0KΩ
(α = 0.00617)	(-76 ~356 °F)		
Ni500	-60 ~ 180 °C	±0.4 °C	2.0KΩ
(α = 0.00617)	(-76 ~356 °F)		
Ni1000	-60 ~ 180 °C	±0.4 °C	2.0KΩ
(α = 0.00617)	(-76 ~356 °F)		
Cu10	-200 ~ 260 °C	±1.0 °C	2.0KΩ
(α = 0.00427)	(-328 ~500 °F)		
+20mA	-26 ~ 26mA	±0.05%	75Ω
+60mV	-122~122mV	±0.05%	3.12MΩ
+200mV	-243~243mV	±0.05%	3.12MΩ
+1V	-1.58~1.58V	±0.05%	3.12MΩ
+2V	-3.16 ~ 3.16V	±0.05%	3.12MΩ
+6V	-6.32 ~ 6.32V	±0.05%	3.12MΩ
+20V	-25.3 ~ 25.3V	±0.05%	3.12MΩ
+50V	-50.6 ~ 50.6V	±0.05%	3.12MΩ
0.4 ~ 2V	-3.16 ~ 3.16V	±0.05%	3.12MΩ
1~5V	-6.32 ~ 6.32V	±0.05%	3.12MΩ

### **Digital Input Card (DI206):**

Channels: 6 per card  
Logic Low: -5V minimum, 0.8V maximum  
Logic High: 3.5V minimum, 24V maximum  
External pull-down Resistance: 1K $\Omega$  maximum  
External pull-up Resistance: 1.5M $\Omega$  minimum

### **Relay Output Card (RO206):**

Channels: 6 per card  
Contact Form: N.O. & N.C. (form C)  
Relay Rating: 5A/240 VAC, life cycles 200,000 for resistive load

### **Analog Output Card (AO206):**

Channels: 6 per card  
Output signal: 4-20mA, 0-20mA, 0-5V, 1-5V, 0-10V  
Resolution: 16 bits  
Accuracy:  $\pm 0.05\%$  of Span  $\pm 0.0025\%$  / $^{\circ}$ C  
Load Resistance: 0-500 ohms (current), 10K ohms minimum (voltage)  
Output Regulation: 0.01% for full load change  
Output Setting Time: 0.1 second (stable to 99.9%)  
Isolation Breakdown Voltage: 1500VAC at 50/60Hz for 1 minute  
Integral Linearity Error:  $\pm 0.005\%$  of Span  
Temperature Effect:  $\pm 0.0025\%$  of Span / $^{\circ}$ C

### **COMM Module (IF232 and IF485):**

Interface: RS-232 (1 unit), RS-485 or RS-422 (up to 247 units)  
Protocol: Modbus Protocol RTU mode  
Address: 1-247  
Baud Rate: 9.6 ~ 115.2 Kbits/sec.  
Measured data Bits: 7 or 8 bits  
Parity Bit: None, Even or Odd  
Stop Bit: 1 or 2 bits

### **Standard Ethernet Communication:**

Protocol: Modbus TCP/IP, 10/100 Base T  
Ports: AUI (Attachment Unit Interface) and RJ-45, Auto- detect capability

#### **Real time clock accuracy vs. temperature inside of housing**

Temperature inside housing	typical error per month
10 ~ 40 $^{\circ}$ C	18 seconds
0 $^{\circ}$ C or 50 $^{\circ}$ C	52 seconds
-10 $^{\circ}$ C or 60 $^{\circ}$ C	107 seconds

## **Environmental & Physical:**

Operating Temperature: 0 ~ 50 °C

Storage Temperature: -30 ~ 70 °C

Humidity: 20 to 90% RH (non-condensing), maximum relative humidity 90% is for ambient temperature up to 38°C decreasing linearly to 50% relative humidity at 50°C

Altitude: 2000 M maximum

Insulation Resistance: 20 M ohms min. (at 500 VDC)

Dielectric Strength: 2300VAC, 50/60 Hz for 1 minute between power terminal and earth

Vibration Resistance: 10-55 Hz, 10m/ s<sup>2</sup> for 2 hours

Shock Resistance: 30m/ s<sup>2</sup> (3g) for operation, 20g for transportation

Operation Position: no inclined restriction

Dimensions: Panel Mount style: 144(W) x 144(H) x 193mm (D) (for PR10/20)  
288(W) x 288(H) x 194mm (D) (for PR30)

Standard Panel Cutout: 137 x 137mm (for PR10/20)  
281 x 281mm (for PR30)

## **Approval Standards:**

Safety: UL61010C-1, CSA C22.2 No. 24-93

CE: EN61010-1 (IEC1010-1) over voltage category II, Pollution degree 2

Protective Class: IP 65 front panel for indoor use,  
IP 20 housing and terminals

EMC:

Emission: EN61326-1 (EN55022 class A, EN61000-3-2, EN61000-3-3)

Immunity: EN61326-1 (EN61000-4-2, EN61000-4-3, EN61000-4-4,  
EN61000-4-5, EN61000-4-6, EN61000-4-8, EN61000-4-11)

## 2. Installation and wiring

### 2.1 Unpacking

If any damage is found while unpacking, the user should contact the local representative at once. It is suggested that the special packaging is retained for possible future requirements.

### 2.2 Installation



**Remove stains from this equipment using a soft, dry cloth. Do not use harsh chemicals, volatile solvents such as thinner or strong detergents to clean the equipment in order to avoid deformation.**



The recorder is designed for indoor use and not in any hazardous area. It should be kept away from shock, vibration, and electromagnetic fields such as variable frequency drives, motors and transformers.

It is intended to operate under the following environmental conditions:


Pollution Degree Level II	IEC1010-1(EN61010-1)
Temperature	0 ~ 50 °C
Humidity	20 ~ 90 % RH (non-condensing)
Power	90 ~ 250 VAC, 50/60 Hz or 11-36VDC
Altitude	2000M maximum

## 2.3 Panel mounting style

PR10:




### Panel Cut Out Dimensions




**PR20:**


Front Side



### Right Side




### Panel Cut Out Dimensions




PR30:


Front Side



Right Side




## Panel Cut Out Dimensions



### Note:

- ◆ Do not over tighten mounting clamp screws that could result in distortion of the case.
- ◆ There is no mounting angle restriction.

### Portable styles:



## 2.4 Setup input and output

### Analog input cards (part numbers AI206 and AI203)

**AI206 and AI203** are analog input cards in 3 and 6 channels respectively. Each card includes universal inputs of TC (J, K, T, E, B, R, S, N, L, U, P, W5, W3, LR, A1, A2, A3, and M), RTD, mV, mA, V. The accepted input types and sensor range for each type are listed in clause 1.8 of chapter 1. Plug the card into the rear slot then power on. The recorder will automatically detect the card and display the specific input type, then show its location in a specific slot when the user is in Configuration Mode.

To select a specific input, please press menu and then the Config button to get into the configuration window. In the configuration window, press up/down and enter key to select AI to get into AI setting window. In the AI setting window, move the selected focus to the item "Type" under the node "Sensor", then press the enter key to select the desired sensor type. Press OK when finished. All other items are similar to set up. The item "Events" can be added to do further control.





Figure 2 – 15 (AI206)

## Relay Output card (RO206) / 6 relay alarm card

The relay output card includes 6 relays rated 5 Amp/240 VAC each. Plug the card into a rear slot and power on the recorder. The recorder will automatically detect the card and display the output type and its location in a specific slot in **System Info** mode while doing the configuration.


To set up the relay output card, please press **menu** and then the **Config** button to get into the configuration window. In the configuration window, press up/down and enter key to select DO and to get into the DO setting window. In the DO setting window, the setup steps are similar to AI. The item "Reverse" is to reverse the output status.



## Digital Input card (DI206)


This card includes 6 channels of event inputs. As above, plug the card into rear slot and power on the recorder. The recorder will automatically detect it, and then display the input type and its location in a specific slot in **System Info** mode while doing the configuration.

To set up the digital input card, please press **menu** and then the **Config** button to get into the configuration window. In the configuration window, press up/down and enter key to select DI and get into the DI setting window. In the DI setting window, the setup steps are similar to AI. The item "Type" is for the user to decide if this channel will have a logic level or Pulse Counter input. If you select Pulse Counter, the item "Frequency" will appear for you to select input frequency (100Hz, ). The item "Events" can be added to do further control.



### Combination Digital Input and Output card (RD233)

This card includes 3 relays rated 5 Amp/240VAC each and 3 Channels of Digital Inputs. As above, plug the card into rear slot and power on the recorder. The recorder will automatically detect it, and then display the input type and also a Relay. The first 3 combination are for relays (Terminal 1 to 9) and last 3 combination are for Digital inputs (Terminals 10 to 18). The setup is similar to relay output card and digital input card.



## Analog output cards (AO206)

These cards are 6-channel current output cards. They are used to retransmit process values to other devices like meters, controllers, ect.

To set up the analog output card, please press the menu and then the Config button to get into the configuration window. In the configuration window, press the up/down and enter key to select AO. This will get you into the AO setting window. In the AO setting window, the setup steps are similar to AI. The item "Type" is to decide whether to output current or voltage. The item "Output" is to select the output range for current or voltage (0-10, 4-20mA, ect.). The item "Expression" is a math expression field where the user can input an expression to control the output value.




**Note 1:** The IO Cards should not be removed or Inserted to the PR when the Power is ON. This should be carried out in the Power OFF Condition only.


**Note 2:** In the PR30, the Analog Input card should be inserted in slots 1 to 8 only. It should not be inserted in slots 9 to 16.

**Note 3:** The below pictures explain how to install a new AI card into a recorder slot:

**Step 1:** Insert the AI card into the empty slot and insert the screws into the plastic nuts as shown. The Maximum Torque is 0.8Kgf-cm (.7in-lb)



**Step 2:** Insert the IO board in slot as shown below and tighten the metal screws. The Maximum Torque for the metal screw is 3Kg-cm (2.6in-lb)



**Note 4:** For some industries who prefer/favour circular displays, PR30 can offer this unique feature and set the display speed for each page/circle in 30 minutes, 1, 2, 4, 8, 12 hours, or 1, 2 days, or 1, 2, 4 weeks.


**Note 5: Calibrate:** Sometimes the field calibration is required for high accuracy. In this case, a qualified engineer can do the necessary calibration.

## 2.5 Wiring of the cards




### Wiring Precautions


1. Care must be taken to ensure that the maximum voltage rating specified on the label is not exceeded.
2. For the panel-mount version, it is recommended that near an external fuse or an external switch rated at 2A/250 VAC should be used.
3. Beware not to over tighten the terminals screws. The torque should not exceed 0.4 N-m (3.6 Lb-in or 4.0 Kg F-cm).
4. With the exception of the thermocouple wires, all wires should be stranded copper conductor with maximum gauge of 18 AWG.
5. Connect a grounding conductor with 1.6mm diameter minimum to provide protective grounding prior to turning on the equipment.




Analog Input Card AI206




**Analog Input Card AI203**




Relay output card (RO206)



Digital input card (DI206)




Relay output and digital input card (RD233)



Analog output card (AO206)

## 2.6 RS-232, RS-422, and RS-485 wiring

### RS-232 Wiring



### Configuration of The RS-232 Cable






Figure 2 – 24

### RS-422 Wiring




## RS-485 Wiring



## 2.7 External Memory Card:

There are two types of external storage for the User. One is the SD card and the other is USB memory. There are two slots for inserting USB memory, one in the front and the other on the rear side of the recorder. If bigger capacity USB memory is required, the user may buy it locally. The SD card slot is in the front side. Please see the below figures for more information.



**Note:**


- ◆ To read measured data and events on USB memory and SD card Memory, it is necessary to install either the free basic software or the Extensive Data Acquisition software on PC first.
- ◆ Power should be turned off while inserting input and output cards. It is not recommended to insert input or output cards while the unit is powered on.

### 3. BASIC FUNCTIONS OF RECORDERS

In this chapter we will be briefly explaining the functions that are available in the recorder.

#### 3.1 Configuration


The configuration in the recorder follows a tree type layout. This makes it easy for users to go through the different sub menus easily and to not miss any setting.




#### 3.2 Standard and Plus Version of Firmware

The standard version of firmware will have only Input configuration, and does not include Math, External channels, Custom Edited Display, Batch, or FDA CFR part11 functions. However, the plus version includes all the above listed functions.

**Math:** It includes Math, Counter & Totalizer.



Math Expression is keyed in an easy way.




### 3.3 Communication with Third Party Interfaces

The Recorder has the flexibility to communicate with Third party Interfaces via protocols such as Modbus TCP/IP or Serial connections as either a Modbus Master or Modbus Slave. The detailed settings related information can be found in Chapter 4, Configuration, Section 4.5.

### 3.4 Information Accessibility through WEB

Web Server:

The Recorder Trend and Digital data can be viewed in any place in the world if we have Web Server connectivity. For this the Recorder should be connected to Internet with a fixed IP address provided by the Internet Service provider.



Email:


All Important Data events can sent as an email. The detailed settings related information can be found in Chapter 4, Configuration, Section 4.5.

### 3.5 Handwriting Messages on Trend Screens


Handwriting Messages on Trend Screens is very handy for process associates to highlight important events.

The User can write handwritten messages using a stylus on Historical Trend screens. This is shown in the below picture.


When the User navigates through  (Menu) -  $\rightarrow$  History  $\rightarrow$  Page 1, as shown in the below screen.




If the User wants to write a message, they can press the pen symbol as shown in the red square in the screen below




Then using the stylus, the User can write any message in Historical Trend Pages as shown below.




If the User wants to change the width of the written message, he/she can choose the width of pen as shown in the screen below. The menu to change the width is shown by the arrow pointing to the red box.




If the User wants to change color of the pen, he/she can change it by pressing the menu shown in the red box in the picture below.




If the User wants to erase part of a message, he/she can do this by pressing the menu (shown in the red box in the picture below), and erase part of the message.




If the User wants to undo part of a message, he/she can do this by pressing the undo symbol (shown in the red box in the picture below). This will undo the last part of the message.



If the User wants to delete the written message, he/she can this do by pressing the delete symbol (shown in the red box in the picture below), and this will delete the written message.




If the User wants to save the written message, he/she can do this by pressing the “save” symbol (shown in the red box in the picture below). This will save the written message.



### 3.6 Custom Edited Display Screens

(We call it a Custom Page on the device and Custom Page Editor on PC software)

In Plus versions, the PC software Panel Studio allows users to have custom edited displays linked with Analog and Digital Tags.



### **3.7 Analog Input Log Speed Flexibility**

The Analog input can be logged at various speeds such as 100ms, 1, 2, 5, 10, 20, 50 Dot/sec and 1 or 2 dot/min. The User has a lot of flexibility in logging speeds.

### **3.8 High Speed Input**

The Digital input can be accessed as normal Logic or a High frequency pulse.

### **3.9 System Clock Synchronization via Internet**

The Recorder System clock can be synchronized via internet and Summer Saving Time can be defined. The detailed settings related information can be found in Chapter 4, Configuration, Section 4.4.

### **3.10 Increased Security in Password configuration**

The password can be configured as normal or CFR-21. For normal, there is only one password defined but for CFR-21 three 9 levels of password definition. The related settings information can be found in Chapter 4, Configuration, Section 4.7.

### **3.11 Auto Output to Printer**

The daily or shift reports data can be printed automatically by a Printer. The related settings information can be found in Chapter 4, Configuration, Section 4.9.

### **3.12 External Channels**

Besides AI and DI inputs, the Recorders can accept inputs through Modbus communication. The PR10, PR20, and PR30 can have a maximum of up to 24, 48 and 96 channels respectively. The related settings information can be found in Chapter 4, Configuration, Section 4.1.6.

### **3.13 Batch**


Using this function, the recorded data can be stored in batches per shift. This makes it easy for the production personnel, and for quality and quantity management.

### **3.14 FDA 21 CFR PART 11**

This feature is meant to comply with U.S. Food and Drug Administration with human health concern. When this feature is enabled, the recorded data cannot be manipulated.

## 4. CONFIGURATION

Press  ("Menu"), then the "More" soft button to enter Configuration mode. A vertical list appears with a provision to configure Channel, Tools, Message, Display, Instrument, Security, Auto-Output, Demo, and system Information. In addition, the Save, Load, Default and Home soft buttons also appear.



### Soft buttons



Enter key



Up directional key



Down directional key



Home key

Various options are available to enter into configuration mode

Option-1: Select the mode by pressing up & down directional keys, then press "Enter" key

Option-2: Select the required mode directly with a touch, then press "Enter" key

Option-3: Select the required mode by pressing the mode two times quickly, it is same as a double click from a mouse

**Save:** Save configuration from the recorder to a USB Stick or an SD Card.

**To read the configuration from a USB Stick for the first time or any time the configuration has been changed, it is important to press the “Save” soft button to save configuration changes to the USB Stick or SD Card beforehand.**

**Load:** Load configuration from a USB stick or SD Card to the recorder.

**Default:** If the configuration is set incorrectly, “Default” is a useful key to recall the default settings for the analog input card inserted into rear expansion slot.

**Home:** Returns the User to the home page.

## 4.1 Channel


Path:  (Menu)-More-Config-Channel

AI  
DI  
Math  
AO  
DO  
External

This section is to configure different type of channels. Analog Input (AI), Digital Input (DI), Math, Analog Output (AO), Digital Output and External device channels.

### 4.1.1 Analog Input

After entering the Configuration mode, in “Channel”, select “AI”, then Press the “Enter” key to get into Analog Input Channel mode. It displays the Analog input **AI1** as the first analog input channel configuration page. Press directional keys < > at the bottom to select other channels. Press directional keys ↑ ↓ on the right hand side to select the column. **After completing Configuration, press “Back” soft button, then press “Home” soft button to return to main display. All configurations will be saved automatically.**



**Copy:** For example, to copy the channel configuration from channel 1 to channel 2, select the source channel, in this case AI1 (or whatever the channel is named), press on “Copy” button. Now, a “Paste” button will get enabled, go to target channel, say channel 2, and then press on “Paste” button.

**Name:** Enables the User to define the name for each channel with a maximum of 18 characters.

Select “Name”, then Press “Enter”, soft button, a keyboard with several keys appear. Press “Shift” to select special characters. Press “Caps” to select capital letters. Press soft key “OK” after entering a new channel name.

**Desc:** The description about a specific channel on the display.

**Type:** Option available to enable or disable the channel from selection

**Filter:** It is to reduce the noise of input signal before sampling. It is possible to select range from 1 to 16 sec. It is a soft filter available to reduce fast variation of analog inputs. It gives a moving average value. For example, if the filter value is set as 5 sec for AI1, it means all the samples collected in the last 5 sec shall be averaged, and the value is available to record as per Log method.

**Log:**

**Data Type:** 2 byte

2 byte range: -32767 to +32767

**Trigger:** Two options are available

- a) Disable: Select disable while the recording of a specific channel is not required at this time
- b) Enable: Select Enable while the recording of a specific channel is required at this time

**Method:** This is the method of logging measured data. Select the column and press "enter". Then choose the Log method of Instant, Average, Minimum or Maximum data.

**Instant:** logging the last measured data at the sampling interval

**Average:** logging the averaged measured data at the sampling interval


**Minimum:** logging the minimum measured data at the sampling interval

**Maximum:** logging the maximum measured data at the sampling interval

**Speed:** It is the logging speed (recording speed) of measured data. Select Log Speed column, then choose one of the following

- 100ms/Dot
- 1 Sec/Dot
- 2 Sec/Dot
- 5 Sec/Dot
- 10 Sec/Dot
- 20 Sec/Dot
- 30 Sec/Dot
- 1 Min/Dot
- 2 Min/Dot


(Auto)Set Jobs under Events



### Sensor

- Type: Thermocouple K Type, °C
- Unit: °C
- Range: -200.0~1370.0

**Type:** Select the sensor input type for the Channel.



- RTD JPT100 Type
- RTD RTD1 Type
- Milli-Volts
- Volts
- Current

**Unit:** The engineering unit of input.

**Range:** Select based on Sensor type

Select

-200.0~1370.0

-200~1370

**-200.0~1370.0**

Sensor

Type: Milli-Volts

Unit: mV

Range: 0~1000

Select

0~1000

0~60

**0~1000**

-60~60

Sensor

Type: Volts

Unit: V

Range: 0~5

Select

0~5

0~10

**0~5**

1~5

-2~2

-20~20

Sensor

Type: Current

Unit: mA

Range: 4~20

Select

4~20

0~20

**4~20**

-20~20

**Scale:** Appears only for linear inputs Ex: mV, Voltage, current etc..

Scale  
Unit: °C  
Low: -120.0  
High: 1000.0

**Offset:** It is offset value to correct the sensor error.

**Gain:** It is a multiplier to correct the sensor error.  
The correct value = (the process value x gain) + offset

## Events

Events are frequently used for Alarm purposes. Events can also be used for digital outputs (DO), Timer, Totalizer, Counter or Report.

Maximum five events are possible to set for each Analog Input  
Press "Add" to add new event  
Press "Remove" to remove selected event

Events  
Add  
Remove  
1  
Type: H  
SetPoint: 776.0  
Log: Log Alarm  
Job1: No Action  
Job2: No Action  
Hysteresis: 0.0

Type: There are various types of H, L, HH, LL, Dev+, Dev-, and Error to be selected for a job  
or Alarm purpose

**H:** High limit. When the process is over high limit, the alarm or job is actuated.

**L:** Low limit. Any the process is lower than low limit, the alarm or job is actuated

**HH:** High high limit, to set up another limit higher than high limit for double warning.

**LL:** Low low limit, to set up another limit lower than low limit for double warning.

**Dev+:** Trigger event on positive deviation of process value. The job or alarm is activated when process value is deviated by greater than the setpoint+the process value.

For example:

Set point =10

At 10.00.01 Hrs, Tag1=40

At 10.00.02 Hrs, Tag1 = 51

Then, job or alarm is activated

**Dev-:** Trigger event on negative deviation of process value .The job or alarm is activated when the process value is deviated by less than the set point-the process value.

For ex: Set point =10

At 10.00.01 Hrs, Tag1=40

At 10.00.02 Hrs, Tag1 = 29

Then, job or alarm is activated.

**Error:** On channel error, an alarm or job is activated

**Setpoint:** To set up the process value for actuating Job1 and /or Job2

## Alarm

**Log Alarm:** Record alarms

**Log Alarm (Auto Ack):** Record alarms and acknowledge automatically

**Log Event:** Record events

**Job1, Job2:** When an event occurs, the task to be performed is called the job. A typical example is to trigger **an alarm buzzer** in the event of a high temperature. Each pen can accept five different types of events (or alarms) and each event can create two jobs. Please note that a job under Event is different from a job created by pressing the **Operate** key. The former is actuated by an event, and the latter is actuated by manual control, no event necessary.

**Note:** Please refer to the section “Jobs” for full details about various jobs available

**Hysteresis:** To avoid it been activated too often, the Log Alarm or relay can set for no reaction. Hysteresis value can be defined for the event trigger set point

### Example1

If the temperature is increased to more than 120 °C, log alarm and switch on digital output 1. When the temperature is decreased to less than 80 °C, log the alarm and switch off the digital output1.

Setting of events for the analog input in the channel configuration is as follows..


**Events**

<ul style="list-style-type: none"><li>— Add</li><li>— Remove</li><li>— 1<ul style="list-style-type: none"><li>— Type: H</li><li>— SetPoint: 120.0</li><li>— Log: Log Alarm</li><li>— Job1: DO Latch On_DO1</li><li>— Job2: No Action</li><li>— Hysteresis: 0.0</li></ul></li></ul>	<ul style="list-style-type: none"><li>— 2<ul style="list-style-type: none"><li>— Type: L</li><li>— SetPoint: 80.0</li><li>— Log: Log Alarm</li><li>— Job1: DO Latch Off_DO1</li><li>— Job2: No Action</li><li>— Hysteresis: 0.0</li></ul></li></ul>
--	---

### 4.1.2 Digital Input

Path:  (Menu)-Config-DI

After entering the Configuration mode, in the Channel, select DI then Press the “Enter” soft button to get into Digital Input Channel configuration page.



**Name:** Define the name for the Digital Input Channel. A maximum of 18 characters is allowed for the name.


**Description:** Define detail description for the channel.

**Type:** Logic Level

Logic Level: This selection activates digital logic, which is either one or zero with low frequency which is less than 1Hz, such as an external relay.

Pulse Counter: With this selection, we can feed high speed inputs (high Frequency, up to 100Hz)

Select Logic Level and press “Enter” key



**Events:** A maximum of 2 events are supported for every digital Input channel. A maximum of two jobs can be configured for each event.

*\*Note: Events will not appear if Logic Level selected as Pulse Counter*

**Add:** Press “Add” to add events to the Digital Input

**Remove:** Press “Remove” to remove events from the Digital Input

**Type:** Select Low, L or High, H


**Job1, Job2:** To configure a Job, select Job1, then press the Enter button. It will show a list of all the available jobs. Select the required Job.

Note: Number of digital inputs shown on the DI screen depends on number of Digital input cards inserted in the paperless recorder.

Sample applications of Digital input ...

After pressing a “Start” switch, latch ON Digital Output1  
After pressing a “Pause” switch, latch Off Digital Output1  
Start Timer, Stop Timer  
Reset Totalizer, Reset Counter  
Reset MaxMinAve values of all the channels etc..

It is possible to display Digital input status via status bar on any page in the paperless recorder. If digital input is not enabled, it shows as “Low”. Presence of an enabled digital input shall be shown as “High”. See the picture below. To configure status bar, refer section “Display”



Digital Input status can also monitored from the  (Menu). Press “Status” and then select “DI”, it will show the Digital Input Status as follows.

Menu		Status		DI	
DI	DO	AO	Counter	Totalizer	
No	Name			Value	Desc
1	DI1			Hi	Tank1 Level switch high
2	DI2			Low	Tank2 Level Switch High


### 4.1.3 Math Channel

Maximum no. of Math channels in various PR series Recorders are as follows

PR Recorder	PR-10	PR-20	PR-30
Maximum Math Channels	15	40	60

Path:  (Menu)-More-Config-Math

After entering the Configuration mode, in Channel, select Math, then Press the “Enter” soft button to get into Math Channel configuration page.



**Name:** Define the name of the Math channel

**Desc:** Define the detail description for the channel name


**Type:** Specify either Math, Totalizer or Counter

Note: Based on selection at “Type”, configuration details will be changed. For ex: Type=Math has different configuration details compared with Type = Totalizer or Type = Counter

**Log data type, Trigger, Method, Speed:** Same as Analog Input

Press **Back** key and then press “**Home**” soft button go to Real time display and memorize the Math settings.

Enter Expression column, it appears Source, Operator and a keyboard.



The Source covers all available Analog inputs, Digital Inputs, Math inputs, external channels.

The Operators are mathematical expressions described below.

Use Source, Operator and keyboard to define the Math equation.


Scale  
 Unit: Tons  
 Transformation: Value  
 Table: Point 1 to 8  
 Range: 0 ~ 170

**Transformation:** Select disable, value or Math channel. This function mainly used to display process values obtained from Non-linearization table

**Table:** Select disable, value or Math channel

Maximum 64 rows can be entered in the Transformation table

Ex: A chemical tank has a non-linear shape. The level is 0 to 1400 cms. The Recorder should display 0 to 170 Tons as per following table



Add: Press “Add” soft button to add a new row into the Transformation table

Delete: Press “Delete” soft button to delete existing row from the Transformation table

Copy: Press to copy existing row in the Transformation table to create a duplicate entry

Mode: Press to toggle between Input and Output entries in the Transformation table

Up & Down: To navigate among rows in the Transformation table

### 4.1.3.1 Math Expression

Expressions	Mathematics Functions
+	Addition
-	Subtraction
*	Multiplication
/	Division
SIN(x)	$\sin(x)$
COS(x)	$\cos(x)$
EXP(x)	$e^x$
SQRT(x)	Square root of x
LN(x)	$\log_e(x)$
LOG(x)	$\log_{10}(x)$
ABS(x)	Absolute of x
POW (x,y)	$x^y$
ROUND(x)	The closest integral number to x
HI(x,y)	The bigger value between x and y
INV(x)	$1/x$
TG(x)	$\tan(x)$
CTG(x)	$1/\tan(x)$
ASIN(x)	$\sin^{-1}(x)$
ACOS(x)	$\cos^{-1}(x)$
ATG(x)	$\tan^{-1}(x)$
x%y	Remainder of x/y
x^y	$x^y$

#### 4.1.3.2 Math Example-1

##### Relative Humidity – PR20 Math application

\*How to Calculate Relative Humidity - Theory

Requirement: Two Analog Inputs, Type: RTD

AI1: To measure dry bulb temperature

AI2: To measure wet bulb temperature

First calculate the saturation vapor pressure (E) for both the dry-bulb (Td) and wet-bulb (Tw) temperatures using the following equations:

$$E_w = 0.61078 * \text{EXP}((17.269 * T_w) / (T_w + 237.3)) * (T_d - T_w)$$

$$E_d = 0.61078 * \text{EXP}((17.269 * T_d) / (T_d + 237.3)) * (T_d - T_w)$$

In the above equations the temperatures units are Celsius and the saturation vapor pressure units are millibars. The function "EXP" is the exponential and not raising something to an exponent.

Then calculate actual vapor pressure (Ea) using the following equation:

$$E_a = E_w - 0.63 * (T_d - T_w)$$

Relative Humidity is then calculated using the following equation:

$$RH = (E_a / E_d) * 100$$

The units of relative humidity are in percent.

Here is an example of the using the equations:

Assume that your dry-bulb temperature (Td) = 40 C and your wet-bulb temperature (Tw) = 30 C.

$$E_w = 0.61078 * \text{EXP}((17.269 * T_w) / (T_w + 237.3)) * (T_d - T_w)$$

$$E_w = 0.61078 * \text{EXP}((17.269 * 30) / (30 + 237.3)) * (40 - 30)$$

$$E_w = 42.4262 \text{ millibars}$$

$$E_d = 0.61078 * \text{EXP}((17.269 * T_d) / (T_d + 237.3)) * (T_d - T_w)$$

$$E_d = 0.61078 * \text{EXP}((17.269 * 40) / (40 + 237.3)) * (40 - 30)$$

$$E_d = 73.7416 \text{ millibars}$$

$$E_a = E_w - 0.63 * (T_d - T_w)$$

$$E_a = 42.4262 - 0.63 * (40 - 30)$$

$$E_a = 36.1262 \text{ millibars}$$

$$RH = (E_a / E_d) * 100$$

$$RH = (36.1262 / 73.7416) * 100$$

$$RH = 48.99 \%$$

\* End of Theory

5 Math channels are required to calculate one RH.

Td = AI1, analog input for dry bulb temperature (PT100)

Tw = AI2, analog input for wet bulb temperature (PT100)

Math1 = EXP ((17.269\*AI1)/ (AI1+237.3))

Math2 = Ed1 = 0.61078\*Math1\*(AI1-AI2)

Math3 = EXP ((17.269\*AI2)/ (AI2+237.3))

Math4 = Ew1 = 0.61078\*Math3\*(AI1-AI2)

Ea = Ew - 0.63 \* (Td - Tw)

Math5= RH1 = ((Math4-0.63\*(AI1-AI2))/Math2)\*100

Name: Math1  
Desc: Math Channel 1  
Type: Expression  
Log  
Expression: EXP((17.269\*AI1)/(AI1+237.3))

Name: Math1  
Desc:  
Type: Math  
Log  
DataType: 4 Byte  
Value Range: -3.4E+38 ~ 3.4E+38  
Trigger: by Time  
Method: Instant  
Speed: 1 Sec/Dot  
Expression: EXP((17.269\*AI1)/(AI1+273.3))

Name: Math2  
Desc:  
Type: Math  
Log  
DataType: 4 Byte  
Value Range: -3.4E+38 ~ 3.4E+38  
Trigger: by Time  
Method: Instant  
Speed: 1 Sec/Dot  
Expression: 0.61078\*Math1\*(AI1-AI2)

Name: Math3  
Desc:  
Type: Math  
Log  
  DataType: 4 Byte  
    Value Range: -3.4E+38 ~ 3.4E+38  
  Trigger: by Time  
  Method: Instant  
  Speed: 1 Sec/Dot  
**Expression:  $\text{EXP}((17.269 \cdot \text{AI2}) / (\text{AI2} + 273.3))$**

Name: Math4  
Desc:  
Type: Math  
Log  
  DataType: 4 Byte  
    Value Range: -3.4E+38 ~ 3.4E+38  
  Trigger: by Time  
  Method: Instant  
  Speed: 1 Sec/Dot  
**Expression:  $0.61078 \cdot \text{Math3} \cdot (\text{AI1} - \text{AI2})$**

Name: Math5  
Desc:  
Type: Math  
Log  
  DataType: 4 Byte  
    Value Range: -3.4E+38 ~ 3.4E+38  
  Trigger: by Time  
  Method: Instant  
  Speed: 1 Sec/Dot  
**Expression:  $((\text{Math4} - 0.63 \cdot (\text{AI1} - \text{AI2})) / \text{Math2}) \cdot 100$**

Now, in Math5, you will get Relative humidity in %


Five events are supported for every Math channel and two jobs are available in every event, the same as the Analog input channel.

Math channels are virtual channels. They contain measured values based on equations. These values can be recorded similar to physically connected Analog inputs and display digital values, trends, bar graphs etc.

### 4.1.3.3 Counter

Path:  (Menu)-More-Config/Math

Select **Type = Counter**



Press directional keys  $\langle \rangle$  at the bottom to select one of the Math channel for the Counter operation.

**Name:** Defines the name of counter, max. 18 characters allowed

**Desc:** Defines the description for a specific counter on the display

**Type:** Select **Counter**

#### Counter

**Unit:** Defines the unit of counter

**Preset:** Defines the preset value for the counter.

**Event:** Defines the type, Set point, Log, Job1 or Job2 & Hysteresis

**Type:** Select one of the options: H, L, HH, LL, Dev+, Dev-, Error

**Set point:** Defines the set point trigger of Counter value to initiate Jobs and/or Log alarms

**Log:** Select Log Alarm, Log Alarm (Auto Ack.), or Log Event

**Job1, Job2:** various jobs can be assigned, 2 jobs for each counter

**Hysteresis:** To avoid jobs have been activated too often, it can set for no reaction.

Hysteresis value can be defined for the event trigger set point

#### 4.1.3.4 Counter Example-1

The operator wishes to know the number of occurrences of an event in a day. Let's say the pressure switch in DI1 goes logic high

Digital input1 is used for a Pressure switch. High signal indicates High pressure, Low signal indicates normal pressure

The screenshot displays two configuration panels. The top panel, titled 'DI', shows a table with two columns labeled '1' and '2'. Below the table, the configuration for 'DI1' is shown, including a description 'Pressure Switch', an 'Events' section with 'Add' and 'Remove' options, and a list of jobs: 'Job1: Inc Counter\_Counter1' and 'Job2: No Action'. The bottom panel, titled 'Timer', shows a table with seven columns labeled '1' through '7'. Below the table, the configuration for a timer is shown, including 'Type: Daily', 'Action: Enable', 'Time' settings (Hour: 23, Min: 59, Sec: 1), and jobs: 'Job1: Log Report\_Counter1' and 'Job2: Reset Counter\_Counter1'.

(Reset Counter1 historical data in order to log new data for the next day)

Archive historical data by pressing the following.

 (Menu)-Event-Report, Select Daily in the Mode

If values meet the following conditions, recorder will change notation from traditional to scientific

- a. the value is more than  $10^5$  or less than  $1/(10^5)$
- b. the value digit-length in display exceeds the allowed range


Ex: Up to 5 digits, counter displays value directly, let's say 0-99999.  
100000 will be shown as 1E5, which means 5 zero's after 1  
4294967295 will be shown as 4.29497E9 etc.

#### 4.1.3.5 Totalizer

In our new generation Recorder, the Totalizer is a part of Math channels.

Configuration Path:  (Menu)-More-Config-Math

Select **Type = Totalizer**



Press directional keys < > at the bottom to select from available Totalizers

**Name:** Defines the name of the Totalizer, Maximum 18 characters allowed

**Desc:** Defines the description for a specific Totalizer on the display

**Type:** Select "Totalizer"


**Log:** Same as Analog input configuration

**Totalizer:**

**Input:** Analog Input (AI) or Pulse Counter (DI)

**Source:** Select the source for the Totalizer from Analog input/Math/Counter/Totalizer

**Action:** Disables or enables the Totalizer



**Decimal:** Defines the decimal point for the Totalizer

**Period:** Selects if seconds, minutes or hours are used for the Totalizer

**Unit:** Defines the unit of totalizing

**Preset:** Defines the preset value for the Totalizer.

**Low Cut:** Defines the Low Cut for the Totalizer.

For ex: If 0.0 is set as Low cut, then, if source channel AI1 is less than 0.0, the Totalizer value will not go to negative.

**Event:** Total 5 events are supported for each Math channel. Defines the type, Set point, Log, Job1 or Job2 & Hysteresis

**Type:** Select one of options, H, L, HH, LL, Dev+, Dev-, Error

**Set point:** Defines the set point trigger of Totalizer value to initiate Jobs and/or Log alarms

**Log:** User can select one of Log Alarm, Log Alarm (Auto Ack.), or Log Event

**Job1, Job2:** various jobs can be configured, 2 jobs for each Totalizer

**Hysteresis:** To avoid jobs from being activated too often, the hysteresis can set to avoid nuisance tripping. Hysteresis values can be defined for the event trigger set point

#### 4.1.3.6 Totalizer Example-1

Water flow rate is in M<sup>3</sup>/Sec. The operator wants to know about total water discharged and wants this information in daily, weekly and monthly reports

```
Name: Totalizer1
Desc:
Type: Totalizer
Log
  DataType: 4 Byte
  Value Range: -3.4E+38 ~ 3.4E+38
  Method: Instant
  Speed: 1 Sec/Dot
```

Timer						
1	2	3	4	5	6	7
Type: Daily						
Action: Enable						
Time						
Hour: 23						
Min: 59						
Sec: 1						
Job1: Log Report_Totalizer1						
Job2: Reset Totalizer_Totalizer1						

Reset Totalizer1 historical data in order to log new data for the next day


Archive historical data by pressing the following.

Path:  (Menu)-Event-Report

Select **Daily** in the **Mode** to see reports on daily basis. To navigate to another day, press on Left and right arrows below the **Mode** button. Select **Weekly** in the **Mode** to see weekly reports, or select **Monthly** on the **Mode** to see Monthly reports.

#### 4.1.4 Analog Output

After entering the Configuration screen, in the Channel section, select AO, then Press the “Enter” soft button to get into Analog Output Channel configuration page.




**Desc:** Define detail description for the channel name

**Type:** Current, Voltage

**Output:** Select either disable, 0 to 20mA , 4-20mA, 0-5V, 1-5V, 0-10VDC

**Expression:** This is similar to Math channel.

## 4.1.5 Digital Output



**Desc:** Define detail description for the channel name

**Reverse:** Enable this if Reverse operation is required for the Digital Output.

For ex: If reverse is disabled, the relay output is Normally Open (NO). In case if you need to have a Normally Closed (NC) relay at Recorder Power ON, then enable “Reverse” for the selected Digital Output. The Relay output shall be normally closed.

## 4.1.6 External


This is to access data from the external devices.

Maximum no. of external channels in various PR series Recorders are as follows

PR Recorder	PR-10	PR-20	PR-30
Maximum External Channels	24	48	96

All the properties are similar to Analog Input channel.

More details about external channels are available at section “Communication”



Please refer section “Communication” for examples of external channels

#### 4.1.7 Jobs

Various types of jobs can be selected as follows.

**No Action:** Do nothing

**Send Email:** Send Email directly from Recorder

**Pause:** Stop logging data.

**Start:** Start logging data.

**Sound Buzzer:** Sound the buzzer. It stops once any key is pressed.

**Dump Data:** To dump data from internal memory to external memory.

**DO Latch On:** Set digital output / relay on, and then select Target, let’s say from one of DO 1 to DO 6. The relay is latched when it is activated.

**DO Latch Off:** Set digital output / relay off, and then select Target, let’s say from one of DO 1 to DO 6. The relay is un-latched when it is activated.

**DO Process:** Set digital output / relay on for process high or low, and then select the target, let's say from 1 of DO 1 to DO 6. The relay is not going to be latched when it is activated.

**Enable Timer:** Start the timer, and then select Target timers

**Disable Timer:** Stop the timer, and then select Target from Timers

**Preset Totalizer:** set a preset value to the target Totalizer.

**Reset Totalizer:** Reset Totalizer to zero. Select a single Target Totalizer or All totalizers

**Enable Totalizer:** Starts the Totalizer. Select a single Target Totalizer or All totalizers

**Disable Totalizer:** Stops the Totalizer. Select a single Target Totalizer or All totalizers

**Preset Counter:** set a preset value to the target counter.

**Reset Counter:** Resets the counter to zero. Select a single Target counter or all counters

**Inc Counter:** Increases the counter by 1. Select a Target counter or all counters

**Dec Counter:** Decrease the counter by 1. Select a Target counter or all counters

**Log Report:** Make a report for Counter, Totalizer, Analog inputs (Min/Max/Avg), Math (Min/Max/Avg), All Counters, All Totalizers, and All Channels (Min/Max/Avg). Choose this column, and the report will be presented as described in section "**Reports**".



**Reset MinMaxAve:** In the Report function, after logging the Min/Max/Avg data of AI and Math channels for one day for example, this will reset historical data in order to log new data for the next day. It is also possible to reset the Min/Max/Avg for "All Channels" at one step.

**Print:** If a printer is connected to the Paperless Recorder via the USB port or Ethernet, the following print jobs can be triggered from "events"

- Print Historical data
- Print Event List
- Print Report List
- Print Snapshot

The time period of Print depends on the configuration available at

 (Menu)-More-Config-Auto-Output



Note: Please refer section “Auto Output” for more details about options available

**Note:**

- ◆ In any mode , the sampling rate of the recorder is fixed at 100 milli seconds, i.e. 10 samples are collected per second. If the logging speed is set at 1 second in Instant mode, the recorder logs the last of ten measured data values. For the same speed in Average mode, the recorder logs using the average of the Ten measured data values. For the same speed in the Maximum or Minimum mode, then the recorder logs using the maximum or minimum of the Ten measured data values.

<b>Sampling</b>		<b>Logging (historical trend)</b>	<b>Display (real time)</b>
Instant	100mS	the last of 10 points of data	last of 10 points of data
Averaged	100mS	the average of 10 points of data	last of 10 points of data
Maximum	100mS	the maximum of 10 points of data	last of 10 points of data
Minimum	100mS	the minimum of 10 measured data	last of 10 points of data

Press “**Home**” key to return to real-time display, all configurations will be memorized


- ◆ The Digital output DO card with relays can be set in Job1 and/or Job2. It can be viewed in “System Info” mode after it is installed into a Slot.

## 4.2 Display

Path:  (Menu)-More-Config-Display

Select “**Display**”, then press the “**Enter**” Soft button to get into the Display mode configuration page (shown on the following page).

	PR10	PR20	PR30
Display pages	8	20	21
Pens/Page	6	6	10



**Name:** Defines the name of the display page

**Mode:** Defines the default method of displaying data for the page.  
Options are: Trend, Bar, Digital, Mix, Circular (only for PR30) and Disable modes.

\* Circular Trends are only available in the PR30 model.

For Circular Trends

**Speed:** This is the display speed. Available options are 100 msec/dot, 1 Sec/dot, 2 Sec/dot, 5 Sec/dot, 10 Sec/dot, 20 Sec/dot, 30 Sec/dot, 1 min/dot, 5 min/dot, 10 min/Page, 30 min/Page, 1 hour/Page, 2 hour/Page, 4 hour/Page, 8 hour/Page, 12 hour/Page and 1 Day/Page.

**Direction:** Sets the trend direction to be horizontal or vertical.

**Background:** Sets the background color of Trend mode to black or white

**Pen:** For a specific channel, this defines the drawing pen, its color, width, Range Low and Range High for the display.

**Channel:** Selects a specific analog input, Math, Counter, Totalizer, External channels. Select Disable if a specific channel is not required to be displayed.

**Color:** Selects the color for each pen.

**Width:** Selects the width of trend, 1-thin, 2-medium, 3-wide.

**Low:** Defines the low scale for a pen on the display.

**High:** Defines the high scale for a pen on the display.

**Note:**

- ◆ To illustrate the difference between Display Hi, Display Lo, Scale Hi, and Scale Low, here is a typical example, with input 0-10V, Scale Low=0.00, Scale Hi=100.00, to have better resolution and vision on Bar, set the Display Lo=0.00 and Display Hi=50.00 so that the Bar displays from value 0.00 to 50.00.
- ◆ The decimal point is defined by Scale Hi and Scale Low, and not by Display Hi, or Display Lo.

#### 4.2.1 Status Bar

**Status Bar:** To make it convenient when viewing the status of Digital Input, Digital Output, Math channel, Totalizer, Counter and AO, the user may enable these items in the status bar. The Status bar is displayed at Lower part of the page. A maximum of 10 tags can be displayed in each Status bar. One status bar can be configured for each page.

**Note:** Status bar configuration is not shared in all the pages. You may define a different setup for status bars in each page per your requirements.





Fig: Status bar display in Real time

### 4.3 Timer

Path:  (Menu)-More-Config-Timer



Press directional keys  $\langle \rangle$  at the bottom to select from one of 20 available timers.

**Type:** Countdown, Repeat Countdown, Daily, Weekly or Monthly.

**Countdown:** Defines the interval of time, e.g. days, hours, minutes and seconds.  
(Not the Actual Time)

**Repeat Countdown:** Repeats the previous countdown (Not the Actual Time)

**Daily, Weekly or Monthly:** The timer works in selected interval of Real Time.

**Action:** Disables or enables the timer.

**Job1, Job2:** 2 jobs can be configured for each timer.

#### 4.3.1.1 Timer Example-1

Switch on water pump every day at 8.00am and switch off at 10.00am

This application requires a “Daily” timer which works with Real Time Clock.

Configuration settings are as follows.

##### Timer1

Type: Daily      Action: Enable  
Time – Hour: 8    Min: 0    Sec: 0  
Job1: DO Latch On, Target: DO1  
Job2: No Action

##### Timer2

Type: Daily      Action: Enable  
Time – Hour: 10   Min: 0    Sec: 0  
Job1: DO Latch Off, Target: DO1  
Job2: No Action

#### 4.3.1.2 Timer Example-2

Let’s say, when a digital input high event is triggered by high pressure, you would like to switch on a relay after a 10 seconds delay.

##### Digital Input1

Event1  
Type: H  
Job1: Enable Timer, Target: Timer1  
Job2: No Action

Event2  
Type: L  
Job1: DO Latch Off, Target: DO1  
Job2: No Action

##### Timer1

Type: Countdown, Action: Disable  
Time – Hour: 0    Min: 0    Sec: 10  
Job1: DO Latch On, Target: DO1  
Job2: No Action

### 4.3.1.3 Timer Example-3

Timer & Report:

A manager plans to get a **daily** report from the recorder about the **minimum, maximum and average** values of the process every day. After production has finished, he can press **Menu**, then **Event**, then he selects **Report** and presses the **Mode** key to select the **Daily** mode. He then is able to view the report like in the figure shown below

#### Timer1

Type: Daily                      Action: Enable  
 Time – Hour: 17                  Min: 01  
 Job1: Log Report                Target: ALL CH MinMaxAve  
 Job2: Reset Min/Max/AveTarget: ALL CH  
 (Reset historical data in order to logging new data for the next day.)

No	Type	Name	Value	Time
1	Channel	AI1	1000.0\120.0\441.9 °C	5:01:01 PM
2	Channel	AI2	1271.9\101.9\587.4 °C	5:01:01 PM
3	Channel	AI3	318.8\168.8\75.8 °C	5:01:01 PM
4	Channel	AI4	712.5\87.5\401.1 °C	5:01:01 PM
5	Channel	AI5	1365.0\455.0\911.6 °C	5:01:01 PM
6	Channel	AI6	1215.4\552.4\885.0 °C	5:01:01 PM
7	Channel	AI7	1104.9\662.9\884.7 °C	5:01:01 PM
8	Channel	AI8	621.9\428.1\525.3 °C	5:01:01 PM
9	Channel	AI9	1832.0\184.0\855.6 °F	5:01:01 PM
10	Channel	AI10	2321.4\151.4\1123.8 °F	5:01:01 PM
11	Channel	AI11	605.8\271.8\180.8 °F	5:01:01 PM
12	Channel	AI12	1314.5\189.5\769.7 °F	5:01:01 PM
13	Channel	AI13	2489.0\851.0\1695.7 °F	5:01:01 PM
14	Channel	AI14	2219.6\1026.4\1641.7 °F	5:01:01 PM
15	Channel	AI15	2020.8\1225.3\1635.5 °F	5:01:01 PM
16	Channel	AI16	1353.9\960.1\1163.2 °F	5:01:01 PM

## 4.4 Clock

Path:  (Menu)-More-Config-Clock





Fig: Clock configuration page in Paperless Recorder

**Date Style:** Selects either month/date/year or date/month/year

**Date/Time:** Set up the local time. Use directional keys Up/Down to select the column, press “Enter” soft button to change the clock data. Then press the “Apply Time” Soft button to apply it to the recorder.

**Summer time:** In some countries of North America and Europe, clocks are adjusted forward one hour near the start of spring and are adjusted backward in autumn. This is commonly referred to as Daylight Savings Time. We refer to this as “Summer Time”. A Summer time set provision is available in the paperless recorder. In **Summer time**, Select **Type:** Enable and then set Start (Month, Day, Hour, Min) and End (Month, Day, Hour, Min) details.

## 4.5 Communication



### Ethernet

#### IP: DHCP/STATIC

Select **DHCP** if the server on the network automatically allocates the IP address for the recorder.

Select **STATIC** to manually set a fixed address for the recorder.

**IP Address:** Defines the current address of the recorder on the network

**Subnet Mask:** Defines the current **Subnet Mask** address on the network

**Default Gateway:** Defines the current Gateway address.

**DNS Server:** This is required if the recorder is to be connected to Internet

**Modbus Server:** When configured as Slave Recorder is act as Server in Modbus Connectivity

**Modbus TCP Port:** Default: 502 for Modbus TCP

## Serial:

**Protocol:** Modbus RTU Master/ Modbus RTU Slave

**Address:** Address of Master/Slave in the network

**Baud rate:** 9600/14400/19200/38400/57600/115200

**Data format:** None, 8, 1 or Odd, 8, 1 or Even, 8, 1

## Modbus Client/Master:

### Sample Rate:

Ethernet: 100 msec/dot, 1 sec/dot, 2 sec/Dot, 5 sec/dot, 10 sec/dot


Timeout : The default timeout is 100ms

Serial: 100 msec/dot, 1 sec/dot, 2 sec/Dot, 5 sec/dot, 10 sec/dot

Timeout : The default timeout is 100ms


Interval between 2 commands : The default timeout is 10ms

**Email:** Enable/Disable



Press' "Email Test" and check mail function


If any problems with Email delivery, it will show error as shown attached



#### 4.5.1 Connections

There are a total of 16 connections available


Each connection can be configured as either Serial or Ethernet



**Name:** Connection name

**Type:** Serial/Ethernet


**Slave ID:** If Recorder is Modbus RTU Master, then, all the Slaves need to be configured in the connections.



**IP:** This is enabled only if Type = Ethernet selected at any connection

## 4.5.2 Commands

A total of 16 commands are available



**Action:** Enable/Disable

### To Channel:

**First:** Enter first external channel details, Ex : Ext1

**Last:** Enter last external channel details, Ex: Ext24

### From Device

#### Register:

**Start: Address:** Enter Start register address


**Data Type:** Int16/UInt16/Int32\_B/Int32\_L, UInt32\_B, UInt32\_L, Float\_B, Float\_L

**Connection:** Select the required connection

### 4.5.3 Modbus RTU Master, Example1

Master: Paperless Recorder

Slaves: External IO modules, 2 nos. each with 8 channel Analog inputs



Modbus Address	Register Name	Low Limit	High Limit	Access
30002	Analog Input 1	0	4095	R
30003	Analog Input 2	0	4095	R
30004	Analog Input 3	0	4095	R
30005	Analog Input 4	0	4095	R
30006	Analog Input 5	0	4095	R
30007	Analog Input 6	0	4095	R
30008	Analog Input 7	0	4095	R
30009	Analog Input 8	0	4095	R

Fig: External IO modules Register table

## Master Configuration

### Serial

- RS232/485
  - Protocol: Modbus Master
  - Address: 1
  - Baud Rate: 38400
  - Data Format: No,8,1

## Slave Configuration

Connections					
1	2	3	4	5	6
Name: Connect1					
Type: Serial					
Slave ID: 2					

Connections					
1	2	3	4	5	6
Name: Connect2					
Type: Serial					
Slave ID: 3					


Commands					
1	2	3	4	5	6
Action: Enable					
To Channel					
First: Ext1					
Last: Ext8					
From Device					
Register					
Type: Input					
Start Address: 2					
Data Type: Int16					
Connection: Connect1					

Commands					
1	2	3	4	5	6
Action: Enable					
To Channel					
First: Ext9					
Last: Ext16					
From Device					
Register					
Type: Input					
Start Address: 2					
Data Type: Int16					
Connection: Connect2					

#### 4.5.4 Modbus RTU Master, Example2

Master: Paperless Recorder

Slave: PID Controller



Register Address	Parameter Notation	Parameter Description	Range	Default Value	Data type
128	PV	Process value	Low: -32768 High: 32767	—	R
129	SV	Set point value for control	Low: SPLO High: SPHI	—	R

Fig: External PID Controller Register table

## Master Configuration

- Serial
  - RS232/485
    - Protocol: Modbus Master
    - Address: 1
    - Baud Rate: 9600
    - Data Format: No,8,1

## Slave Configuration

Connections					
1	2	3	4	5	6
Name: Connect1					
Type: Serial					
Slave ID: 2					


Commands						
1	2	3	4	5	6	7
Action: Enable						
To Channel						
First: Ext1						
Last: Ext2						
From Device						
Register						
Type: Input						
Start Address: 129						
Data Type: Int16						
Connection: Connect1						

External							
1	2	3	4	5	6	7	8
Name: Ext1							
Desc:							
Log							
DataType: 2 Byte							
Value Range: -32768 ~ 32767							
Trigger: by Time							
Method: Instant							
Speed: 1 Sec/Dot							
Range							
Low: -3276.8							
High: 3276.7							
Scale							
Unit:							
Low: -32768							
High: 32767							

#### 4.5.5 Modbus RTU Slave, Example

Master: PC, Modbus RTU OPC Server

Slaves: Paperless Recorders, 2 nos. each with 6 channel Analog inputs



## 1. Input Register Parameter Table

Address	Notation	Parameter	Scale Low	Scale High	Notes
0	AI1PV	AI1 process value	*1	*1	R
1	AI2PV	AI2 process value	*1	*1	R
2	AI3PV	AI3 process value	*1	*1	R
3	AI4PV	AI4 process value	*1	*1	R
4	AI5PV	AI5 process value	*1	*1	R
5	AI6PV	AI6 process value	*1	*1	R
6	AI7PV	AI7 process value	*1	*1	R

\*1: The scale high/low value are define in the following table for

Conditions	DP=0	DP=1	DP=2	DP=3	DP=4	DP=5
Scale low	-19999	-1999.9	-199.99	-19.999	-1.9999	-0.19999
Scale high	45536	4553.6	455.36	45.536	4.5536	0.45536

Fig: Paperless Recorder (Slave) Register table and scaling information

### Serial

RS232/485


**Protocol: Modbus Slave**

Address: 2

Baud Rate: 38400

Data Format: No,8,1

## 4.6 Instrument



**Language:** A total of 19 languages are supported. They include English, Simplified Chinese, Traditional Chinese, Japanese, Korean, French, German, Italian, Polish, Spanish, Portuguese, Brazil Portuguese, Russian, Thai, Czech, Danish, Dutch, Swedish & Turkish

**Security:** Select Normal or CFR-21 security. More details available at section "Security"

**Batch Control:** Disable and Enable options available for the selection. Refer section "Batch Control" for more details.

**Volume:** When the screen is touched, you can hear a "beep" sound. Select Disable to switch off the beeper. Select value 1 to 10 for volume control. 1 is minimum sound and 10 for maximum sound

**Tool bar:** On left side of the display page, the tool bar appears for configuration.  
Auto Hide: Select 10 Sec or 20 Sec or 30 Sec or 60 Sec to hide the tool bar if the user does not operate recorder via touch screen for the set time interval. Select "disable" if auto-hide is not required on specific set time

**Scan Page:** The User can set Automatic scanning of display pages for fixed time when enabled . The Fixed times are 1minute to 10 minutes.

**Idle time:** If touch screen is not used for the set idle time, then the display pages will start scrolling as per defined scan rate. Select 1 to 10 Min. for the idle time if display scroll feature is required, otherwise select "disable".

**Scan Rate:** This is the scroll time for the display pages. Select a time interval between 5 sec to 30 sec. This time interval is effective only if the “idle time” is enabled and the selected time is between 1 to 10 min

#### **LCD:**

**Brightness:** Select level between 0 and 6. 0 is the lowest brightness and 6 is for the highest possible brightness

**Screensaver:** To prolong the life of the LCD display, it is suggested to set the display turn-off time to 1, 10, 20, 30, 40, 50 or 60 minutes after the last time the user operates the recorder. ***Screensaver default time is set to 10minutes from the factory.*** The recorder continues to record data while it is in screen saving mode. The display turns on again by touching the LCD screen

**Storage:** Select internal flash memory or SD card

**Custom page:** User can use this setting to enable or disable custom pages downloaded via Ethernet.

**Allow download via Ethernet:** Enable/disable

## **4.7 Security**

### **4.7.1 Normal**

Path:  (Menu)-More-Config-select Instrument, then press “Enter”

Select “Security” = Normal

If normal security is selected, users will need to key in a common password with a maximum of 18 characters. Once the password has been entered, the user needs to key in the password whenever **Config, Dump, Clear** or **Operate** soft keys are required. These keys enable the user to do configuration, dump data, clear data or manually operate the job. For easy access **Config, Dump, Clear** or **Operate** soft keys, the user may ignore the password by leaving the password field blank. If a password is not entered initially, there is no password required.

How to enter simple password

 (Menu)-More-Config, select Password, press “Enter”, then key-in the passwor

## 4.7.2 CFR-21

If the higher security CFR-21 is selected, it requires the recorder to operate with more restricted rules which comply with **FDA 21 CFR Part 11**

It has time limit during operation. If the user does not press any keys in a predefined period of time (which can be selected between 1 to 20 minutes using LogOut function), the user needs to key in the password again. It also offers an audit trail function to record the user, the timing, and what type of work the user was doing on the recorder. Incorrect password and unauthorized operation will be recorded into the event list as well. The maximum number of users available in FDA 21 CFR Part 11 Security Mode is 30.

In  (Menu)-More-Config-Select **Instrument**, press “Enter” soft button.

Select Security = CFR-21.

### Security Mode: CFR-21

```
Logout: Disable
Password validity: Unlimited
Security Level of Functions
  Login From PC: 9
  Dump: 9
  Clear: 9
  Operate: 9
  Config: 9
  Pause: 9
  ShutDown: 9
```

**LogOut:** Time selection available from 1 min. to 20 min. This selection is visible only if CFR-21 is selected

If no user operates the Paperless Recorder for the above set duration, the current user will be logged out automatically

### **Password validity:**

Password validity can be set for 30, 60 or 90 days. After the preset amount of days, it will require the user to key in a new password, or keep the old one for an additional 30, 60 or 90 days.

### **Security levels:**

0 to 9 levels are supported


9 is the highest authority level, 0 is the lowest

## 4.8 Demo

The Demo mode is a simulation mode used as a sales tool for demonstration purposes. It is set to simulate AI analog inputs and Math functions.


*To start the automatic demonstration, first enable **Demo mode**, then turn the power OFF and Power ON to make it effective. To stop the automatic demonstration and return to real mode with real inputs, first disable Demo mode, then turn the power off and Power ON.*

## 4.9 Auto-Output



**Setup Printer:** It is to configure printer

Select **Setup Printer** and then press the “Enter” soft button



Two kinds of printers are supported. One is USB printer for page printing and another is Serial printer for Line printing

Applications: Print Historical data, events, & Reports and snapshot directly from Paperless Recorder.

## 4.9.1 USB Printer


Generally, USB printer support PCL protocol. It means, it will support Page Print, but not line print. We support PCL language 4, 5 & 6

If USB printer supports ESCP protocol similar to EPSON LQ300+, then, it is possible to take line print.

Please refer Printer user manual for exact protocol details



Do not use USB printer supporting only PCL to print single line alarms, otherwise, pages will be wasted




### Procedure



Connect Recorder to Printer via USB cable

Power ON Printer

Path:  (Menu)-More-Config-Auto-Print, Enter

Select "Setup Printer", press "Enter" soft button





**Printer:** PCL Laser, ESCP printer, PCL Inkjet available by default. Select one from the list as per printer model connected to the Paperless Recorder

**Port:** It shows “Network” by default. Once a printer is connected to the USB port, it will show “LPT1” for the USB printer. Select “LPT1”

**Net Path:** It is required to enter the correct network path here only if both Printer and Paperless Recorder are connected to a LAN network

**Paper Size:** A4, B5, Legal and Letter are supported

**Draft mode:** By default, it is selected. If more quality print is required, deselect Draft Mode

**Color:** Enabled for Inkjet printer


**Orientation:** Select Portrait/Landscape as per requirements

Note: Margins & Print Range are not working at this time.

Now, setup is ready at Paperless Recorder

## 4.9.2 Network Printer (LPT1)

Serial printer will print minimum one line and is generally used for printing Real time alarms. Also, it can be used for printing historical data and alarms from the Paperless Recorder. ESCP language is supported, so any printer supporting ESCP like LQ300+ can be used. The LPT1 port of a PC can be connected to a Serial printer directly. However, it needs to have a Printer driver installed in PC first, and share it for network use via Ethernet.



### Procedure

Connect Paperless Recorder to PC via Ethernet


Install Printer driver in PC. Share Printer for network use



Connect Printer to PC via LPT1

Power ON Printer

In Paperless Recorder, at Path, select  (Menu)-More-Config-Auto-Print, Enter

Select "Setup Printer", press "Enter" soft button





Select ESCP printer.

Then, enter the proper Net Path. Ex: \\PC1\LQ300


PC1 is computer name and LQ300 is shared printer driver for network use

Now, the setup is ready at the Paperless Recorder

### 4.9.3 Print Historical data

Configure USB Printer or Network printer as explained in earlier section

In Paperless Recorder, at Path, select  (Menu) -More-Config-Auto-Output, Enter




**Period:** Select Last hours or Last days


**Hours/Days:** Select no. of hours or no. of days as per above selection

**Interval:** Select intervals of 100 msec/1 sec/2 sec/ 5sec/ 10 sec/ 20 sec/ 30 sec/ 1 min/ 5 min/ 10 min.

The Print function is available in the Job list and can be initiated in various ways.


Ex: Print historical data of last 1 hr. and do this every day at 8.00 hrs





#### 4.9.4 Print Reports

In Paperless Recorder, at Path, select  (Menu)-More-Config-Auto-Output, Enter



In the **Mode**, select which kind of Reports are required. Available options include Daily Reports, Weekly Reports and Monthly Reports

Timer					
1	2	3	4	5	6
Type: Daily					
Action: Enable					
Time					
Hour: 8					
Min: 0					
Sec: 1					
Job1: Print Report List					
Job2: No Action					

### 4.9.5 Print Snapshot

 (Menu)-More-Operate-Print Snapshot

Menu	
Realtime	
Mode	Dump
Alarm	Clear
Status	Operate
History	Config
Event	Stop
More	ShutDown

x
Operate

Print Snapshot

Job Items:

- Enable Totalizer
- Disable Totalizer
- Preset Counter
- Reset Counter
- Inc Counter
- Dec Counter
- Log Report
- Reset MinMaxAve
- Print Historical Data
- Print Event List
- Print Report List
- Print Snapshot
- Output Historical Data

Target

▲

▼

OK

Cancel

◀

▶

## 4.10 System Info



Path:  (Menu)-More-Config-System Information

The system information includes System version, Internal and External memory, Ethernet IP address and Slots status

**Version:** The firmware version of the recorder.

### **Memory (Free / Total):**

**Internal:** Indicates the percentage of free memory compared to total memory available in internal flash card

**External:** Indicates the percentage of free memory compared to total memory available in external memory devices of SD and USB.

A small icon on the top right indicates the percentage of free memory e.g.: Mem 96 %

### **Address:**

**MAC:** Displays the MAC address of Paperless Recorder


**IP address:** Displays the IP address for the Paperless Recorder

**Slot 1..5:** Indicates the status of all Slots and the cards that have been inserted. The cards include Analog Input AI, Digital Input DI and Digital Output DO & AO.

#### 4.10.1.1 Upgrade Firmware

Path:  (Menu)-More-Config-System Information-Maintain

**Maintain:** The Maintain button is located at left lower side in System Info. page. It is the button to upgrade the firmware and calibrate the touch screen in the paperless recorder




#### Upgrade Core System:

This is to upgrade firmware in the paperless recorder. Contact factory/supplier for the latest firmware files. Please download firmware file to a USB stick or SD Card then, insert the USB stick into USB port or SD Card at SD card Slot in the Paperless Recorder. Select the External Storage to SD Card or USB flash on the External Storage Setting depends on the storage inserted. Select “Update Core System”, then click the “OK” button. It may take a few seconds to finish the process. Please note that the power to the recorder should be not switched off during this upgrade process


#### 4.10.1.2 Calibrate Touch Screen

Path:  (Menu)-More-Config-System Information-Maintain

**Maintain:** The Maintain button is located at left lower side in System Info. page. It is the button to upgrade the firmware and Calibrate touch screen in paperless recorder



This is used to calibrate the touch screen. A "+" symbol appears in the center of the LCD screen. Carefully press and briefly hold a stylus or finger on the center of the target. Repeat this procedure as the target moves around the screen. Just touch the screen to complete the screen calibration. This procedure helps to locate pointer via touch screen and properly select the objects during operation of the recorder




## 4.11 Batch Control


This feature is to store data in a different folder for every batch and archive data later with reference to a batch.

Path:  (Menu) - More-Config- Instrument

Select Batch Control and press “Enter” key. Select “Enable”. Press “Ok”




Press “Back”






Press "OK", then, press "Home" Soft key to save these settings

Power the recorder OFF then ON, then in the  (Menu), the Batch soft key will be shown as below



Note: "Batch" soft key will appear only after Batch Control enabled as explained above

Press on Batch and it shows the following screen



**Set Batch** [X]

Batch Name - No:  
 -

Comments:

1:


2:

3:


OK Cancel

Operator can enter a maximum of three comments for any batch.

In the  (Menu)-More-Config, select “Batch”, press “Enter” key



It will show the Batch control settings as shown below



**Name:** Enter Batch name. A maximum of 18 characters is allowed. By default, the name is Batch1.

**Lot Number:** Enter the Lot number. If Auto increment is enabled, then Lot numbers will be incremented automatically by the recorder, Batch1-1, Batch1-2, Batch1-3 etc. during every start of a new batch

**Jobs:** Two events, Start, Stop are available

**Start:** Start means Jobs that should be done during start of a new batch

**Stop:** Stop means Jobs that should be done during stop of a batch

**Note:** When batch control is enabled, the recorder will be in Pause mode by default initially and it requires Starting of the recorder from the Menu by pressing at  (Menu) - More than “Start”. When recorder is not logging any data, Pause status shall be shown in the Top right area of the recorder as shown below



### How to do the batch control

Press on  (“Menu”), “More”, then “Start”. Batch number will be shown in the recorder Top area.



To Stop this batch, press on “Menu”, “More”, then “Pause”. It gives a message “Saving data” and updates batch data in the internal memory of the paperless recorder.

#### 4.11.1.1 Batch Example-1

The operator wants to start a batch every day at 8.00am and stop the batch at 12.00am.

Configuration

##### Timer1

Type: Daily	Action: Enable
Time – Hour: 8	Min: 0    Sec: 1
Job1: Start	
Job2: No Action	

##### Timer2



Type: Daily	Action: Enable
Time – Hour: 12	Min: 0    Sec: 1
Job1: Pause	
Job2: No Action	


#### How to view batch data in Recorder

Press on  (Menu)-History-Page1

Press “Search”, select required Batch and press “Ok”


Batch details including lot number can be archived by pressing soft key “Batch”





### How to Dump Batch data to external USB memory

Press on  (Menu)-More then press on Dump




Select "All" or required lots and press "OK"

For ex: Batch1-1, Batch 1-2, Batch1-3 are available  
Initial 1 Lot means, Batch1-1  
Initial 2 Lots means, Batch1-1 and Batch1-2  
Initial 3 Lots means, Batch1-1, Batch1-2 and Batch1-3

Note: Provision not available to dump only specific lot.

Please refer Instrument->Data Transfer-> Transfer and Remain



Press on "Yes" to dump data from internal memory to external SD Card or USB memory.


If you have 3 batches, let's say Batch1-1, Batch1-2 and Batch1-3, then you can see three different folders in the external USB memory card after completing of dump



Please note that the data available in USB memory is in a proprietary format to avoid any kind of tampering. You will need PC software to view this data.

## 4.12 Calibrate


This function is used for calibrating Individual Analog channel.




Example 1:

### Calibrate an AI with 0-5V


When you click Calibrate menu, the user can see the below screen. Please click calibrate as shown in the below screen




Please follow the next instruction, input 0V in to the input which can be seen in below screen




After you input 0V and select ok, the user can see the below screen. Now follow the next instruction.




Now input 5V and click ok



After you input 5V and select ok, the user can see the below screen  
Now follow the next instruction.




When the calibration is done successfully, the user can see below screen.




Example 2:

Calibrate an AI with K-Type Thermocouple


When you click Calibrate menu, the user can see the below screen. Please click calibrate as shown in the below screen




Please follow the next instruction, input 0 mV in to the input which can be seen in below screen




After you input 0V and select ok, the user can see the below screen.  
Now follow the next instruction.




Now input 60mV and click ok



After you input 60 mV and select ok, the user can see the below screen  
Now follow the next instruction.



When the calibration is done successfully, the user can see below screen.




**Note:**

Channel #3 should be calibrated first in all types of Analog Input cards. An analog temperature sensor is installed in channel # 3. When channel # 3 is calibrating, the cold junction voltage measured by this temperature sensor will be loaded into a register.

If channel # 3 is not calibrated, the default value of cold junction voltage will be used for all channels. It does not matter what order you perform calibration after calibrating input 3, there is no need to follow a sequence, and any one of T/C, RTD, mA or VDC can be done independently.

## 4.13 Procedure To Reset and Restore Factory Default Settings

Power ON the Recorder while Pressing the Reset Button



Now the Screen will appear like below



#### Format:

Press the Format Button for at least 3 Seconds to return the Recorder to factory Settings.

After the Recorder is done formatting, it will ask for Screen Calibration.

Do the Screen Calibration.

The recorder has now been returned to factory default settings.

#### Upgrade:

Download the Firmware from the FTP Link Given

Copy the File to the SD Card. Be sure the SD card is formatted to FAT32.

Insert the SD Card to the SD Card Slot on the Recorder.

Press Upgrade Button for at least 3 Seconds to upgrade the image from SD Card.

Follow the on-Screen instructions.

## 5. PC BASED SOFTWARE

By using this software you can configure the settings of the Recorder offline and online. Trends of configured channels can be viewed in PC by using this.

This has got 4 Options:

### 5.1 Free Basic Software

#### 5.1.1 Requirements

##### Hardware

Recommended hardware

PC with 2 GHz processor, 1GB RAM

50GB free space in the hard disk.

Ethernet port, RJ 45 female/ USB port

Minimum 20% free space in hard disk, Less than 10% space generates an error message

#### 5.1.2 Operating system

Windows based Operating systems, Windows XP, Windows 7, Windows 8 etc..

32 bit and 64 bit operating systems are supported

#### 5.1.3 Software

Software installation

1. Install latest dotNet software from Microsoft website
2. Install the software
3.  Historical viewer icon desktop shortcut will be created after installation of software
4. Historical viewer can be accessed from the following path as well  
Start-Programs-Historical viewer-Historical viewer.

The Software contains:



HIST\_VIEWER is for monitoring historical trends and also for configuration of recorder parameters via the PC.

### Uninstall the free Software

This is to remove previous versions of free software from PC.

### HIST\_VIEWER



### How to set configuration of the Recorder from PC.

Start-Programs-Historical Viewer


Tool bar




To open new project



To open existing project file




When the User clicks the icon new (shown in the above picture in the red square), they can view the below menu where they can select the Recorder (PR) and click ok.




After that, the user must give a name to the project and select the location of project (as shown in the below figure). If the user already has the configuration stored in a SD card or USB, they can select the path accordingly.

If the User wants to configure the Recorder for the first time via Ethernet, they must select Ethernet, and enter the correct IP address of the Recorder.



If the User wants to open file in the software, already configured in the PC, then they can select \*.prj file to open the project.



 To save the project file settings in PC

 Receive configuration (Storage Media/Ethernet)

 Send configuration (Storage Media/Ethernet)

If the software is already configured in the PC, then you can select \*.prj file to open the project.


### Bank

This is used to select the physical connection between the Recorder and PC.

Two options are available:

Storage Media

Ethernet



Standard Ethernet port (RJ 45 female) shall be available at the Recorder. RS 232/RS485 shall be supplied as additional options.

## 5.1.4 Ethernet Configuration

It is possible to use PC software for data logging of Recorders connected on standard Ethernet. A maximum of 1024 tags can be configured for data logging, archiving and analysis. The tags cover AI, Math, DI, DO, Counter & Totalizer.

1. Make sure that the network adapter in the PC is properly configured. IP address, Subnet mask and Gateway should be configured at the PC for using the Observer II program. Please contact your System administrator to set a Unique IP address for the PC.
2. Install the Observer II application software in your PC. The software may be installed from "setup" available in the CD supplied as per the order.
3. Ethernet configuration at the Recorder

Please refer to **4.5 Communication** for entering the IP address, subnet mask and gateway address manually at the Recorder.

Gateway refers to a device on a network that sends local area traffic to other networks.

Subnet mask numbers help to define the relationship between host and rest of the network.

For every LAN, the Network administrator shall define a Subnet mask and Gateway. Obtain the subnet mask and gateway address for the LAN at the place where the Recorder to be connected. Enter these details at the Recorder manually using front buttons.



By default, subnet mask address: 255.255.255.0

By default, Gate way: 0.0.0.0

Enter the Unique IP address to the Recorder and enter IP address at the Recorder manually. Contact your system administrator to obtain a free IP address available at user LAN. Naming duplicate IP addresses may disable the communication between the Recorder and PC/LAN HUB.

4. Local area network uses UTP cable for Ethernet connectivity. Maximum UTP cable distance between the Recorder and LAN/HUB/PC should be less than 100 Meters. If the distance is more than 100 Meters, additional LAN accessories/equipment may be required for increasing signal strength. Please contact your network administrator for more information on extending the LAN distance.

- Two different types of cables shall be used for connecting the Recorder on Ethernet as follows. For connecting the Recorder to LAN HUB, then standard straight-through Ethernet cable should be used. For connecting the Recorder to a PC/Laptop directly, a crossover Ethernet cable should be used.



- Connect a proper UTP Ethernet cable per the requirements and observe the communication status between the Recorder and PC/LAN HUB at the LED's located near the female RJ 45 connectors.

Recorder side

Link (Green LED)

Green lit: Cable connected between the Recorder and PC/LAN HUB


Green Off: No Link between the Recorder and PC/LAN HUB

Tx/Rx

Orange Lit continuous: No cable connection

Orange slow blink: Communication established between Recorder & PC/LAN HUB

If the download is successful, the User can see the below screen.



If Upload is unsuccessful, the recorder shows the message “No response from Recorder, connection fails”.



If this is the case, please check the Ethernet cable connections at both the Recorder and PC/LAN HUB side. Also make sure that green communication LED is lit which shows there is a proper firm connection at the RJ 45 connector.

If still communication is not established between the Recorder & PC, then once again check Subnet mask and gateway address at the Recorder & PC. Contact Network/ System administrator for proper Ethernet configuration of the Recorder & PC. Please note that Recorder should have a unique IP address in the network and PC that is using Observer II shall have a separate Unique IP address in the network.

## 5.2 Data Acquisition Studio Software

### 5.2.1 Requirements

#### Hardware

##### Recommended hardware

PC with 2 GHz processor, 1GB RAM

50GB free space in the hard disk.

Ethernet port, RJ 45 female/ USB port

Minimum 20% free space in hard disk, Less than 10% space generates error message

#### Operating system

Windows based Operating systems, Windows XP, Windows 7, Windows 8 etc..

32 bit and 64 bit operating systems are supported.

### 5.2.2 Software

#### Software installation

5. Install latest dotNet software from Microsoft website
6. Install Data Acquisition Studio software



Historical viewer icon and Real time viewer icon , desktop shortcut will be created after installation of software

Historical viewer can be accessed from the following path as well  
Start-Programs-Historical viewer-Historical viewer

Real time viewer can be accessed from the following path as well  
Start-Programs-Data Acquisition Studio Realtime viewer

### 5.2.3 How to configure Communication Bank

It is to set path for the data transfer. It's important to setup "Bank" properly at the to proceed further



1. Open existing Project or create a new project from RealTime viewer using one of the following options

Start-Programs-Data Acquisition Studio-Realtime Viewer




Click on the new Project as shown in the red square in the above figure

Then the User must give a name to the project as shown in the below figure



Click the bank icon  to open communication bank configuration, and select the bank accordingly.



Protocol: **Modbus\_RS232** ▼

Disable  
Modbus\_RS232  
**Modbus\_TCP**

RS232

Com Port : COM2 ▼

Baud Rate : 9600 ▼


Parity : No ▼

Data Bits : 8 ▼

Stop Bits : 1 ▼

Default

If the recorder is connected to Ethernet, then select Modbus\_TCP as shown below



Bank1

Protocol: **Modbus\_TCP** ▼

Ethernet

Port : 502

Format : Standard ▼

Default

If the recorder is connected via Serial RS-232 or RS-485, then select Modbus\_RS232 as shown below. Please select the same com port and baud rate that is in the instrument.

**Bank1**

Protocol: **Modbus\_RS232** ▼

RS232

Com Port : COM2 ▼

Baud Rate : 9600 ▼

Parity : No ▼

Data Bits : 8 ▼

Stop Bits : 1 ▼

Default

**Note :** For connecting PR with Realtime Viewer , we suggest to use Ethernet . as Ethernet has better speed compared to RS485/RS232. The Volume of Configuration data in PR is Large comparing to VR. So If you want to connect PR with DAQ using RS485 then you need to follow the below steps :

1. Dump the Configuration file to USB/SD Card from PR
2. Create a new project in Real time Viewer and select the bank with RS485
3. Select the Folder of SD Card/USB where the configuration file was dumped from PR
4. Now the Real time viewer read the configuration file from PR and start monitoring the real time value.

#### 5.2.4 How to configure Recorder


There are three ways to configure the recorder:

Touch screen, Software and Storage Media.

## 5.2.5 Touch Screen

It is possible to configure the recorder directly from the touch screen.

Press Menu-Config



Please refer chapter 4 for more details

## 5.2.6 Ethernet

The steps are given below

1. Connect Recorder to PC via cross over or straight Ethernet cable
2. Check IP address of your Computer. Make sure to set IP address of Recorder in the same domain as your PC  
For ex: IP address of your computer: 192.168.0.200  
You may set IP address of Recorder as 192.168.0.11
3. Procedure to set IP address manually at Recorder  
Menu-More-Config-Communication, press "Enter"  
IP = Select User Define  
Select, IP address: 192.168.0.11 (Default) and press "Enter" to change if required

Subnet mask: 255.255.255.0  
Default Gateway: 192.168.0.1

4. Use "Ping" from DOS prompt and check if communication is ok or not. If there is no response, check the cable or IP address at your computer or IP address at the recorder

```
C:\ Command Prompt
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

E:\Documents and Settings\Mahi>ping 192.168.0.11

Pinging 192.168.0.11 with 32 bytes of data:


Reply from 192.168.0.11: bytes=32 time<1ms TTL=128

Ping statistics for 192.168.0.11:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms


E:\Documents and Settings\Mahi>_
```

5. Double click the Realtime viewer icon  at desktop and follow on screen instructions to create a new project


Note: Create a new project only if it's first time. Next time, you can open  the saved project available in your computer



If the connection is working fine, the user can see the below figure. Upon clicking the icon shown in the red box, you are accepting the configuration




Click yes to apply the settings.



If you have set no password just click ok





And after that you will see the below figure



## 5.2.7 Removable Media

The steps are given below

1. In recorder, please insert an empty SD card or USB stick
2. In the recorder, press “Menu-More-Config”. Press “Save”



Press “Yes”. It will save Recorder configuration files into USB stick.

Check contents of removable media. It should have the following files




3. Remove the removable media from the recorder. Insert into PC

4. Double click the historical viewer icon  at desktop and follow on-screen instructions to create a new project




Select PR Recorder. Click “OK”


Note: Above screen appears right away if no project files available in Computer



Select “Storage Media”. Then enter the path to the Recorder files in USB stick or SD card. Click “OK”



Click “Yes”. It will open Recorder configuration screen





Note: The configuration screen is the same as the screen available directly in recorder. Please refer to Chapters 3 & 4 for more details about configuration

5. Do your required changes in the configuration. Click at Send configuration icon 




6. Now, remove your removable media from the PC. Insert it into the Recorder. In the recorder, press "Menu-More-Config".

Press "Load"



Press "OK"



Press "Yes"

## 5.2.8 Configuration

Please refer to Chapter 4 for full details related to configuration

### 5.2.8.1 Analog Input

The screenshot shows the configuration interface for channel AI1. On the left is a navigation tree with options: Channel, AI (selected), DI, Math, AO, DO, External, Display, Tools, Timer, Clock, Communication, Instrument, Password, Demo, Auto-Output, and System Info. The main area is titled "AI1" and contains the following settings:

- Name: AI1, Desc: (empty), Type: Enable
- Filter: Disable
- Log:
  - Data Type: 2 Byte, Value Range: -3276.8 ~ 3276.7
  - Trigger: Enable, Method: Instant
  - Speed: 100 ms/Dot
- Offset: 0.0, Gain: 1.0
- Sensor:
  - Type: Thermocouple J Type, Unit: °C
  - Range: -200.0 ~ 1100.0
- Events table:

No.	Type	Setpoint	Log	Message	Job1	Job2	Hysteresis
1	H	840.0	Log Alarm		No Action	No Action	0.0
2	L	60.0	Log Alarm		No Action	No Action	0.0
3	HH	937.5	Log Alarm		No Action	No Action	0.0
4	LL	-37.5	Log Alarm		No Action	No Action	0.0
5	Error	0.0	Log Alarm		No Action	No Action	0.0

### 5.2.8.2 Digital Input

Channel

- AI
- DI**
- Math
- AO
- External
- Display
- Tools
  - Timer
  - Clock
- Communicati
- Instrument
- Password
- Demo
- Auto-Output
- System Info

**DI1**

1 2 3 4

Name

Desc

Type

Events

No.	Type	Log	Message	Job1	Job2
1	Disab	No Action		No Action	No Action
2	Disab	No Action		No Action	No Action

### 5.2.8.3 Math channel

Channel

- AI
- DI
- Math**
- AO
- External
- Display
- Tools
  - Timer
  - Clock
- Communicati
- Instrument
- Password
- Demo
- Auto-Output
- System Info

**Math1**

1 2 3 4 5 6 7 8 9 10 11 12

Name

Desc

Type

Log

Data Type  Value Range: -3.4E+38 ~ 3.4E+38

Trigger  Method

Speed

Expression

Scale

Unit

Transformation


Decimal  Table

Range: 0 ~ 10


Events

No.	Type	Setpoint	Log	Message	Job1	Job2	Hysteresis
1	H	0	No Action		No Action	No Action	0
2	Disab	0	No Action		No Action	No Action	0
3	Disab	0	No Action		No Action	No Action	0
4	Disab	0	No Action		No Action	No Action	0
5	Disab	0	No Action		No Action	No Action	0

### 5.2.8.4 Analog Output



### 5.2.8.5 External Channel



### 5.2.8.6 Display

**Display1**

1 2 3 4 5 6 7 8 9 10 11 12

Name  Mode  Direction

Speed  Background

**Pen**

No.	Channel	Color	Width	Display Low	Display High
1	AI1	Blue	1	-120.0	1000.0
2	AI2	Lime	1	-200.0	1370.0
3	AI3	Cyan	1	-250.0	400.0
4	AI4	Red	1	-100.0	900.0
5	AI5	Magenta	1	0.0	1820.0
6	AI6	Yellow	1	0.0	1767.8
7	AI7	Gray	1	0.0	1767.8
8	AI8	Dark Blue	1	-250.0	1300.0

**Status Bar**

Type

1.  2.  3.  4.

5.  6.  7.  8.

### 5.2.8.7 Timer

**Timer 1**

1 2 3 4 5 6 7 8 9 10 11 12

Type  Action

**Time**


Day Hour Min Sec

**Events**


Job1



Job2


### 5.2.8.8 Clock




### 5.2.8.9 Communication












### 5.2.8.10 Instrument












#### 5.2.8.11 Password




### 5.2.8.12 Demo



### 5.2.8.13 Auto-Output



### 5.2.8.14 System Information



### 5.2.9 How to view Historical data

There are three ways to view Historical Data

1. Touch screen
2. Ethernet
3. USB stick

#### 5.2.9.1 Touch Screen

Please refer Chapter 3 for details how to view historical data in directly from the recorder using the touch screen

#### 5.2.9.2 Ethernet

Note: Please read the following sections first


1. How to configure Communication bank
2. How to configure Recorder - Ethernet

Make sure your Project has already been created and saved in your computer. Then set bank to Ethernet before proceeding with the following steps


Open Project from Historical viewer using one of the following options

Desktop: Historical viewer icon 


Start-Programs-Historical viewer-Historical viewer




Select Project and click “Open”



Click Import measured data icon 



Note: Time taken based on amount of data available in internal memory



Press anywhere on the trend area, then click at Zoom icon  and then see the historical trend clearly

Note: Please read "Historical viewer" help file from software itself for all the features available in Historical viewer software

### 5.2.9.3 Removable Media



Note: Please read the following sections first

1. How to configure Communication bank
2. How to configure Recorder via SD card or USB


Make sure that if a project has already been created, and the settings and data are stored on an SD card or USB, set the bank to "Storage media" before proceeding with the below steps:

Insert Empty - SD card or USB in Recorder


Press "Menu-More-Dump"



Select "All" or one of the other available options, then press "OK"




Press "Yes"



Now, remove USB stick from Recorder

Check contents in the USB stick




Open Project from Historical viewer using one of the following options

Desktop: Historical viewer icon 


Start-Programs-Historical viewer-Historical viewer





Select Project and click “Open”



Click Import measured data icon 




Note: Time taken is based on the amount of data available in internal memory



Select "Yes" if you wish to delete data from USB stick.

Select "No" only if you have plans to transfer data to another Computer or if you have plans to maintain data storage as back up in proprietary format in a Computer hard disk



Press on any area of the trend screen, then click at Zoom icon  and then see the historical trend clearly

Note: Please read "Historical viewer" help file from software itself for all the features available in Historical viewer software

## 5.2.10 How to view Real time data in PC

It is possible to monitor Real time data from paperless recorder on your PC

For this, the recorder should be connected to a PC via Ethernet or Serial network (RS232/422/485). Set bank appropriately to proceed with required option.

## 5.2.11 Bank configuration


How to open Real time viewer

There are two ways to open Realtime Viewer




Click the desktop icon


Start-Programs-Data Acquisition Studio Studio-Real time viewer



Click "No"



Click bank icon 




A total of 4 communication banks are available

Each bank can be configured as Either Modbus Serial (232/422/485) or Modbus\_TCP (Ethernet)

For example: If two Paperless Recorders are coming on two different RS485 networks, then each bank can be configured for each individual Recorder. This is provided that two COM ports are configured in PC to receive data from two different serial networks. You may use two USB to Serial converters for this application (See our UPort1150).

After completing the bank setup, click "Save" icon . To close, click the return to main program icon 



### 5.2.12 Ethernet

1. Install Data Acquisition Studio software
2. Set bank radial button to Ethernet
3. If the recorder is connected to the PC via Ethernet, make sure recorder is set with a User defined IP address and domain that is the same as the PC

Use Ping instruction from the Dos prompt, make sure the recorder is communicating with the PC via Ethernet

```
C:\> Command Prompt
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

E:\Documents and Settings\Mahi>ping 192.168.0.11

Pinging 192.168.0.11 with 32 bytes of data:

Reply from 192.168.0.11: bytes=32 time<1ms TTL=128

Ping statistics for 192.168.0.11:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms
```

4. Create a new project in Data Acquisition Studio software and monitor real time data from Recorder directly from PC


How to open Real Time Viewer

There are two ways to open Real Time Viewer

Click the desktop icon



Start-Programs-Data Acquisition Studio Studio-Real time viewer



Click "Yes"

**Auto-configuration**

Device Type: PR Recorder      Bank: 1

Protocol: Modbus\_TCP       Auto-update the Tag contents

LogSpeed: Auto      LogMethod: Auto

IP address

Input Format: IP address

Example: 192.168.0.25      192.168.0.11

IP List:

+  
-

Please key in IP here and then press '+' button to add it to the IP list.

Please select one IP form IP List and then press '-' button to remove it.

Use Converter

Use Converter:Device Node address      From: 1

Set node range:      To: 1

OK      Cancel

IP address

Input Format: IP address

Example: 192.168.0.25


IP List: 192.168.0.11

+  
-


Please key in IP here and then press '+' button to add it to the IP list.

Please select one IP form IP List and then press '-' button to remove it.

Click "OK"



Click “Save” icon . To close, click the return to main program icon .



Note: When real time viewer is running in PC, data will be stored on the computer hard drive. This data can be archived later from Real time viewer itself using the “Measured data” icon. This data is same as the recorder’s internal memory (Historical data).

In the case of a PC running round the clock (like a server), there may be no need to manually transfer historical data from Recorder to PC via Memory stick.

Note: Please read “Real time viewer” help file from software itself for all the features available in Real time viewer software

### 5.2.13 Serial (RS232/422/485)

The procedure is similar to Ethernet. But the bank must be set for Modbus Serial.

## 5.2.14 View Real time data from Multiple Recorders


Assume one Recorder database has already been added in Ethernet using IP address 192.168.0.11

Target: Connect a second Recorder, IP address 192.168.0.12 to the Real time viewer


Connect both the Recorders and PC to Ethernet switch

Use “Ping” instruction at DOS prompt and check communication between PC and two Recorders. If there is no response, then check IP address in all the devices. Also check Ethernet cables.

If there is good response from Recorders using the “Ping” instruction, Open Real time viewer



Click “Configuration data” icon 



Click “Add”



Select Device Type = PR Recorder

Deselect checkbox next to “Auto-update the Tag contents”


Enter IP address of second Recorder. (Make sure to select user define IP address in Recorder. Do not select “automation”)


Click “OK”

Now, second Recorder database will add to Real time viewer.

### 5.3 Panel Studio version

Using this software you can develop custom screens for your display same as SCADA. All the graphics developed on the screens can also be configured for animations.





Use this editing software to develop animation screens on the Recorder. It is mainly used for application development useful for operator interface in industrial applications. Using Screens, operators will be able to communicate with PLC's, inverters etc. via COM ports, the Ethernet port, on Modbus RTU or Modbus TCP/IP. Using this software, it is possible to develop operator interface applications like the following.

Sending start/stop command from Recorder to PLC to start motors, pumps etc.

Display running stats of motors, pumps etc.

Display Real time value of process parameters like temperature, flow, pressure etc

Visualize process data in meaningful ways such as bar graphs, dial, meter, level, digital LED etc.

Animation like visibility control, blinking, horizontal movement, vertical movement etc.

### 5.3.1 System Requirements

Recommended hardware:

PC with 2 GHz processor, 1GB RAM

50GB free space in the hard disk.

Ethernet port, RJ 45 female

Minimum 20% free space in hard disk, Less than 10% space generates error message

RS 232 serial port, RS485/RS232 converter to check online simulation if required

USB host to insert USB flash disk

Screen resolution better than 1024 X 768 (For Recorder 10" and 1550 projects)

Operating system: Windows XP, Windows Vista, Windows 7, Windows 2000 & Windows 2003 Server

### **5.3.2 Software Installation**

**Install Microsoft installer V3.1**

**Install Microsoft.Net frame work V3.5 SP1**

**Install Editing Software**

**Install OPC server**

**Install Demo projects**

**Install Historical viewer**


**Install Remote viewer**



If any folders or files are deleted manually from C:\Program Files\Panel Studio, then delete a file by name "BCFile" manually from C:\WINDOWS before attempting to start new installation process. Otherwise, you may get error message "Access Violation".

### 5.3.3 Project status

During design time, it is possible to check current status of resources being used



The screenshot shows the 'Project Status...' dialog box. It displays a table of resource counts and a section for project designed time.

	Total
Tag	40
Objects	450
Image	66
Connection	0
Alarm	5
Recipe	0
DataLog	4
Scheduler	2
UserScript	2
Security	1
Language	5

Project designed time  
0 Days 17 Hours 55 Minutes



“Image” means symbols used from graphics and symbol factory. These symbols are also considered objects, so, if you add symbols, it also updates quantity in objects.

For example: If you add 2 symbols and one rectangle object. Then, Images = 2, Objects = 3

### 5.3.4 Create new project

Open Recorder Editing Software from desktop icon or from Start-Programs-Recorder Editing Software

Click on “Create a new project”



**Project Name:** It is Name of the Project. For ex: Boiler

**Location:** It is path for project file storage.

**Default Language:** English

**Width:** It is pixels, resolution in dots available on X-axis



**Height:** It is pixels, resolution in dots available on Y-axis

**Author:** Write author name/system integrator name for future reference

**Version number:** It is for version management

**Comments:** It is for project management


After entering all the above details, click “OK”



### 5.3.5 Menu bar



### 5.3.6 File



**New:** To create a new project

**Open Project:** To open existing project

**Close Project:** To close present project

**Save Project:** To save Project in default path

**Save Project As:** Saves project in selected path other than default path specified while creating a new project settings.

**Upload:** To upload project from Recorder back to PC

**Recently:** It is to open recently opened projects

**Exit:** To exit from current project

**Language:** To update language files in Recorder. This is required only if a new language required at Control Center. Contact factory for further information

**Clock Synchronization:** To synchronize recorder clock with PC clock.

### 5.3.7 Environment



#### **General:**

**Language:** Select Language for project environment. 19 languages are supported from Recorder editing software V1.1 onwards including English, Simplified Chinese, Traditional Chinese, Japanese, French, German, Italian, Polish, Spanish, Portuguese, Brazil Portuguese, Russian, Thai, Czech, Danish, Dutch, Korean, Swedish and Turkish

**Environment font:** Select font required for design time environment.  
Example: Menu, Tool Box, Project explorer, function editor etc.

**Project Path:** Location to storage of project files  
Default project path: C:\Program Files\Recorder Editing Software\Recorder Editing Software\PanelProject

**Graphic Path:** Location of default basic Symbols  
Default graphic path: C:\Program Files\Recorder Editing Software\Recorder Editing Software\Basic Symbols

**Security:** This is to protect opening Recorder editing software in specific Personal computer (Not for project). Once password is entered, it is required to enter password correctly to open Recorder editing software for the current session. This is useful in factory environment to prevent un- authorized users to open Recorder editing software.


Note: If you need a password for a specific project, click “Settings” in the project explorer, select “General” tab, then enter the Password.



In general, it is preferred to back up project files regularly in other standard storage media like CD, DVD etc. It is recommended to store project files in separate folders on the D: drive instead of C: drive. Developers may make a hard disk partition and save all project files in drives other than location of operating system in the event that if there are problems with Operating system, it is still possible to retrieve project files.

**Download and Upload:** Please refer to section “Project tools” for more detailed information.


**Snap and Grid:** Used to define grid behavior in the design time environment.



**Grid:** Select this option and select “Show grid” if grids are to be appeared in screen at design time.

**Snap lines:** Select this option if grids are not required to appear in screen at design time.

**Snap:** Select this option if component coordinates should within grids all the time.



**Object:** Define default font size, Fill color, Back color and Fore color for the properties of most of the objects (label, Check box, Rectangle, Ellipse, Pie, Table, Dial, Level, Meter, Slider, Thermometer etc.).

### 5.3.8 Edit



### 5.3.9 Format




**Align:** Used to align selected components, objects etc. for adjusting their position precisely in the screen layout. Available options for selection are Center, Right, Left, Top, middle & Bottom.


Example: Align two Labels to the left in Recorder screen.

Assume both labels are created in Screen1. Select both labels first using your mouse. Alternatively, select first label by left clicking the mouse, then press "Ctrl" on the keyboard and select the second label by left clicking the mouse. Now, in Menu, click "**Format**", then select "**Align**", then select "**Left**".

**Before Align adjustment**



**After Left Align adjustment**



**Make Same Size:** To adjust different objects to the same Width, Height, Both width and height, Size to grid etc.

Example: Adjust five buttons to same size i.e., height and width.

Create five buttons first. Then, select all these buttons via Mouse, then click "**Format**", then select "**Make same size**", then select "**Both**".

**Before size adjustment**



### After Same Size adjustment



**Horizontal spacing:** It allows adjustment of horizontal spacing between any objects to make Equal/Increase/Decrease/Remove.

For example: There are 3 buttons located at bottom area of a page. Spaces between these buttons are not equal and screen does not look good. Select all the 3 buttons via Mouse or using “Ctrl” on the keyboard along with mouse. Then in Menu bar, click “Format”, then select “Horizontal spacing”, then select “Make equal”. Now, space between all these buttons will have an equal distance.

### Before Spacing adjustment




### After Horizontal spacing adjustment




**Vertical spacing:** It allows adjustment of vertical spacing between any objects to make Equal/Increase/Decrease/Remove

### Before Spacing adjustment





### After vertical spacing adjustment



**Center in Page:** It allows adjusting objects to the center of the page horizontally and vertically.

For ex: There are 3 buttons located at screen. You wish to locate them in the center of the page horizontally. Select these buttons and apply this feature to adjust buttons as per requirement.




**Order:**

**Bring to back:** Moves objects to the back


**Bring to Front:** Moves objects to the front

For example: There is Rectangle box and a label with different colors. If you wish to keep label text in front of the Rectangle, select the Rectangle, choose the option, “Bring to Back” and for the label, choose the option “Bring to Front”, such that both are visible at same time allowing overlapping of two objects for clear display.



**Lock Controls:** It is to lock control for further development. Apply this for a second time to unlock the control.


**5.3.10 View**



Select the required items to view in window layout.

### **Properties**

If “properties” is checked as shown above, in the right side bottom of screen layout, the properties box will appear showing all the properties for the component/object that is selected.



In above example, a rectangle is drawn, and once it is selected, the right side bottom corner will show all the properties for this specific rectangle if “properties” is checked in the View dropdown menu. It is possible to modify properties of the rectangle from property grid. Alternatively, if you double click on the rectangle, you will see a pop-up window where you can edit properties.

### **Output**

If output is selected in the view drop-down menu, this window appears just below the screen working area. This window will display any errors that appear during compilation of project.

In Menu, click “Tools”, then “Build”, or alternatively, on the “standard” bar, click the icon  to prepare the build for the application. The project will then compile. A summary is shown in the output window as shown below.

```

Output
Screens preparing...
Check automatic of scan....
Screen1 images 0 / 0 objects 1 / 1
Conversion checking...
UserScripts checking...
Objects checking...
Alarms checking...
Scheduler checking...
Datalogs checking...
Recipes checking...
Build started....
Build succeeded.

```

### **Zoom**

It is used to Zoom the current screen to various %, and it is useful during screen editing, particularly if screen size of PC screen is small. If 200% is used and if PC screen size is small, then horizontal and vertical slider will appear automatically in screen to navigate to other areas of screen easily.

### **Full screen**

It is to display full screen. After selection, the screen layout will be as shown below. To go back, in menu, click at “View” and then “Full screen” again


### **Reset window layout**

Used to display the default screen layout showing the screen working area, tool box, project explorer, output window etc.



Ex: If user deselects the “project explorer” in the View drop-down menu, then it will not show the Project explorer at the right side of the window layout. In this case, the user may select Project explorer again in the View drop-down menu. Alternatively, in Menu, click “View”, then “Reset Window Layout”, then it will reset all the view selections and show default window layout.

### **5.3.11 Objects**




More details about Basic objects, Enhanced objects, Symbol factory and Graphics are explained in section “Tool Box”



If you would like to increase font size in Menu bar, then, in menu, click File, then click “Environment” and then set font settings.

### 5.3.12 Project



Above details are explained at section “Project Tools”

### 5.3.13 Standard bar



 New Project

 Open Project

 Save Project

 Undo

 Redo

 Cut

 Copy

 Paste

-  Delete
-  Search
-  Show Grid
-  Align to Grid
-  Build
-  Offline Simulator
-  Online Simulator
-  Stop simulation
-  Download
-  Full screen

### 5.3.14 Format bar



- |   |                |   |               |   |                  |
|---|----------------|---|---------------|---|------------------|
|  | Bring to Front |  | Bring to Back |  | Lock the control |
|  | Group          |  | Ungroup       |  | Align left       |
|  | Align center   |  | Align right   |  | Align Top        |

- |   |   |   |
|---|---|---|
|  Align bottom                  |  Align middle                |  Make same width |
|  Make same height              |  Make same size              |  Size to grid    |
|  Make horizontal spacing equal |  Increase horizontal spacing |   |
|  Decrease horizontal spacing   |  Remove horizontal spacing   |   |
|  Make vertical spacing equal   |  Increase vertical spacing   |   |
|  Decrease vertical spacing     |  Remove vertical spacing     |   |
|  Center vertically             |  Center horizontally         |   |

### 5.3.15 Project Explorer



### 5.3.16 Screen

This is to add new screen to the project.


It is possible to set screen into the following types

#### 1. Page


When a new project is created, screen1 (Page type) is created by default. It is not possible to change screen1 to either template or popup. Screen1 (start page) should be "Page" type only.

#### **How to add a new page**


In Project Explorer, select "Screen1", then right click your mouse. It will show the screen below. Click "Add", and Screen2 will be created and will appear as shown below.






Now, Select Screen1, then check its properties. For example: It is possible to change the background color of a screen from the page properties



Right click your mouse keeping the pointer on any page, then, you can edit screen properties via the wizard.





It is possible either to open, delete or rename a screen. Select the appropriate screen in the project explorer, then “Right click” the mouse to show the above Screen dialog.



**Note:** These screen display names are the same as those available at project explorer. These are different from title bar (Text) defined for screen.

### **Properties:**

**Back Color:** Defines the background color of a component.

### **Events:**

**Activated:** Defines tasks to be executed before opening a Screen.

**Deactivated:** Defines tasks to be executed before closing a Screen.

### **Screen Style**

**Page No:** Displays current page number.

**Screen Height:** Defines/Displays current screen height.

**Screen Width:** Define/Display current screen width.

**Template:** Select the Template page for this screen.

**Title bar:** Control visibility of Title bar and select it in design time.




If “Title Bar” is selected in Page properties, then, the number of grids vertically in screen multiplied by grid size will not match the screen height since the Title Bar occupies some space.

**Type:** Defines the type of screen. Available options include Template, Page and Popup.


### 5.3.17 Tool box

These can be accessed from menu bar also from objects.



#### 5.3.17.1 Basic Objects

It is to draw simple shapes in the screen, data entry, data display, alarms view etc.



There are three ways to insert the above objects into the screen.

- i) Drag and drop.
- ii) Select the object, say a line, then use the mouse to draw a line on screen.
- iii) Select the object, then double click (mouse left click) quickly by keeping pointer on selected object. Then, the object will appear on screen. For example, select "line" and Double click it 3 times by keep mouse pointer on line, you can see 3 lines appear on the screen.

After inserting object to screen, it is possible to edit its properties either by Graphical User Interface (GUI) dialog or editing properties directly in property grid.

### ***How to edit via GUI dialog***

Insert any object in a screen. Select the object, right click the mouse, and then select properties.

Or

Insert any object in a screen. Double click on the Object. A GUI dialog will open automatically.



### ***How to edit via Property grid***


By default, the property grid will appear at the bottom-right area of the screen editor. If it is not available, click on the "View" drop-down menu, then click "Reset Window Layout". The property grid will appear at bottom right side of the screen editor just below the Project Explorer.



### **Property grid**



Before placing any objects in screens, check the section File- Environment and set default font size, fill color, fore color and back color for the objects as shown below.



### 5.3.17.2 Common Properties

#### *Appearance*

**Back Color:** Sets the background color of the component.

**Fore Color:** Sets the Fore color of the component.


**Bevel:** Used to set the border including inner border, outer border and style of border.

Inner Border: True/False

Outer Border: True/False

Style: 9 styles are available

None, Flat, Single, Double, Raised, Lowered, Double Raised, Double Lowered, Frame Raised, and Frame Lowered



### **Behavior**

**Visible:** True/False, determines whether component/control is visible or hidden

**Enable:** This is for event control. If linked with a Digital tag, when the tag value =1 in run time, events configured for the object will be executed. If the tag value = 0, events will be not executed

### **Data**

**Tag Binding:** Select the Tag of the desired process value

**Write design time value:** If selected, it writes the value available at "Text" in design time and in run time replacing the default value defined at Tag data base.

### **Design**

**Name:** It is the name of the component.

**Security level:** Define the security level for the component.

**Locked:** True/False: It is to Move or Resize the component.

### **Layout**

**Dock:** Defines which borders of the control are bound to the container.

**Location:** The coordinates of the upper-left corner of the component relative to upper-left corner of the container. Set X and Y position in screen in pixels.


**Size:** Size of the component in pixels. Set height and width of component in pixels.

↖ **Pointer:** It is to deselect the tool selection.

### 5.3.17.3 Line

↘ **Line:** An object used to draw a line and do animation in Run time when linked with a Tag.

User can edit properties via GUI dialog or property grid. After drag/drop of object to a screen, double click the object to open the GUI dialog, or, select the object and directly enter properties via the property grid available at bottom right corner of screen editor.



#### General

##### **Appearance**

Line Width: Define Line width

Direction: Horizontal or Vertical

## Points

Point1: Define X and Y coordinate for line starting point and they show current position.

Point1: Defines the X and Y coordinates for the line end point and shows the current position.

## Tag Binding

Select a Tag to be linked with this line. This is useful if animation is required.

The screenshot shows the 'Line1 Configuration' dialog box with the 'Animation' tab selected. The dialog is divided into three main sections: 'Movement', 'Size', and 'Tag Value'.  
1. **Movement**: Contains a checkbox for 'EnableMove' (unchecked). Below it are two groups: 'StartPosition' and 'EndPosition'. Each group has 'X' and 'Y' coordinate input fields, both containing the value '0'.  
2. **Size**: Contains a checkbox for 'EnableSize' (unchecked). Below it are two groups: 'StartSize' and 'EndSize'. 'StartSize' has 'Width' (10) and 'Height' (10) input fields. 'EndSize' has 'Width' (100) and 'Height' (100) input fields.  
3. **Tag Value**: Contains 'From' (0) and 'To' (100) input fields.

## Animation

***This is to do animation on line in Run Time***

### ***Movement***

Select "Enable Move" check box if movement animation is required during Run time.

Start Position: Defines X and Y coordinates for the start position when tag value is at its minimum during Run Time.

End Position: Define X and Y coordinate for end position when tag value is at its max. during run time.

The X position indicates movement from Left to Right, this is Horizontal movement. The Y position indicates movement from Top to Bottom, this is Vertical movement.

For example: Recorder 7" (High Performance) project,  
800 X 480 pixels,  
Normal installation, Horizontal (Left to Right) = 800 pixels,  
Vertical (Top to Bottom) = 480 pixels

Enable move: Selected  
Start position X = 0, Y = 0  
End position X = 800, Y = 0  
Tag Value, From = 0, Tag Value To = 100

Now, in Run time, when the Tag value = 0, the line will be at the Top left.  
When the Tag value = 100, the position of the line will be at the Top Right

### **Size**

Select "Enable Size" check box to enlarge/decrease size of component during Run time.

Start Size: Defines X and Y coordinates for the starting size when the tag value is at its minimum during Run time.


End size: Define X and Y coordinate for end size when tag value is max. Run time.

### **Tag Value**

Select a Tag to be linked with this line. This is useful if animation is required to be done on the line.

## **Bands**

***This is to select various bands as part of an animation during Run Time***




### **Band Count**


A maximum of 32 bands are available.

For example: In the above sample,  
 If the Tag value is 0 to 20, the line will be Yellow  
 If the Tag value is 21 to 80, then, line color = Green  
 If the Tag value is above 80, line color = Red

### **5.3.17.4 Polygon**

✦ **Polygon:** Used to draw a polygon. After finishing drawing, double left-click the polygon using the mouse to complete the Polygon. It is also possible to link a polygon to a tag and define some user friendly animation to appear during Run time.





**Polygon1 Configuration**

General Points Animation Bands Common

**Point1**


X	5	Y	49
---	---	---	----

**Point2**

X	93	Y	5
---	----	---	---

**Point3**

X	130	Y	64
---	-----	---	----



**Polygon1 Configuration**

General Points Animation Bands Common

**Fill**

EnableFill

StartFill	0	EndFill	100
-----------	---	---------	-----

**Movement**

EnableMove

<b>StartPosition</b>		<b>EndPosition</b>	
X	0	X	0
Y	0	Y	0

**Size**

EnableSize

<b>StartSize</b>		<b>EndSize</b>	
Width	10	Width	100
Height	10	Height	100

**Tag Value**

From	0	To	100
------	---	----	-----

## Animation

***This is to do animation with a Polygon in Run Time***

### ***Fill***

Select "Enable Fill" if filling animation is required on a Polygon object during Run time. When a tag value changes during Run time, it shows the polygon filling with a defined color inside the Polygon object. It's like a bar graph where the filling is within the polygon shape.

Start Fill: Defines a Start value for Fill

End Fill: Defines an End value for Fill

### ***Movement***


Used to define a movement position. This is the same as previously explained for the Line object earlier.

### ***Size***

Used to define the amount of size increase/decrease. This is the same as previously explained for the Line object earlier.

### ***Tag Value***

Select a Tag to be linked with the Polygon object. This is useful if animation is required to be done with the Polygon.




Band editor: A maximum of 32 bands are available.


For example: In the above sample,  
If the Tag value is 0 to 20, Polygon fill color = Yellow  
If the Tag value is 21 to 80, then, Polygon fill color = Green  
If Tag value is above 80, Polygon fill color = RED

If required, it is also possible to configure the blink property and set blink color for any band.

### 5.3.17.5 Rectangle


**Rectangle:** Used to draw a Rectangle and do animation during Run time when linked with a Tag.





Animation Supported: Fill, Movement and Size

The above features are same as explained for Line and Polygon objects





Band editor: A maximum of 32 bands are available.

For example: In the above sample,  
If the Tag value is 0 to 20, Rectangle fill color = Yellow  
If the Tag value is 21 to 80, then, Rectangle fill color = Green  
If the Tag value is above 80, Rectangle fill color = Red

If required, it is also possible to configure blink property and set blink color for any band.


### 5.3.17.6 Ellipse

**Ellipse:** Used to draw an Ellipse or a circle and do animation during Run time when linked with a Tag.



Animation Supported: Fill, Movement and Size

The above features are the same as explained for Line and Polygon objects.



Band editor: A maximum of 32 bands are available.


For example: In above the sample,

If the Tag value is 0 to 20, Ellipse fill color = Yellow  
If the Tag value is 21 to 80, then, Ellipse fill color = Green  
If the Tag value is above 80, Ellipse fill color = Red

If required, it is also possible to configure blink property and set blink color for any band.


### 5.3.17.7 Arc

 **Arc:** Used to draw an Arc and do animation during Run time when linked with a Tag.




Start Angle: Defines the start angle.

Sweep angle: Defines the end angle



## Supported Animation: Movement and Size




Band editor: A maximum of 32 bands are available. Band editor for “Arc” is the same as explained for the “Line” object earlier.

### 5.3.17.8 Table


It is used to draw a table during design time by specifying number of rows & columns. All rows/columns will have an equal width and height. It is possible to place labels on rows (Linked with Tags) for displaying process values to appear like a tabular column. User can edit properties via the GUI dialog or Property grid as per convenience. After dragging/dropping the object to the screen, double click on the object to open GUI dialog.



While working with a Table, in page properties, select Snap to Grid = False so that it will be easy to place labels/textboxes in required positions easily.



Drag/Drop Table from Basic objects to the screen, then double click on Table. The following screen will open.



Note: Deselect “Same Width” to adjust column width in the Table

Note: Deselect “Same Height” to adjust Row height in the Table

### Property grid



<b>Design</b>	
(Name)	<b>Table1</b>
Columns	<b>5</b>
Locked	False
Rows	<b>5</b>
<b>Layout</b>	
Dock	None
Location	<b>80, 192</b>
Size	<b>480, 176</b>

### Properties

**Back Color:** It is the back color of the table

**Fore Color:** It is the color for the lines of the table

**Line Width:** It is the width of the lines of the table

**Columns:** Defines the number of columns in the table

**Rows:** Defines number of rows in the table

**Name:** The unique name for the table in a specific page

**Locked:** Used to determine if table is locked for further moving and resize in design time and you can set this in property grid.


### 5.3.17.9 Numeric Up/Down

Numeric Up/Down is a Graphical User Interface widget that allows the user to increase or decrease the value of a tag by pressing up or down arrows during Run time, or to enter a numeric value directly via a keypad. Users can edit properties via GUI dialog or Property grid for convenience. After drag/drop of a numeric up/down object to the screen, double click on the object to open GUI dialog.

Every Numeric Up/Down button should be linked with an **Analog Tag**.



Except the Up/Down arrow, if a user presses another area of the Numeric Up/Down component in the recorder during Run time, a numeric keypad will open. The user can then enter a numeric value directly. The numeric keypad will not appear in the PC during Online/Offline simulation, you can use the keyboard directly to enter a numeric value.



Increment: Select the value to be incremented/ decremented each time when the up/down arrow is pressed during Run time.

### **Properties**

**Write design time value:** If selected, it writes value available at “Text” during design time and also during run time replacing the default value defined in the Tag data base.

**Rounding:** Rounds to nearest value


**Decimal:** Enter the number of decimal points

**Value:** Current Tag value. It is used to enter a value during design time and to check how a value is displayed during Run time.

**Increment:** Value to be incremented during Run time after pressing Up/Down button.


**Minimum:** Defines the minimum value

**Maximum:** Defines the maximum value




**Soft keyboard:** If enabled, it is possible to control the keypad appearance during run time. For example, if alignment is selected as Middle center, then, when keypad appears in run time, it will be located to Middle center in screen

**Events:** Defines events to be executed when the operator presses the Up/Down arrow and changes the value during Run time.




### 5.3.17.10 Digital LED

This object is used to view a process value in a digital format. Generally, it is linked with an analog type tag (example: an analog input tag at a PLC, which is received as 4-20 mA signals from field transmitters to define things like Temperature, Pressure, Flow, Level, Position etc...)



For common properties like Back Color, Bevel, ect., please refer section “Common Properties



### Property grid

[-] Digits	<b>Red,80,3,40,Color [Silver]</b>
ActiveColor	<span style="color:red">■</span> <b>Red</b>
DigitHeight	<b>80</b>
DigitSpace	<b>3</b>
DigitWidth	<b>40</b>
InactiveColor	<span style="color:grey">■</span> <b>Silver</b>
SegmentSpace	<b>1</b>
SegmentThickness	<b>10</b>

### Properties

**Back Color:** Defines background color for the component

**Inner border:** Select if inner border is required for the component

**Outer border:** Select if outer border is required for the component

**Style:** Defines border style. Available options are Single, Double, Raised, Lowered, Double Raised, Double Lowered, Frame Raised and Frame Lowered

**Active Color:** Defines Active Color of Segment for Digits

**Inactive Color:** Defines color of inactive segments. In the seven-segment LED display, some segments may be active and some other segments may be inactive depending on numeric values.

**Digit Height:** Defines height of digits

**Digit Width:** Define width of digits

**Digit Space:** Defines the space between digits

**Segment Space:** Defines the space between segment to segment for digits


**Segment Thickness:** Defines thickness of segments for digits

**Decimals:** Defines the number of decimal points


**Tag Binding:** Selects the Analog Tag of process value

### 5.3.17.11 Digital Box

Digital Box is a Graphical User Interface widget that displays a digital tag value along with four predefined labels as attributes for the process value in Run time.



Digital Boxes are normally used with **Analog** tags to display process values like Temperature, Pressure, Flow etc. They also allow 4 different labels as attributes for displaying tag related information.



<b>Appearance</b>	
Attribute1	T10
Attribute2	°C
Attribute3	Mill 1
Attribute4	Outlet
AttributeFont	Microsoft Sans Serif
BackColor	Khaki
Decimal	2
ForeColor	Blue
ValueFont	Arial,20,Bold

<b>Behavior</b>	
Value	0
Visible	True
<b>Data</b>	
TagBinding	Tag3
<b>Design</b>	
(Name)	DigitalBox1
Locked	False
<b>Layout</b>	
Dock	None
Location	176, 224
Size	256, 112

### Properties

**Attribute1:** attribute to be displayed at Top left side of Digital Box

**Attribute2:** attribute to be displayed at Top Right side of Digital Box

**Attribute3:** attribute to be displayed at Bottom Left side of Digital Box

**Attribute4:** attribute to be displayed at Bottom Right side of Digital Box

**Attribute font:** Define font for attribute, select type font, and size of font and style of font. Styles include Regular, Bold, Italic, Underline, and Strike out.

**Back color:** Defines background color

**Fore Color:** Define fore-color for the font

**Decimal:** Defines number of decimal places for the value to be displayed


**Value font:** Used to adjust the size of the display process value font, select type of font, size of font and style of font. Styles include Regular, Bold, Italic, Underline and Strike out.

### 5.3.17.12 Text box

Used to Read/Write Alpha numeric text in Run time. It can be linked with any type of tag.




If the object is linked with String type tag, an alpha-numeric keypad opens during Run time if a user touches the object. If the object is linked with an Analog or Digital tag, a numeric keypad opens during Run time if a user attempts to touch the object. If a digital tag is used, make sure "decimal" is set to 0.



Alpha numeric keypad




Numeric keypad



Note: For common properties of all components, please check the beginning of this section.

**Write design time value:** If selected, it writes the value available at “Text” during design time and also during run time replacing the default value defined in the Tag database.




**Soft keyboard:** If enabled, it is possible to control the keypad appearance during run time. For example, if “alignment” is selected as Middle center, then, when the keypad appears during run time, it will be located in the middle-center of the screen

<table border="1"> <tr><td>Appearance</td></tr> <tr><td>BackColor</td><td>White</td></tr> <tr><td>Decimal</td><td>2</td></tr> <tr><td>ForeColor</td><td>ControlText</td></tr> <tr><td>Password</td><td></td></tr> <tr><td>Text</td><td>TextBox1</td></tr> <tr><td>TextFont</td><td>Tahoma,12,Bold</td></tr> <tr><td colspan="2">Behavior</td></tr> <tr><td>Visible</td><td>True</td></tr> <tr><td colspan="2">Data</td></tr> <tr><td>TagBindin</td><td>Tag1</td></tr> </table>		Appearance	BackColor	White	Decimal	2	ForeColor	ControlText	Password		Text	TextBox1	TextFont	Tahoma,12,Bold	Behavior		Visible	True	Data		TagBindin	Tag1	<table border="1"> <tr><td colspan="2">Design</td></tr> <tr><td>(Name)</td><td>TextBox1</td></tr> <tr><td>Locked</td><td>False</td></tr> <tr><td>SecurityL</td><td>0</td></tr> <tr><td colspan="2">Events</td></tr> <tr><td>Changed</td><td></td></tr> <tr><td colspan="2">Layout</td></tr> <tr><td>Dock</td><td>None</td></tr> <tr><td>Location</td><td>96, 96</td></tr> <tr><td>Size</td><td>112, 24</td></tr> <tr><td colspan="2">Misc</td></tr> <tr><td>WriteDesi</td><td>False</td></tr> </table>		Design		(Name)	TextBox1	Locked	False	SecurityL	0	Events		Changed		Layout		Dock	None	Location	96, 96	Size	112, 24	Misc		WriteDesi	False
Appearance																																																
BackColor	White																																															
Decimal	2																																															
ForeColor	ControlText																																															
Password																																																
Text	TextBox1																																															
TextFont	Tahoma,12,Bold																																															
Behavior																																																
Visible	True																																															
Data																																																
TagBindin	Tag1																																															
Design																																																
(Name)	TextBox1																																															
Locked	False																																															
SecurityL	0																																															
Events																																																
Changed																																																
Layout																																																
Dock	None																																															
Location	96, 96																																															
Size	112, 24																																															
Misc																																																
WriteDesi	False																																															

### 5.3.17.13 Label

The “Label” object is used to write a simple line of text for user information in the screen. Example: Tag name, Pump number display etc. It is also used to display process values (read only) to operators if linked with a Tag.





Properties...	
<b>Appearance</b>	
BackColor	<b>Yellow</b>
Decimal	2
ForeColor	<b>Blue</b>
Rounding	False
Text	<b>P102</b>
TextAlign	TopLeft
TextFont	<b>Tahoma,12,Bold</b>
<b>Behavior</b>	
Enable	
Visible	
<b>Data</b>	
TagBinding	<b>Tag3</b>
<b>Design</b>	
Name	<b>Label1</b>
<b>Events</b>	
Clicked	
<b>Layout</b>	
Location	<b>224;126</b>
Size	<b>112;38</b>

Note: For common properties of all the components, please check beginning of this section.

## Properties

**Text:** Defines text associated with this component and it should be entered at design time only.

**Text Align:** It is for Alignment of text. Available options include Top Left, Top Center, Top Right, Middle Left, Middle Center, Middle Right, Bottom Left, Bottom Center and Bottom Right

**Text Font:** Defines font for text including type of font, size of font and style of font. Styles include Regular, Bold, Italic, Underline and Strikeout.


**Tag Binding:** Select the Analog Tag of a process value

**Decimal:** Defines the number of decimal points

### 5.3.17.14 Date and time Label

1/20/2010 PM 4:43:03

Used to display Date and Time in screen.



If date and time is required in more than one screen, it is better to create a screen and select the screen type as “Template”, and then link this template to all other required screens to display Date and Time automatically. This is more efficient than keeping Date and Time label in more than one screen, since it uses less memory.


### 5.3.17.15 Button



A Button is commonly used to perform an action after operator presses it with their finger, or by clicking using a mouse during Run time.


Generally, “Button” is used to turn ON a bit, Turn OFF a bit etc. when used with Digital type tags. Example: Start Pump, Stop pump etc.

Three kinds of “Events” are supported for a button. Clicked, Pressed and Released. Several functions are supported which can be configured from “Events” and all the functions are covered in next section “Function editor”.



## Properties

**Back Color:** Selects Back color for the object. Also, it is possible to select transparent mode if required. *Firmware V1.20 onwards.*




**Text:** Defines required text to be displayed on the object. *It is also possible to enter multiline text from firmware V1.20 onwards*




**Show select:** True/False. If it is selected, then, when the operator presses this button, it will show a dotted line just inside the button. When the operator presses another button, it automatically shows selected “show” status to latest button and deselect “select” status for previous button pressed by the operator.

**Border Style:** Defines border style. Available options include none, fixed single and fixed 3D

**Image:** Selects the Image to be displayed on the object. Image can be selected from either Basic symbols or Symbol factory, or a custom image can be used if they are formatted as bmp, wmf, jpg, gif or png.



**Text font:** Define the font including name of font, size of font and style of font



**Timing:** This is an advanced feature and used to make sure operator action is properly received by PLC when the PLC has a large scan time.

**Hold time:** This is generally applicable for a “Clicked” event. This keeps executing the action defined at the “Clicked” event for the time defined at hold time. We suggest using holding time greater than the PLC scan time.  
Example: 300 msec.


Example:

**Push button Function**




Example: Operator presses button for only 200 msec. When operator clicks the button, Tag1 = 1. When operator releases the button, Tag1 = 0, holding time = 1000 msec.

Since holding time is set for a clicked action, the released action “TurnBitOff” will be executed only after completing 1000 msec, not immediately after the operator releases the button. In this case, if the PLC scan time is 800 msec, the operator click action will be detected properly because the button will remain active for 1000 msec.




**Auto Repeat & Interval time:** This is generally applicable for a “Pressed” event. It is to repeat the action defined at the “Pressed” event as per the set interval time.

Example: When operator keeps the button pressed, the set point should be incremented by 1 for every 1 second.




Auto repeat with time interval and holding time cannot be used together.

**Tag binding:** Select the tag that should be linked to the button to show a different display during run time based on configuration available at Band editor. Any of the configured Analog or Digital tags can be selected.



If Tag1 is an Analog Type (32 bit), it is also possible to show a different display based on individual bits. By default, it is disabled. You can select the bit from the combo box and then configure the band editor per project requirements.



**Bands:** Defines bands for the button.

**Back color:** Defines the back color for the selected band

**Fore color:** Defines the fore color to appear for selected band in run time

**Text:** Define the text to be displayed for selected band in run time

**Visible:** Controls if the button is visible

**Blink:** Select if blink is required when the tag value reaches a selected band during run time. If yes is selected, it allows the user to enter a blink color.

**Bitmap file:** Select the image to be displayed on button when tag value reaches this band in run time.

For example: When Tag1=0, show Red colored motor symbol on the button.

When Tag1=1, show Green colored motor symbol on the button.

Note: Two different symbols are required for the above example

Bmp, wmf, jpg, gif and png types are supported. If the selected file is different than wmf, then, it is also possible to select Image layout and transparent options.



**From File browser:** To select image from a specified location

**From Basic Symbol:** To select images from the free basic symbols (\*.wmf format) available in Recorder editing software.

**From symbol factory:** It allows the user to select symbols from the symbol factory (in wmf format).

**Image layout:** None, center and Stretch options are available. Stretch means the selected bitmap will be stretched to the size of the button.

Note: If a bitmap has poor resolution, when stretch is used, it may show a low quality image in screen.


**Flip:** Used to flip a button. This needs to be configured during design time. Available options include None, Horizontal, Vertical and Both.

**Rotation:** Used to rotate the button at predefined angles. This needs to be configured during design time. Available options include 0°, 90°, 180° and 270°.

**Value:** Defines the maximum range of the selected band. Low range will be the value defined at the previous band. There is no need to enter any value for band 1 as its value is 0 which is low range.



If the button is linked with a Digital Tag, then, in the band editor, it will show only two bands for value 0 and 1. When a button is linked with an Analog tag, it is possible to configure up to 32 bands for showing different states of button based on value of tag. It shows statuses similar to word lamp.



**Security control:** Defines security level for the button. It allows the user to operate the button only when operator security level is equal to or more than security level defined here.

Please refer section “Security” at Project explorer for more information about security features.

## Events

**Clicked:** Define the action that happens when user presses button during Run time. If required, it is possible to configure a holding time for this action.



Holding time is a very useful function. If the PLC has a large scan time, sometimes the operator “clicked” action will be not detected by the PLC. In this case, it is possible to have a hold time for a “clicked” event so that operator action will be continuously present for the time defined at “holding”, such that the PLC will receive the operator action properly.



If the operator touches a button and releases his/her finger instantly, it is called a “Clicked” action. During this time, a total of three actions will be executed. Click, Pressed and Released



Case-1

Holding time = 0

In above example, Tag1 value becomes 3

Case-2

Holding time = 5000m sec

In the above example, if the scan time for Tag1 is 1000m sec, the Tag1 value becomes approximately 8.

When the button is clicked, the “Clicked” and “Pressed” event action occurs, and the Tag1 value becomes 2. Since the holding time is 5 sec, for the next 5 seconds, the Tag1 value is incremented by 1 each second. So, Tag1 value becomes 7. When the button is released, Tag1 value is incremented by 1 again, so it becomes 8.

The above example is for illustration only to understand about events for the button object.

**Pressed:** Define the action that happens when a user continuously presses on a button. If required, it is possible to configure Auto repeat and interval time for this action.



Once an operator touches a button, the “clicked” event will be executed first. If the operator keeps holding the button continuously, the “pressed” action


will continuously be executed. When the operator releases their finger, the “released” action will be executed.

Auto repeat: On, Time interval=1000 m sec. In this example, the Tag1 value will first increment by 1, then it will keep incrementing by 1 once every 1000 m sec. as long as the operator presses the button. The Tag1 value will also be incremented by 1 when the operator releases the button.

**Released:** Defines the action when the user releases the button

### **Switch Function**


With this function, two buttons are required. One button to turn a tag ON, and a second button to turn a tag OFF.




When the operator clicks Button1, Tag1 will = 1. Now, Tag1 will = 1 even after the operator releases the button, and it will continue to maintain its earlier state. When the operator clicks Button2, Tag1 will = 0.

#### **5.3.17.16 Function editor**

This is very useful to select different functions to execute based on operator actions. During Run time, this provides an easy way for an application developer to use a ready-made macro instead of writing scripts. Insert a Button into any screen and configure events. The following functions are supported.



### ***Page Control functions***



Every screen has a screen number. The pointer will be the screen number for navigation.

***GotoFirstPage:*** It is used to navigate from current screen to first screen

***GotoPreviousPage:*** Used to navigate from current screen to previous screen

***GotoNextPage:*** Used to navigate from current screen to next screen

***GotoLastPage:*** Used to navigate from current screen to Last screen


***GotoPage:*** Used to navigate from current screen to specific screen by name

***GotoPageByNumber.*** Used to navigate from current screen to specific page by number

***GotoPopUp:*** Used to open specific pop up screens by name

***ClosePopUp:*** Used to close pop up screens by name

## Tag functions



**SetValuetoTag:** Writes a value to a tag

Example: Set 90 to TagA when operator presses on a button during run time.



**AddValuetoTag:** Used to add value to Tag

**SubtractValuefromTag:** Used to subtract value from Tag

**CopyTagBtoTagA:** Used to copy TagB value to TagA



**AddTagBtoTagA:** Used to add TagB to TagA and store result in TagA

**SubtractTagBfromTagA:** Used to subtract TagB from TagA and store the result in TagA.

**SwapTagAforTagB:** Used to swap TagB data with TagA

**CopyStringTagBtoTagA:** Used to copy the string type of TagB to TagA


**SetStringtoTag:** Used to write a string to a String type Tag



**CopyBlockfromTagBtoTagA:** Used to copy a block of tags from TagB to Tag1

For example: Copy 4 continuous tags from Tag5 to a target location starting with Tag1. Tag5 is copied to Tag1, Tag6 is copied to Tag2, and so on.

Note: Maximum block size is limited to 80 tags



**EditValuetoTag:** Used to edit tag value during run time from a keypad. For example, if this function is called from button “clicked” event, then, a keypad will open during run time and the user can enter a set point.

**TurnBitOn:** Used to turn on a bit.

If a momentary Turn on is required, then in “Clicked” action, select Turn On, then, in “Released” action, select “Turn OFF”.

**TurnBitOFF:** Used to turn off a bit

**Togglebit:** Used to toggle the bit




Fig: Ladder logic in PLC





Fig: On button configuration





If a button is not switching properly at the PLC, then, in the “General” Tab, select the “Hold” check box and enter the hold time. Default value is 50 msec. If required, adjust this to 100 msec. and check again if the button is switching properly.



Fig: Off Button configuration



If button is not switching properly at PLC, then, in General Tab, select “Hold” check box and enter the hold time. Default value is 50 msec. If required, adjust this to 100 msec. and check again.






Fig: Bit lamp status

### 5.3.17.17 Bit lamp



A bit lamp is used to show the digital input status for the operator. It is linked with either a digital input tag or an Analog input tag. By using the band editor, it is possible to display a different foreground color, different background color, different text, different symbols, different Blink color, and control visibility when the Tag value is 0 or 1.

When a Bit lamp is linked with a digital tag, it has only two bands by default. The Band1 value is 0 and Band 2 value is 1.

For example: If Tag1 = 0, show Red colored background with an Orchid color blink. If Tag9=1, show green colored background.



## GUI Wizard




**Bitmap file:** Select the image to be displayed when tag value reaches this band in run time.

For example: When Tag1=0, show Red colored motor symbol  
When Tag1=1, show Green colored motor symbol

Note: Two different symbols are required for the above

Bmp, wmf, jpg, gif and png types are supported. If the selected file is other than wmf, then it is also possible to select Image layout and transparent options.



**From File browser:** Allows user to select images in formats of bmp, wmf, jpg, gif and png

**From Basic Symbol:** Allows user to select wmf format images from basic symbols

**From symbol factory:** Allows for selecting symbols from symbol factory in .wmf format

**Image layout:** None, center and Stretch options are available. Stretch means the selected bitmap will be fixed to the size of the bit lamp

Note: If a bitmap has poor resolution, when stretch is used, it may show a low quality image in screen.

**Flip:** Used to flip bit lamp and needs to be configured during design time. Available options include None, Horizontal, Vertical and Both.

**Rotation:** Used to rotate a bit lamp in predefined angles and needs to be configured at design time. Available options include 0°, 90°, 180° and 270°

**Circle:** By default, a bit lamp object shape is in Rectangle. Select this if you wish to change the bitlamp shape to a circle. It is more useful to show status of digital inputs for the operator during Run time.

### **How to show status of an individual bit in Analog type tag**

Sometimes, you will get a 16 bit/32 bit tag from a PLC with different diagnostic information, and you would like to show 16 bit/32 bit lamps in the Recorder screen.

When a Bit lamp is linked with an Analog tag, for example: Int16/Int32, it has two bands. By default, Band1 value is 0 and Band 2 value is 1. In this case, using each bit lamp, it is possible to show the status of each individual bit status within 32 bits as per configuration available at band editor.



In the above figure, Tag2 is an analog type (4 byte), so, a TagBitNo combo box will appear for the selection of the required bit within 32 bits (0 to 31).

If Tag2 is Digital type tag, then, TagBitNo. Combo box is not visible.

### **5.3.17.18 Word lamp**



Word lamps are similar to Bit lamps but linked with an Analog type tag only. It can have many bands. By using the band editor, it is possible to display a different foreground color, different background color, different text, different symbols, different Blink color, and control visibility when Tag values change values during Run Time.



For example: Tank Level indicator

When Tag1 value is

- 0 to 10, Text = Low Low Level, Color = Yellow Blinking
- 11 to 20, Text = Low Level, Color = Yellow Background
- 21 to 80, Text = Normal, Color = Green back ground
- 81 to 90, Text = High level, Color = Red back ground
- 91 to 100, Text = High High Level, Color = Red blinking

Create 5 bands as shown

## GUI Wizard/Dialog



Band1 range = 0 to value defined at band2-1.

i.e., 0 to 10

The screenshot shows the configuration panel for Band2. It includes the following settings:


- BackColor:** Yellow
- ForeColor:** Black
- Text:** Low Level
- Visible:** Checked
- Blink:** Unchecked
- BlinkColor:** Pink
- Image:**
  - BitmapFile:** (Empty field with a browse button)
  - ImageLayout:** None
  - Transparent:** Unchecked
  - TransparentColor:** (Empty field)
  - Flip:** None
  - Rotate:** 0
  - Value:** 11

Band2 range: Band 2 value to Band3 value-1  
i.e., 11 to 20


The screenshot shows the configuration panel for Band3. It includes the following settings:

- BackColor:** Green
- ForeColor:** Black
- Text:** Normal
- Visible:** Checked
- Blink:** Unchecked
- BlinkColor:** Pink
- Image:**
  - BitmapFile:** (Empty field with a browse button)
  - ImageLayout:** None
  - Transparent:** Unchecked
  - TransparentColor:** (Empty field)
  - Flip:** None
  - Rotate:** 0
  - Value:** 21

Band3 range: Band 3 value to Band4 value-1  
i.e., 21 to 80



Band4 range: Band 4 value to Band5 value-1  
i.e., 81 to 90



Band5 range: More than or equal to value defined at band 5 (In this case number of bands=5)  
i.e., greater than 91

### 5.3.17.19 Check Box

The Check box (or tick box) is a graphical user interface widget that permits the user to make multiple selections from a number of options during run time. Generally it is linked with a Digital type tag Flag/Bit memory in a PLC for use in ladder programming to receive an action from an operator.

## CheckBox



Every check box is linked with a single **Digital** tag from Tag Database

In the above white box, normally,

white space means Not selected, False, Tag Value = 0

Tick mark means, True, Tag value = 1

A caption describing the meaning of the check box is normally shown adjacent to the check box. Inverting the state of a check box is done by touching with a finger or clicking the mouse on the box, or on the caption.



## Properties

**Write design time value:** If selected, it overwrites the default value defined in the tag database.

**Checked:** Default setting, available options True/False

For example: Tag1 is linked with Checkbox 1. If Checked, the tag = False, that means Tag1=0. If Checked, the tag = True, then Tag1 = 1.

**Text:** It is Text that appears near Check box as a caption. Example: Text = P101

## Events

**Changed:** Define action using function editor. When operator presses on check box during Run time, the actions defined here will be executed.

Example: There are three pumps named P101, P102 and P103, and the operator would like to select pump P101 for startup. Using the check box, write a meaningful caption via the "TEXT" property to appear at the right side of check box, and link each of the above check boxes with appropriate Tags. Let's say P101, P102 and P103.

Then, when P101 is selected by the operator in run time, P101 Tag value will become 1.



If "checked" = false is selected during design time, then Tag value will = 0. If operator presses on check box during Run time, the symbol ✓ will appear, and the Tag value will become 1.


If "checked" = True is selected during design time, the Tag value will = 1, and the ✓ appears during Run time. If the operator presses the check box during design time, the symbol ✓ disappears and the Tag value becomes 0.



**If you are unable to select the required selection using check box in Run time, please perform touch screen calibration.**



**If Check box is linked with an Analog type Tag, then, it is possible to select an individual bit.**





### 5.3.17.20 Combo box



A combo box is a commonly-used graphical user interface widget. It is a combination of a drop-down list or list box and a single-line textbox, allowing the user to choose from the list of existing options in Run time. Generally it is linked with an Analog tag. Based on selection, the value of the tag will be changed, and it can be used in Logic at PLC.


It saves space in the Recorder screen by allowing the operator to select the option only when it is required by touching the down arrow at right side of Combo box.

Every Combo box is linked with single **Analog** tag from properties.



Note: Do not keep any empty space between different text entries, otherwise, unpredictable results may occur.

### Property grid



<b>Design</b>	
(Name)	<b>ComboBox1</b>
Locked	False
SecurityLevel	<b>0</b>
<b>Events</b>	
Changed	
<b>Layout</b>	
Dock	None
Location	<b>128, 96</b>
Size	<b>224, 24</b>

## Properties

**Button Width:** Defines the width of a Button. It modifies the width of the down arrow at the right side of the combo button.

**Items:** Defines all the available options during design time.

For example: There are 7 options available to select a process.

Tag1, an analog tag, is linked to Combo box1

Now, If Option A is selected, then during Run time, Tag1 value will = 0,

If Option B is selected, then Tag1 value will = 1

.....

.....

If Option G is selected, then Tag1 value will = 6

## Events

**Changed:** Defines an action using function editor. When the operator presses on a combo box during Run time, the actions defined here will be executed.



To increase up/down arrow size on combo box, increase the size of text font.

### 5.3.17.21 List box



A list box is a Graphical User Interface widget that allows the user to select a single item from a list of available items. The available options are entered during Design time and they are available for selection during Run Time. On selection, it writes a value to a Tag based on the order number.

Every List Box should be linked with an **Analog** tag.

## GUI Wizard/dialog



Note: Do not keep any empty space between different text entries, otherwise, unpredictable results may occur.

## Property Grid

<b>Appearance</b> BackColor <input type="checkbox"/> White ForeColor <input checked="" type="checkbox"/> ControlText ScrollBarWidth 20 <b>TextFont</b> Tahoma, 12, Bold		Enter List of Options in Design time  Select Analog Tag	<b>Design</b> (Name) ListBox1 Locked False SecurityLevel 0	
<b>Behavior</b> Visible True <b>Data</b> Items (Collection) TagBinding Tag10			<b>Events</b> Changed <b>Layout</b> Dock None Location 176, 128 Size 160, 112	

## Properties

**Scroll Bar Width:** Defines the width of the scroll bar that appears on Right side of List box.

**Items:** Define all the available options in design time.

For example: There are 6 options available to select a process.

Tag1, an analog tag, is linked to List box1

Now, If "Select A" is selected, then Tag1 value will = 0

If "Select B" is selected, then Tag1 value will = 1

.....

.....

If "Option G" is selected, then Tag1 value will = 5

## Events

**Changed:** Define actions using function editor. When operator presses on list box item in Run time, the actions defined here will be executed.


### 5.3.17.22 Group Panel

Used to group objects in a screen.

Procedure

Click on "Group Panel" at Basic Objects

On Screen, just draw a rectangle with your mouse over the objects that you would like to group together. It will appear as shown below:



Now, double click on Group Panel object



Select "Group Controls" check box and click "OK"

Now, you will be able to move grouped objects to another location, or rescale them to fit to another screen size etc.

**Group Controls:** Select the check box to apply the group function. De-select the check box for ungroup

### 5.3.18 Enhanced Objects

Fine components are available for User interface and display. The components include Dial, Digital LED, Level, Meter, Slider, Switch, Thermometer and Toggle.

#### 5.3.18.1 Common Properties

##### *Appearance*

**Back Color:** Set the background color of the component.

**Bevel:** Used to set border including inner border, outer border and style of border.

Inner Border: True/False

Outer Border: True/False

Style: 9 styles are available

None, Flat, Single, Double, Raised, Lowered, Double Raised, Double lowered, Frame Raised, Frame Lowered.

##### *Behavior*

**Visible:** True/False. Determines whether control is visible or hidden.

**Enable:** This is for event control. If linked with a Digital tag, if the tag value =1 during run time, events configured for the object will be executed. If tag value = 0, events will be not executed

## Data

**Tag Binding:** Select the Analog Tag of process value

**Write design time value:** If selected, the value entered here during design time will be replaced by the default value defined in the tag data base.

## Design

**Name:** Label1, It is the name of the component. Every component will have a **UNIQUE** number in a page. If more than one Label is available in the same page, the number will be incremented automatically. The user can also change name of this component if required.

Component "Name" property is very useful and it can be used in scripts also.

Example: Task: Change Label1 "back" color to blue during Run time when Tag1 is equal to 1.

```
if(Tag1 == 1)
{
    Screen1.Label1.BackColor=Color.Blue;
}
```

Screen1: It is the location of Label1

Label1: Object name

BackColor: Property of Label related to background color

Color.Blue: Target Color

If the above script is executed in scheduler once per second, then when Tag1 = 1, the back color for Label1 will change to Blue during Run time.



Properties are case sensitive.

BackColor : OK

Backcolor : Not OK

**Security Level:** Define security level for the component to be used by the operator. If operator security level is less than security level defined for component, it will not allow operator to operate the component.


**Locked:** True/False: It is to Move or Resize the component.

## Layout

**Dock:** Defines which borders of the control are bound to the container.

**Location:** The coordinates of the upper-left corner of the component relative to upper-left corner of the container. Set X and Y position in screen in pixels.





## Properties

**Back Color:** Defines the background color for the component.

**Labels Position:** Define label position. Available options are Top Left, Bottom Right and Both. Naming convention depends on orientation. If orientation = Vertical, then, if “Top left” is selected, label position will be shown on “Left” side. If orientation = Horizontal, then if “Top Left” is selected, label position will be shown on “Top” side of component.


**Orientation:** Vertical/Horizontal. Select direction.

**Text Font:** Used to set the font of the label. Options include Name of Font, Size of font and Style of font. Supported styles include Regular, Bold, Italic, Underline & Strikeout.

**Bevel:** Defines inner border and outer border for the component. Please refer to common properties at the beginning of this section for more details.

**Decimals:** Define number of decimals to be displayed for value to be displayed along with level component in run time.

**Tag Binding:** Selects the Analog Tag of process value.



**Ticks:**

**Ticks Position:** Define Ticks Position. Available options include Top Left, Bottom Right, Both and None.

**Ticks length:** Define length of Ticks in pixels.

**Scale:**

**Scale divisions:** Define the number of Big Ticks in Level graph.

**Scale Sub Divisions:** Define the number of ticks between two big ticks.

**Scale Label Divisions:** Define the number of Labels to be displayed.  
Example: If Scale label division = 5, Scale = 0-100, then, it display labels as 0, 20, 40, 60, 80 & 100.


**Scale Width:** Define Scale width. If ticks are selected to display on both directions, this is the defined width between two scales on both sides.

**Bar**

**Bar Width:** Define width of Bar graph.

**Divisions:** Define number of divisions (Like bricks) to appear in Bar graph.

**Space:** Define Space between divisions (bricks) in pixels.



**Maximum:** This is the max range of the process value (analog input tag)

**Minimum:** This is the minimum range of Process Value (analog input tag)

Example: If an Ear Level transmitter range is 0 to 100, set Minimum = 0, Maximum = 100.

**Reverse Scale:** True/False. If it is selected, then, zero will be on bottom side and 100 will be at top side for vertical orientation.


**Step:** This is the minimum value to reflect change in Bar graph position. Bar Step and Bar division settings are closely related. If Bar divisions = 50 for a scale value of 0-100, then, if Step=2, when process value changes by value 2, it shows level value change clearly in level graph.

**Value:** Used to enter a process value during design time and to check the bar graph display on the PC. It requires the operator to enter a value in multiples of the step value. Otherwise, it is automatically rounded to the closest multiple of the step value.



**Is Indicator only:** If this is selected, the level graph is used for “Read” purposes only. If it is not selected, you can use a level graph for write purposes similar to slider to send a set point from the Recorder to a PLC etc. Just use finger to touch at various places in Level graph to set the level required.

**Value Position:** Define position of process value to be displayed during Run time along next to the Level graph. Available options include None, Top Left, Bottom Right and Both.



**Sections colors:** It is configure bands for the sections to show different colors for Labels and Ticks in Level graph.


Example: Three bands

Section 1, Max % = 60 means, its band is from 0 to 60 %, and it will show labels and ticks in black color.

Section 2, Max % = 80 means its band is from 61 to 80 %.

Section 3, Max % = 100 means its band is from 81 to 100 %.

Note: Band setting is in % for the total Scale defined (Minimum to maximum).




**Active Color Section:** Defines the active color for the process value band. For example: If a process value range is 0-100, set different bands in % for the process value, and define colors to appear within the level Bar graph during Run Time.

When the process value is between 0 and 50 % of scale, display bricks in Lime color.  
 When the process value is between 51 and 80 % of scale, display bricks in Yellow color  
 When the process value is between 81 and 100 % of scale, display bricks in Red color.


**Configuration from Property grid**

ActiveColorSection	ColorSection[] Array
InactiveColorSection	ColorSection[] Array

Click the “ColorSection Array and the following screen will appear. Then, set all the bands and colors.




**Inactive Color Section:** Define Inactive colors for process value bands the same as above. Generally, light colors are selected for Inactive colors and dark colors with more contrast are selected for Active colors. This way, users/operators will be able to differentiate between active and inactive colors easily.




**Events:** It is to trigger functions/jobs to be executed when process value of tag linked with Level bar graph is changed during run time.

### 5.3.18.3 Meter

A Meter is a component generally used to display process values like pressure, Temperature, Flow etc. Generally, it is linked with an Analog tag (Analog input type tag at PLC, which is received as 4-20 mA signal from field transmitters like Temperature, pressure, etc...)





## Properties

**Back color:** It is to set back ground color for the Meter.

**Pointer Color:** It is to set Pointer Color.

**Bevel:** It is to set border including inner border, outer border, and style of border.

Inner Border: True/False


Outer Border: True/False

Style: 9 styles are available

None, Flat, Single, Double, Raised, Lowered, Double Raised, Double lowered, Frame Raised, and Frame Lowered.

**Text Font:** Used to set font for the label including Name of Font, Size of font and Style of font. Supported styles include Regular, Bold, Italic, Underline & Strikeout.

**Tag Binding:** Select the Analog Tag of process value.



### Labels:


**LabelsCount:** Number of labels to be displayed around the Meter.

**Example:** Pressure transmitter range 0-100 bar  
Label count =10 Around the Meter, you will see labels marked with 10, 20, 30, 40, 50, 60, 70, 80, 90 and 100.

**LabelsRadius:** It is to set the radius of Labels to be displayed around the Meter.

**LabelsVisible:** True/False, it is to set visibility for the label





**External Pointer Radius:** It is used to set external pointer Radius, define end position.

**Internal pointer Radius:** It is used to set Internal Pointer Radius, defines start position.

**Pointer Size:** It is to set Pointer Size in pixels.

**Pointer Type:** It is set Pointer type. Available types include Triangle, Circle and Line.

## Ticks

**Ticks Count:** Set number of ticks between labels.

**Ticks Length:** Set Tick length in pixels.

**Ticks Radius:** Set Tick Radius


**Ticks subdivision counts:** Set Tick sub division counts

**Ticks Visible:** True/False, Set Ticks visibility

## Center

**Width:** Adjust width of meter within boundaries.

**Height:** Adjust height of meter within boundaries. This is useful when a half-circle meter is required. The meter needs to be adjusted to the center as shown below.



## Circles



**Border circle Color:** Set border color for circle.

**Circle Color:** Set Color for circle.

**Circle Radius:** Set Radius for circle.



Note: If Border circle color is the same as the back color, then the circle will not be visible.



## Angles & Scale

**Maximum:** This is the maximum range of the Process Value (an Analog input Type Tag).

**Minimum:** This is minimum range of Process Value (Analog input Type Tag).

Example: If pressure transmitter range is 0 to 100 bar, set Minimum = 0, Maximum = 100.

**Start Angle:** It is the start angle for the Range low (Analog input)

**End Angle:** It is the end angle for the Range high (Analog input)

**Reverse Scale:** It is to set scale direction in Meter

**False:** Anti-Clockwise

**True:** Clockwise




Fig: Standard Reference angle

Reverse Scale = True

For example: If you want  $0^{\circ}$  (Left) to  $180^{\circ}$  (Right) Meter for Process value range 0-100, set the following.

Start Angle:  $0^{\circ}$ , End Angle:  $180^{\circ}$  and Reverse Scale = True.

## Behavior

**Step:** It is the minimum value to reflect change of pointer position in Meter.

For example: By default, Step = 0, i.e., the pointer moves its position in the Meter in Real time even with a minor change in process value.


For example: Step = 5, i.e., the pointer moves its position on the Meter in Real time in steps of 5.

**Value:** It is used to enter process value in design time and check pointer position in PC.



**Indicator only:** By default, it should be selected so that the meter will be used for Read purposes only. If it is not selected, then you can use the Meter for Write purpose similar to a Slider to send a set point from the Recorder to a PLC etc. Just use your finger and move pointer to change set point.

**Write design time value:** If selected, it writes design time value instead of default value defined at tag data base.



### **Sections colors:**

It is to configure bands for the sections to show different colors for Labels and Ticks in Meter.

Example: Three bands

Section 1, Max % = 60. That means its band is from 0 to 60%. It shows labels and ticks in black color.


Section 2, Max% =80 that means, its band is from 61 to 80 %.

Section 3, Max % = 100 that means, its band is from 81 to 100 %.


Note: Band setting is in % for the total Scale defined (Minimum to maximum).

### 5.3.18.4 Slider

This is normally used to change the set point of a process by the operator from the Recorder during Run time. Generally, it is linked with an analog tag (analog output type tag at PLC, to send 4-20 mA signal out from PLC to external Controllers, Variable speed drives, etc).



In the above figure, Scale divisions = 10 (Big ticks).  
Scale sub divisions = 5 (Small ticks between big ticks).  
Scale Label divisions = 10 (0, 10, 20 till 100).



## Properties

**Back color:** Back color for the component.

**Active bar color:** Define active bar color.

**Slider bar color:** Define border color for the slider.

**LED color:** Color of the handle

**Inactive bar color:** Define inactive bar color.

**LabelsPosition:** Define Label position. Available options include Top Left, Bottom Right, Both, Internal and None.

**Orientation:** Horizontal/Vertical. This is the orientation of the slider component. In the above figure, it is in the Horizontal position.

**Slide size:** Define height and width of the slider.

**Text Font:** It is to set the font for the label including Name of Font, Size of font and Style of font. Supported styles include Regular, Bold, Italic, Underline & Strikeout.

**Bevel:** It is to set a border including inner border, outer border and style of border.

Inner Border: True/False

Outer Border: True/False

Style: 9 styles are available

None, Flat, Single, Double, Raised, Lowered, Double Raised, Double lowered, Frame Raised, and Frame Lowered.

**Tag Binding:** Select the Analog Tag of a process value.



**Ticks:**

**Ticks Position:** Define ticks position. Available options include Top Left, Bottom Right, Both, Internal and None.

**Ticks Length:** Set Tick length in pixels

**Scale:**

**Scale divisions:** Define number of Scale divisions (Big ticks).

**Scale Sub Divisions:** Define number of Sub divisions (Small Ticks between big ticks).

**Scale Label Divisions:** Define number of Labels to appear. Ex. 0, 10, 20 etc. till 100 for scale 0 to 100.



Define same value for both Scale divisions and Scale label divisions.

**Scale Width:** Define Scale width.

Note: This is only the width for Scale divisions. Example: If ticks position is selected on both sides, then it is the gap between two scale ticks (Top and Bottom in Horizontal orientation or Left and Right in vertical orientation).

**Bar:**

**Bar Width:** Define width of Bar.



**Scale:**

**Maximum:** This is maximum range of Set point (Analog Tag, Normally Analog Output).

**Minimum:** This is minimum range of Set Point (Analog Tag, Normally Analog Output).

Example: If Controller set point is 0 to 100 Deg.C, set Minimum = 0, Maximum = 100.

**Reverse Scale:** If Selected, Scale labels will be displayed in Reverse.

**Behavior:**

**Step:** It is the minimum value change when the slider is moved.

For example: By default, Step = 0, i.e., Slider moves its position in Real time even with minor change in process value.

For example: If Step = 5, Slider moves its position in Real time in steps of 5.

**Value:** It is used to enter process value in design time and check the Slider position in PC.


**Indicator only:**



If Indicator only is selected, slider is used for Read only. Operator will be not able to move slider in Run time.

If Indicator only is not selected, the slider is used for Read/Write. Operator will be able to move slider in Run time for example: change set point for variable speed drive.

**Value Position:** Define position for the value to appear during Run time. Available options include Top left, Bottom Right, Both, Internal and None.



**Sections colors:** It is configure bands for the sections to show different colors for Labels and Ticks in Slider.

Example: Three bands

Section 1, Max% =60 means its band is from 0 to 60%. It shows labels and ticks in black color.


Section 2, Max% =80 means its band is from 61 to 80%. It shows labels and ticks in brown color.

Section 3, Max% =100 means its band is from 81 to 100%. It shows labels and ticks in Red color.

Note: Band setting is in % for the total Scale defined (Minimum to maximum).

### 5.3.18.5 Thermometer


This is normally used to view process temperature by operator during Run time. Generally it is linked with an analog tag (Analog input type tag at PLC, which is received as 4-20 mA signal from field transmitters like Temperature etc...)



Scale Label Divisions= 10 (0, 10, 20... 100)

Scale Divisions = 10 (No.of Big Ticks)

Scale Sub Divisions = 10 (No.of Small ticks between Big Ticks)



## Properties

**Back Color:** Define back color for the component.

**Liquid color:** Shows temperature level (mercury) in Thermometer.

**Tank Color:** Define background color of thermometer without mercury.

**LabelsPosition:** Define Label position. Available options include Top Left, Bottom Right, Both, Internal and None. The naming convention is based on the selected orientation of the component.

**Orientation:** Horizontal/Vertical. This is orientation of component. In the figure above, it is in the Horizontal direction.

**Indent:** It is the gap between border and start of scale.

**Text Font:** It is to set font for the label including the Name of Font, Size of font and Style of font. Supported styles include Regular, Bold, Italic, Underline & Strikeout.

**Bevel:** It is to set the border, including the inner border, outer border and style of border.


Inner Border: True/False

Outer Border: True/False

Style: 9 styles are available

None, Flat, Single, Double, Raised, Lowered, Double Raised, Double lowered, Frame Raised, and Frame Lowered.

**Tag Binding:** Select the Analog Tag of process value.



**Ticks Position:** Define ticks position. Available options include Top Left, Bottom Right, Both, Internal and None.

**Ticks Length:** Set Tick length in pixels


**Scale divisions:** Define number of scale divisions (Big Ticks) for the component.

**Scale Sub Divisions:** Define number of Sub divisions between the above scale divisions (Number of Small ticks between any two Big Ticks).

**Scale Label Divisions:** Define number of Labels to be displayed for component as per Scale Range of process value. For ex: 0, 10, 20, 30...100.

**Scale Width:** Define Scale width. If you have ticks on both sides of the component, it defines the width between Upper (Left) and Lower (Right) scale divisions based on orientation of component.

**Bar Width:** Define width of Bar in pixels.



**Maximum:** This is maximum range of the Set point (Analog Tag, Normally this is an Analog input, 20 mA, 10V DC etc.)

**Minimum:** This is minimum range of Set Point (Analog Tag, Normally this is an Analog input, 4 mA, 0V DC etc.)

Example: If Temperature transmitter range is 0 to 100 Deg.C, set Minimum = 0, Maximum = 100.

**Reverse Scale:** True/False. Define Scale direction.

**Step:** It is the minimum value to reflect change of mercury level.

For example: By default, Step = 0 means the Mercury level moves in Real time even with a minor change in process value.

For example: Step = 5 means the Mercury level moves its position in Real time in steps of 5.

**Value:** It is used to enter a process value during design time and check mercury level position on the PC.

**Indicator only:** If selected, this component is used for Read only. If it is not selected, then this component can be used for Write/Read purpose.

**Write design time value:** If selected, it writes design time values instead of default values defined in the tag database.

**Value Position:** Define position for the value to appear during Run time. Available options include Top left, Bottom Right, Both, Internal and None. The naming convention is based on the orientation of the component.




**Section Colors:** Define bands to display Ticks and Label color accordingly based on the value of the tag during Run time.

### 5.3.18.6 Bar Box

Bar Box is a Graphical User Interface widget that displays a bar graph for an Analog Tag during Run Time.

Every Bar box should be linked with an **Analog** Tag.



### Properties

**Border Style:** Define border style. Options include Fixed single, Fixed 3D and None.


**Direction:** Define direction of Bar graph. Up/Down/Left/Right

**Range high:** Display scale high.

**Range Low:** Display scale low.

**Value:** Default value. It is to check how fore color, back color displays in PC during design time.

**Tag Binding:** Select the Analog Tag of process value.



## **Bands**

It is to define various bands for the process value to appear and display animation in Run time.

**Band count:** Use up/down buttons to increase/decrease number of bands. Maximum 32 bands are supported. In each band, it is possible to configure back color, fore color and blink properties.

**Back color:** Define back color.

**Fore Color:** Define fore color.


**Blink:** Select “True” if blink is required and “False” if blink is not required.

**Blink color:** If “True” is selected for blink, then this property is visible and you can select required blink color.

**Value:** It is the band range. For the first band, it is always the Range Low value defined for the bar box. Band 1 high range is the value defined at Band2. Band 2 high range value is the value defined at Band3 and so on.

### 5.3.18.7 Scale

Scale is a Graphical User Interface widget used along with bar box if required.



#### Properties

**Back color:** Define back color

**Fore Color:** Define fore color

**Line width:** Define width of line

**Grids:** Define number of grids

**Direction:** Define direction of Scale. Up/Down/Left/Right


### 5.3.18.8 Picture box

Picture box permits the user to link different picture files into a Picture box component during design time and then later view them during Run time based on the value of the Tag. Supported formats include

Bitmap file (\*.bmp)

Windows Metafile (\*.wmf)

JPEG File (\*.jpg)  
 Graphics Interchange format (\*.gif)  
 Portable Network Graphic (\*.png)




## Properties

**Bitmap file** Select the image to be shown in the object

**Flip:** It is to flip picture file during design time. Available options are Horizontal, Vertical, Both and None.

**Rotate:** It is to select direction for the picture file during design time to adjust direction. Available directions include 0°, 90°, 180° and 270°


**Tag Binding:** Select the Analog tag to be linked with Picture box.



**Movement:** Select “Enable Move” if it is required to move picture during Run time from Location 1 to Location 2 based on a tag Value. Start and End

coordinates for X and Y needs to be configured during Design time, and the Picture moves in Run time based on a Tag value.

### **Tag Value:** Define Tag value



**Band Count:** Define number of bands required.

**Back Color:** Define back color for the selected picture file in specific band.

**Visible:** Define visibility for the picture in specific band.

**Bitmap file:** Select picture file for specific band.

**Image Layout:** Position of image within Picture container. Available options include None/Center/Stretch. When stretch is selected, it attempts to fit the picture file to the size of container.

**Transparent:** Select if no back color is required for picture file.

**Flip:** It is to flip picture file during design time. Available options are Horizontal, Vertical, Both and None.

**Rotate:** It is to select the direction for the picture file during design time to adjust direction. Available directions include 0°, 90°, 180° and 270°

Example: You may take a photo of a section of the factory floor like a tank, then use this on the Recorder screen instead of a default symbol.



A bitmap file by the name sunset.jpg is linked with PictureBox1 in screen1. If you wish to have the same sunset.jpg in screen no2, do not create picture box and link with sunset.jpg again. Since a resource with name sunset already available, if you try to use the same image in other place, it may not allow you to do so, and may give you an error message. If you really need the same image again, copy picture box1 at screen1 and paste it in screen no 2.


### 5.3.19 Graphics

Graphics are used to place a symbol in a screen like a Tank, Motor etc... Basic symbols are available in Recorder Editing Software and it includes the following symbol categories.

#### Symbol categories

	Category	Symbols	Colors	Qty
1	Arrows	7	6	42
2	Blowers	5	6	30
3	Boilers	4	6	24
4	Conveyors	6	6	36
5	Instruments- True Color	7	C	7
6	Lamps	4	6	24
7	Material handling	8	C	8
8	Motors	4	6	24
9	Nature-True Color	6	C	6
10	Office-True Color	7	C	7
11	Pipes	10	6	60
12	Power-True Color	7	C	7
13	Pumps	5	6	30
14	Push buttons	8	6	48
15	Tanks	5	6	30
16	Valves	8	6	48
17	Vehicles-True Color	6	C	6

C = True Color




Use these cursor points to change the size

Some symbols are available with 6 different colors. They are Red, Green, Yellow, Blue, Brown and Grey.

All the symbols are vector graphics. They occupy less memory and have high quality.

It is possible to set the transparent property for symbols during design time from the property grid. "Transparent" means the screen color itself will appear as back ground color, making the object appear to be see-through. Also, it is possible to change the symbol background color during design time and Run time.

*How to set the "transparent property to a symbol from the property grid*



Click "Bands", then set "BackColor" to "Transparent"





Fig: Back color=Transparent

Fig: Back Color=Green



Since all symbols are vector symbols, if a symbol is enlarged, it does not lose quality.

When Recorder Editing Software is installed, all basic symbols will be installed in the default folder C:\Program Files\Recorder Editing Software\Recorder Editing Software\Basic Symbols

In addition, if the application developer has any additional symbols, they can be placed in the same folder as the basic symbols for use in the project.

Example: Create a folder named "Custom", and place it in C:\Program Files\Recorder Editing Software\Recorder Editing Software\Basic Symbols

It is possible to set a path for graphic symbols in the Recorder software. On the Menu bar, click the "File" dropdown menu, select "Environment", then select "Graphics path". All these will appear in a tree type structure within Recorder editor avoiding the need to import these symbols using a "Picture Box".




Once a symbol is selected in the Recorder from Graphics, it is possible to change, Flip or rotate basic symbols in  $0^{\circ}$ ,  $90^{\circ}$ ,  $180^{\circ}$  and  $270^{\circ}$



### Properties


**Tag Binding:** Select an Analog Tag if animation is required for the symbol in Run time.



**Movement:** Select the Enable/Move checkbox, then, enter the X and Y start and end positions (this is in pixels).

**Tag Value:** Linked with the Start and End Positions.

**Ex: Recorder 7" (High Performance), Screen Resolution = 800 X 480, Horizontal installation, Width=800, Height=480. Move symbol from Left to Right of screen during Run time when tag value changes from 0 to 100**




To move the symbol from Left to Right, set start and end Positions for X coordinate in pixels, there is no need to set Y coordinates.

Tag value = 0 corresponds to Start Position (X)


Tag value = 1000 corresponds to End Position (X)

**Ex: Recorder 7" (High Performance), Screen Resolution = 800 X 480, Horizontal installation, Width=800, Height=480. Move symbol from Top to Bottom in screen at Run time when tag value changes from 0 to 100**



**Ex: Recorder 7" (High Performance), Screen Resolution = 800 X 480, Horizontal installation, Width=800, Height=480. Move symbol from Left Top to Right Bottom on screen at an angle during Run time when the tag value changes from 0 to 100**






**Band Count:** Used to define bands for run time animation of symbol. Max. 32 bands are supported.

**Back Color:** Define Back Color of the symbol that should appear in a specific band during Run time.

**Visible:** Define visibility control for the symbol in a specific band during Run time.


**Image:** Select different image file to display in a specific band during Run time.



**Flip:** Define the flip position for the symbol in a specific band during Run time. Available options include None, Horizontal, Vertical and Both.



**Rotate:** Rotate symbol to any predefined direction in a specific band during Run time. Available options include 0°, 90°, 180° and 270°

Example: There is Liquid level Tank. When the Tag value =0, an arrow should appear pointing in the Down direction indicating that a discharge of the tank is in progress. When the Tag value = 1, the arrow should appear in the Up direction indicating filling of tank is in progress.





### 5.3.20 Symbol Factory

Symbol Factory® contains more than 4000 symbols in 64 categories.

No.	Category	Symbols	No.	Category	Symbols
1	3-D Pushbuttons Etc.	73	35	Machining	90
2	Air Conditioning	140	36	Maps and Flags	23
3	Architectural	49	37	Material Handling	118
4	Arrows	63	38	Mining	63
5	ASHRAE Controls & Equipment	100	39	Misc. Pipes	39
6	ASHRAE Ducts	86	40	Misc. Symbols 1	57
7	ASHRAE Piping	49	41	Misc. Symbols 2	79
8	Basic Shapes	86	42	Mixers	24
9	Blowers Etc.	34	43	Motors	38
10	Boilers	36	44	Nature	71
11	Buildings	42	45	Operator Interface	28
12	Chemical	50	46	Panels	14
13	Computer Hardware	38	47	Pipes	82
14	Computer Keys	68	48	Plant Facilities	52
15	Containers	56	49	Power	61
16	Controllers	35	50	Process Cooling	20
17	Conveyors, Belt	40	51	Process Heating	61
18	Conveyors, Misc.	26	52	Pulp & Paper	35
19	Conveyors, Simple	56	53	Pumps	99
20	Ducts	51	54	Safety	27
21	Electrical	83	55	Scales	36
22	Finishing	45	56	Segmented Pipes	41
23	Flexible Tubing	24	57	Sensors	55
24	Flow Meters	35	58	Tank Cutaways	23
25	Food	72	59	Tanks	145
26	General Mfg.	68	60	Textures	181


27	Heating	108	61	Valves	73
28	HVAC	74	62	Vehicles	41
29	Icons and Bitmaps	159	63	Water & Wastewater	112
30	Industrial Misc.	19	64	Wire & Cable	21
31	International Symbols	42		Total	4045
32	ISA Symbols	183			
33	ISA Symbols (3-D)	123			
34	Laboratory	23			




With Recorder Editing Software, only the first symbol from the symbol factory can be selected. If you need all symbols, order our Recorder Editing Software Plus, and we will supply a USB hardware lock to access more than 4000 symbol factory graphics.



***It is possible to link a Analog Tag with a Symbol factory graphic and change its colors during Run time. Up to 50 bands are supported.***





## Design Time

During design time, the applications engineer is allowed to change the colors of these symbols.

Example: Change tank color from standard grey scale to Green color.

### Task: Place symbol on a screen



In Tool box, click “Symbol Factory”, then drag and drop a standard control to the screen.




Fig 1

Fig2

Fig3

Fig4


### Task: Increase size of symbol

Select the symbol on the screen. It will be as shown as in fig2 above.

Then, move mouse to a square pointer till an arrow appears. Left-click and hold the mouse. Drag the mouse to increase size of symbol as per your requirement and then it will be as shown as in Fig4 above. Alternatively, in the property grid, enter the size in pixels as shown below.

Size	120, 100
Height	100
Width	120


### Task: Changing symbol to another category



Drag and the drop symbol factory component onto a screen.

Click , then click on Symbol Factory.NET Properties.


Alternatively, select the symbol factory component using single click (left) with the mouse. Keep the mouse cursor on the symbol, then, double click (left) the mouse to open symbol properties. The following screen will pop up.



Select the required category, select the symbol, then click on button “OK”, then new symbol will be placed in screen.



Click on Help in the above screen to open a Chm type help file (English) for the symbol factory.




If the above error message appears, it is required to reinstall symbol factory.

## Style

Used to define the style of symbol in design time.




Click on “Style”. The following screen will appear.




**Fig: Default Style settings**

### **Orientation:**

**Flip:** It is possible to flip the symbol during Design time. Available options include Horizontal, Vertical, Both and None.



Flip=None



Flip = Horizontal


**Rotation:** It is possible to rotate symbol during design time. Available options include 0<sup>o</sup>, 90<sup>o</sup>, 180<sup>o</sup> and 270<sup>o</sup>

**Padding:** Normally it is 0. It is used to decrease size of symbol within selected boundaries.

**Stretch:** It is used to stretch symbol within selected boundaries.

### **Fill Color:**

**Fill color mode:** Available options include Original, Shaded, Solid and Hollow.



Fill Color Mode:	Original	Shaded	Solid	Hollow
Fill Color:	N.A	Green	Green	N.A

**Fill color:** Define color to be filled in Shaded and Solid fill color mode.

### **Background:**

**Back Style:** Available options include Transparent & Opaque. Transparent means screen background color will appear for symbol. Opaque means, it is possible to set different background colors for a specific selected symbol.

**Back color:** Define background color when the back style = Opaque.

### **Blink:**

**Blink mode:** Available options include No Blink, Blink Invisible, Blink shaded and Blink Solid.

**NoBlink:** Indicates “Blink” is not required for symbol during design time or Run time. Blink Speed and Blink color = Not available when this is selected.

**BlinkInvisible:** Symbol will appear and disappear cyclically during both design time and Run time per the set Blink speed. Blink color: Not Available for selection.

**BlinkShaded:** Symbol will flash 2 colors, one color at a time on the same symbol per the set blink speed during both design time and Run time.

Example

Fill Color mode = Shaded, Color = Green

Blink shaded setting: Blink mode=Blink shaded, Blink speed = Medium\_800, Blink color = Blue

The green color shaded symbol appears first, then the symbol turns into a blue shade after elapsing the preset time in the blink speed setting.

**Blink speed:** Define blink speed. Available options include Fast\_400, Medium\_800, and Slow\_1200. Its period is in *ms*.

**Blink color:** Define background color



Normally, blink is not used during design time. Default settings are as follows.

1. Fill Color Mode = Original. If a different color is required for the symbol, select Fill color mode = Shaded, then define the Fill color.
2. By default, Back Style = Transparent in Background
3. By Default, Blink mode = NoBlink

## **Animation**

It is to define animation for the symbol to appear at Run time in Recorder.

### **Animation mode:**

Define animation mode. Available options include Analog Color Fill, Discrete color fill, Analog integer color fill.

**AnalogColorFill:** Select this option if you wish to link an analog tag. Then define the band for the colors. For ex: 0 to 10, Color = Yellow, 10-90, Color = Green, 90-100, Color = Red etc.(See next section “How beak points work” for more details)

**DiscreteColorFill:** Select this option if you wish to pass discrete values like 1,2,3... during Run time to the Tag linked with symbol for the display of different colors. (See next section “How beak points work for more details)

**AnalogIntegerColorFill:** This is the same as Analog color fill, but only integer values are passed to the Tag linked with the symbol. (See next section “How beak points work for more details)

**Band count:** Defines the number of bands required for the selected Animation mode

**Styles:** Define style of symbols. Available options include Original, Shaded, Solid, Blink Invisible, Blink shaded and Blink solid. All definitions are the same as explained earlier.

### 5.3.20.1 How break points work

The idea behind Breakpoints is that certain animation will occur when a property of the component changes. If this change falls within the defined parameters (see below), an animation will be triggered.

**Please note:** The screen shots in the examples below are based upon the Symbol Factory .NET Standard Control, but the same principle applies to the Cutaway control.

Two types of animation can be defined based upon the setting of Animation Mode: Analog Break Points and Discrete Break points

#### **Analog Break points (Animation Mode = Analog integer color fill or Analog color fill)**

Analog breakpoints are defined as a value on which an animation will trigger when a property of the component reaches that level. Depending upon your component, different properties will need to be changed depending upon the setting of Animation Mode. These properties are:

Component	Animation Mode Setting	Property that Changes to trigger an Animation
Standard	AnalogColorFill	AnalogValue1
Standard	AnalogIntegerColorFill	AnalogIntValue1
Cutaway	AnalogColorFill	Level
Cutaway	AnalogIntegerColorFill	LevelInt

#### Number and Ordering of Breakpoints

The number of breakpoints available to you is the number of bands defined minus 1. As a breakpoint is defined as the point to which an animation changes, make sure you arrange the breakpoints from high to low. For example, suppose you had this screen:



When the value of your property changes, this is what will happen to the control:

Value of Property	Band that is Active	Appearance of Component
Less than 10	Band5	Blink Shaded Red
10 to < 20	Band4	Display Shaded Yellow
20 to < 80	Band3	Original
80 to < 90	Band2	Display Shaded Yellow
Greater than 90	Band1	Blink Shaded Red

If you do not order your breakpoints in a descending order, your results will be unpredictable.

Discrete break points (Animation mode = Discrete color fill)

Discrete Breakpoints aren't really breakpoints, instead, they enable animation if the "DiscreteValue" of an element in the BandsCollection is set to true.

However, since multiple DiscreteValue properties can be set at the same time, how does the component determine the animation to display? What it does is give priority

to the animations based upon their order in the BandsCollection. If the first band in the collection (by default, Band1) has its DiscreteValue set to True, then that animation will be shown no matter which band also has its DiscreteValue set to true. As another example, if Band2 and Band5 each have their DiscreteValue set, the animation that is used will be the one defined in Band2.

Therefore, given the following definition of five bands:




Here is what the animations will be shown based upon different values of Discrete Value

Discrete Value for Band1	Discrete Value for Band2	Discrete Value for Band3	Discrete Value for Band4	Discrete Value for Band5	Appearance of Component
<b>True</b>	False	False	False	False	Blink Shaded Red (Band1)
False	<b>True</b>	False	False	False	Shaded Yellow (Band2)
False	False	<b>True</b>	False	False	Original (Band 3)
False	False	False	<b>True</b>	False	Shaded Orange (Band 4)
False	False	False	False	<b>True</b>	Blink Shaded Black (Band 5)
<b>True</b>	<b>True</b>	<b>True</b>	<b>True</b>	<b>True</b>	Blink Shaded Red


					(Band 1)
False	<b>True</b>	<b>True</b>	<b>True</b>	<b>True</b>	Shaded Yellow (Band 2)
<b>True</b>	False	False	False	<b>True</b>	Blink Shaded Red (Band 1)
False	False	False	False	False	Original (No bands active)

### 5.3.21 Project Tools



### 5.3.22 Build

Once the project is compiled successfully, it creates a build. This build then needs to be transferred to the Recorder. If there are any errors during the preparation of the build, it will be shown in the output window just below the screen working area. If the Output screen is not visible below the screen working area, select it via Menu, "View", and then click "Output" or apply "Reset window layout" from the Menu-"View"




After creating a build, if any errors are shown at Output window, do not attempt to download the application from PC to Recorder, or PC to USB flash disk

First clear the errors and make sure that compilation errors are not present before transferring the application to the Recorder.

### 5.3.23 Build & Offline Simulation

First, it creates a build, then runs an Offline simulation.

It is used to test the application on the PC before downloading the application to the Recorder, without connecting a PLC to either PC or Recorder. It is possible to enter some values for the tags via a table to check how the application would appear during run time.



Tag	CurrentVal	SetVal
Tag1	12	
Tag2	0	
Tag3	0	
Tag4	0.0788529868553987	
Tag5	58.4416722356357	
Tag6	0	
Tag7	0.39426493427699	
Tag8	0.39426493427699	
Tag9	0	
Tag10	0	


Enter a value under the “SetVal” column, then press the enter key on your keyboard. It will accept, then show at “CurrentVal”. You will now be able to see these values in objects linked with the specific tag.



It is better to run offline simulation frequently say once in couple of hours or after completing specific screen editing by application engineer to verify how it will works on a Recorder so that if there are any compilation errors, it is easier to locate and rectify them.

### 5.3.24 Stop

It is used to stop a simulation on the PC. When Offline simulation is running, click the  icon to stop the current running simulation. See the picture below. It is located beneath the “help” dropdown menu.



If Offline simulation or online simulation is already running on the PC, and the user attempts to run it again, the build will fail. It prompts an error message similar to the following

#### Screen1

#### Build Started....

**Could not write to Output file “C:\Program Files\Project\Recorder\Panel.exe”  
“The process cannot access the file because it is being used by another process”**

#### Build Failed

In the case of the above message is prompted, click the Stop icon  a couple of times and make sure that icon  is not available in Task bar. Click “Build” once again, then run simulation.

### 5.3.25 Build & Download

It is to build first and then download application from PC to Recorder.

### 5.3.26 Download

It is to download application from PC to Recorder

Available options

- i) PC to Recorder via Ethernet
- ii) Removable Disk to Recorder via USB flash disk

### ***PC to Recorder via Ethernet:***


After creating an application, create a build on the PC, and make sure there are no compilation errors.

Connect Ethernet cable between PC and Recorder

In editor software, set Environment for Download via Ethernet and enter the IP address of the Recorder. In Environment, Select “Ethernet” at Download, then click the “OK” button.

In editor software, click “Project”, then click “Download” or click the  icon.

The software will build and transfer the application from the PC to the Recorder. If there are any errors during compilation, they need to be fixed. Once the compilation errors are fixed, please attempt to download again.



### ***Removable disk to Recorder***

After creating an application, create a build in the PC and make sure there are no compilation errors.

Connect USB flash disk in to PC via USB port.

In Recorder editor software, set “Environment” to Download via Removable disk. In Environment, Select “Removable disk” at Download and then, click the “OK” button.

In Recorder editor software, click “Project”, then click “Download” or click at  icon.

The application will transfer from the PC to the USB flash disk.

Insert USB flash disk in Recorder.

Switch on Power to the Recorder. Press “Load”, select Path of project files, then press “Load” button near path selection.


It transfers the application from the USB flash disk to the Recorder.

### **PC to Recorder via USB to Ethernet Converter**

For Low cost Recorder models, Ethernet is an option. You can purchase a USB to Ethernet converter to make it possible to download an application from PC to Recorder via Ethernet. Once USB to Ethernet converter is connected to Recorder, you can see the IP address at the Recorder itself via system information. This is similar to onboard Ethernet port.

Note: The purpose of USB to Ethernet converter is to download application from PC to Recorder only.

### **5.3.27 Project status**



	Total
Tag	0
Objects	1
Image	0
Connection	0
Alarm	0
Recipe	0
DataLog	0
Scheduler	0
UserScript	0
Security	1
Language	1

Project designed time

0 Days    0 Hours    0 Minutes


It is used for project management purposes and to know limits and usage of objects.

**Project used time:** It shows how much time a project has been opened for editing purpose.

\

## 6. WEBSERVER

It is used to view Paperless Recorder from a Remote location via Internet.



### 6.1 Requirements

#### 6.1.1 Hardware

Recommended hardware:  
PC with 3G GHz processor, 512 MB RAM.  
5.0GB free space in the hard disk.  
Ethernet port, RJ 45 female.

#### 6.1.2 Operating system

Windows based Operating systems, Windows XP, Windows 7, Windows 8 etc..  
32 bit and 64 bit operating systems are supported.

#### 6.1.3 Browser Requirements


Internet Explorer 10 or higher.  
Google Chrome.

## 6.1.4 IP Address Requirements

A Static IP address is required for the recorder.

Obtain a Static IP address from your Internet service Provider (ISP). This IP address should be unique.

Once the IP address is configured in the Recorder, use a Ping Instruction from the DOS prompt first to verify there is successful communication between the Recorder and the PC via Internet.



```
C:\ Command Prompt
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

E:\Documents and Settings\Mahi>ping 192.168.0.11

Pinging 192.168.0.11 with 32 bytes of data:

Reply from 192.168.0.11: bytes=32 time<1ms TTL=128

Ping statistics for 192.168.0.11:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms


E:\Documents and Settings\Mahi>_
```

Fig: Response from the Recorder for the Ping instruction from PC


## 6.2 How to configure Web server Settings

For using Web server application in the PR series Recorder, Configuring the Recorder for a static IP address, and enabling the Web server.

## 6.2.1 How to Configure Static IP Address



In the Configuration screen, select “Communication”, then press the “Enter” soft key.




Select IP type = User Define.


Enter the IP Address, Subnet Mask, Default Gateway, and DNS Server Settings in the Ethernet Settings.

Note: Make sure to enter Global, Unique, static fix IP address received from Internet solution provider.

## 6.2.2 How to Enable Web Server



Select Web Server Menu in the Communication screen.  
Enable the Web Server for using Web Server application in the Recorder.



After completing the above steps, press the “BACK” key, then the “Home” key to return to the main menu. It will save the configuration settings in the Recorder.

Now the Recorder is ready for the Web Server Applications.

**Note: The Web Server update time on the browser is 1 second for real time data and statuses and 5 Seconds for Alarms.**

### 6.3 How to View Recorder Data in PC via Webserver:

Connect Paperless Recorder to the Internet

Open the browser (Internet Explorer 10 or Google Chrome) in the PC



Enter the IP address of the Recorder in the address bar of the browser.

Format: `http://192.168.1.111`

Now you can see the Paperless Recorder screens in browser as shown below



The display includes Real time values of all channels like AI, Math, Counters, Totalizers, Real time alarms, historical alarms, status of Digital Inputs, Digital Outputs, Analog Outputs, Counters, and Totalizers etc...




Press Overview to view the summary of all data in single screen




By pressing “Mode”, you can view the data in Bar Graphs, Trends and Digital Values.


By Pressing Trend you can view the data in trends.



By pressing “Bar”, you can view the data in Bar Graphs



By pressing “Digit”, you can view the Data in the digital format



By pressing “Alarm”, you can view the List of Alarms along with the details


No.	Active Time	Acked	Type	Name	Value
1	18/10/14 18:22:12		Alarm	A1	10.10
2	18/10/14 18:22:12		Alarm	A2	10.10
3	18/10/14 18:22:12		Alarm	A3	10.10
4	18/10/14 18:22:12		Alarm	A4	10.10
5	18/10/14 18:22:12		Alarm	A5	10.10
6	18/10/14 18:22:12		Alarm	A6	10.10
7	18/10/14 18:22:12		Alarm	A7	10.10
8	18/10/14 18:22:12		Alarm	A8	10.10
9	18/10/14 18:22:12		Alarm	A9	10.10
10	18/10/14 18:22:12		Alarm	A10	10.10
11	18/10/14 18:22:12		Alarm	A11	10.10
12	18/10/14 18:22:12		Alarm	A12	10.10
13	18/10/14 18:22:12		Alarm	A13	10.10
14	18/10/14 18:22:12		Alarm	A14	10.10
15	18/10/14 18:22:12		Alarm	A15	10.10
16	18/10/14 18:22:12		Alarm	A16	10.10
17	18/10/14 18:22:12		Alarm	A17	10.10
18	18/10/14 18:22:12		Alarm	A18	10.10
19	18/10/14 18:22:12		Alarm	A19	10.10
20	18/10/14 18:22:12		Alarm	A20	10.10
21	18/10/14 18:22:12		Alarm	A21	10.10
22	18/10/14 18:22:12		Alarm	A22	10.10
23	18/10/14 18:22:12		Alarm	A23	10.10
24	18/10/14 18:22:12		Alarm	A24	10.10
25	18/10/14 18:22:12		Alarm	A25	10.10
26	18/10/14 18:22:12		Alarm	A26	10.10
27	18/10/14 18:22:12		Alarm	A27	10.10
28	18/10/14 18:22:12		Alarm	A28	10.10
29	18/10/14 18:22:12		Alarm	A29	10.10
30	18/10/14 18:22:12		Alarm	A30	10.10

By pressing “Status”, you can view the status of the Analog outputs, Digital Inputs, Digital Outputs, Counters and Totalizers.

By pressing “DI”, you can view the status of the Digital Inputs


DI	DO	AO	Counter	Totalizer	No.	Name	Value	Description
1					1	DI1	Hi	
2					2	DI2	3	
3					3	DI3	Hi	
4					4	DI4	3	
5					5	DI5	Hi	
6					6	DI6	3	

By pressing “DO”, you can view the status of the Digital outputs




No.	Name	Value	Description
1	DO1	Off	
2	DO2	Off	
3	DO3	Off	
4	DO4	Off	
5	DO5	Off	
6	DO6	Off	

By pressing “AO”, you can view the status of the Analog Outputs




No.	Name	Value	Description
1	AO1	4.106	
2	AO2	5.421	
3	AO3	6.737	
4	AO4	8.051	
5	AO5	9.368	
6	AO6	10.684	

By pressing “Counters”, you can view the status of the counters



No.	Name	Value	Description
1	Counter9	0	
2	Counter1	0	
3	Counter2	0	
4	Counter3	0	
5	Counter4	0	
6	Counter5	0	
7	Counter6	0	
8	Counter7	0	
9	Counter8	0	

By pressing “Totalizers” you can view the status of the totalizers.



No.	Name	Value	Description
1	Totalizer1	0.000	
2	Totalizer2	5.064e+5	
3	Totalizer3	1.347e+5	
4	Totalizer4	2.765e+5	
5	Totalizer5	5.656e+5	
6	Totalizer6	5.433e+5	
7	Totalizer7	5.559e+4	
8	Totalizer8	5.464e+4	





## **Warranty - Important !!**

The present handbook is merely indicative, and it is subject to changes in any moment, without giving any notice.

The not respecting strictly the indication found on this handbook, the opening and tampering the product, the incorrect use, the wrong wiring, the using of spare parts or optional not original CEAM Control Equipment, the removing of the labels, of the identification marks put by CEAM Control Equipment, and the hidden export to Extra CE counties, they make immediately lose the responsibility over the product and the warranty right!

### **WARRANTY TERMS:**

The product is under warranty for a period of 12 Months (Art. 1490 C.C. and following) starting by the delivery note date, also in case it is in vision, and then transformed in selling, the complete text of the warranty conditions offered by CEAM Control Equipment in conformity to the actual laws, are published, and are at disposal of any people which demand for them, the document is registered both in paper form and in electronic form, to the CEAM Control Equipment, headquarter, and to see it, it is sufficient to make a written request, specifying the title of the applicant.

### **The warranty cover:**

The products and the components which bad functioning is referable for sure to production defects, the eventual defect met gives only the right to repair it, and not to substitute the product, besides the eventual production defect, does not give any right to resolute the contract, or to suspend the payment if not expressly agreed in written by CEAM.

### **The warranty does not cover:**

Defects generated by incorrect or improper use of the product  
Defects generated by using spare parts or consumables products not original CEAM  
Defects generated by environmental and/or atmospheric problems and/or natural calamity  
Products and/or services tampered or modified even partially  
Products and/or services to which have been taken off, or tampered, even partially, labels and lot codes original CEAM

### **In any case, the warranty does not cover:**

Batteries, magnetic devices, perishable products and/or consumable products  
The components of Third parts, to which it must answer directly, the assistance service of the same, with the modalities provided from them.  
The technical time used to verify and/or to repair the products  
The travelling allowance, and the technical intervention on the place, if effected.  
The packaging and shipping cost of the products there and back.  
All the additional costs supported by CEAM to fulfil the warranty.

### **Clause of responsibility exclusion:**

CEAM does not assume any responsibility, regarding eventual damages, direct or in direct, caused to people or things, or damages for non production and/or incorrect production and/or eventual damage, in some way referable to the product and/or to this handbook service.

CEAM does not assume any responsibility regarding eventual damages caused to people or things because of the eventual not conformity to the product and/or service of the present handbook, which is merely indicative, and that can be changed by CEAM in any moment without giving any notice.



## **How to order**

The instruments of the CEAM PR series can be ordered in various versions (Dimensions) and with various hardware arrangements and accessories selected directly online by [www.sensorstore.it](http://www.sensorstore.it)





Company With Quality System Certified  
**UNI EN ISO 9001:2008**

# CEAM Control Equipment

Headquarters:

Via Val D'Orme No. 291

50053 Empoli (Firenze) Italy

Tel. (+39) 0571 924082 - Fax. (+39) 0571 924505

 **Skype Name: ceam\_info**

**CEAM is official partner of Branchild**

**Internet:**

Portale Web Generale del Gruppo: [www.ceamgroup.com](http://www.ceamgroup.com)

Divison: [www.ceamcontrolequipment.it](http://www.ceamcontrolequipment.it)

Brand area: [www.brainchild.it](http://www.brainchild.it)

Technical support: [www.ceamsupport.it](http://www.ceamsupport.it)

**Indice servizi E.mail:**

Informazioni Generali: [info@ceamgroup.it](mailto:info@ceamgroup.it)

Servizio Assistenza Vendite: [sales@ceamgroup.it](mailto:sales@ceamgroup.it)

**Rivenditore di zona:**